



[Manuals.plus](#) /

› [AKORD](#) /

› AKORD K120 Artisan Oak Chest of Drawers User Manual

AKORD K120

AKORD K120 Artisan Oak Chest of Drawers User Manual

Model: K120

INTRODUCTION

This user manual provides essential information for the assembly, operation, and maintenance of your AKORD K120 Artisan Oak Chest of Drawers. Designed for modern interiors, this functional furniture piece features six spacious drawers and a durable surface, making it an ideal addition to hallways, living rooms, or bedrooms. Please read these instructions carefully before proceeding with assembly and use to ensure proper functionality and longevity of your product.



Figure 1: Front view of the AKORD K120 Artisan Oak Chest of Drawers. This image displays the dresser's overall appearance, highlighting its six graphite grey drawers and the artisan oak finish of the frame. A camera and books are placed on top, demonstrating its use as a display surface.

SETUP AND ASSEMBLY

The AKORD K120 Chest of Drawers is delivered unassembled and requires self-assembly. Follow the included assembly instructions and use all provided mounting accessories. It is recommended to have a clear, spacious area for assembly and to use appropriate tools (e.g., screwdriver, hammer) as needed. Ensure all components are present before beginning assembly.

1. Unpack all components and verify against the parts list in the separate assembly guide.
2. Identify the main panels (top, bottom, sides, back) and drawer components.
3. Assemble the main frame of the chest of drawers according to the step-by-step diagrams.
4. Install the metal drawer guides onto the side panels of the frame.
5. Assemble each of the six drawers, ensuring the bottom panel is securely fitted and the drawer guides are attached correctly.
6. Insert the assembled drawers into the frame, ensuring they slide smoothly.
7. Secure the back panel to the frame for added stability.






Figure 2: Dimensions of the AKORD K120 Chest of Drawers and its drawers. This diagram provides precise measurements for the overall unit and individual drawers, which is helpful for planning placement and understanding component sizes during assembly.

OPERATION AND USAGE

The AKORD K120 Chest of Drawers is designed for versatile use in various home environments. Its six drawers provide ample storage for clothing, linens, documents, or other household items, helping to maintain an organized space. The smooth metal guides ensure easy opening and closing of the drawers.

- **Placement:** This chest of drawers is suitable for hallways, living rooms, bedrooms, or study areas. Ensure it is placed on a level surface to prevent wobbling.
- **Storage:** Utilize the six drawers for organized storage. Avoid overloading drawers to ensure smooth operation and prevent damage to the guides.
- **Surface Use:** The top surface can be used to display decorative items, plants, or even a television, adding style to your room.



Figure 3: The K120 dresser integrated into a modern living room. This image illustrates how the dresser can complement contemporary decor and function within a living space, showcasing its aesthetic appeal and versatility.



Figure 4: The K120 dresser with drawers open. This view demonstrates the functionality of the drawers, showing their capacity and the smooth operation of the metal guides, which are designed for easy access to stored items.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your AKORD K120 Chest of Drawers. The surface is designed to be resistant to mechanical damage, abrasion, water, and stains, making it easy to maintain.

- **Cleaning:** For general cleaning, wipe the surface with a dry or slightly damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** In case of spills, wipe them immediately with a clean, dry cloth to prevent staining.
- **Protection:** While resistant, it is advisable to use coasters or protective pads under hot items or items that might scratch the surface.
- **Drawer Guides:** Periodically check the drawer guides for any debris and clean if necessary. If drawers become stiff, a small amount of silicone spray or wax can be applied to the metal guides.



Figure 5: Detail of the dresser's finished edges. This image highlights the quality of the ABS-coated edges, which contribute to the durability and aesthetic appeal of the furniture, protecting it from wear and tear.

This section addresses common issues you might encounter with your chest of drawers.

Problem	Possible Cause	Solution
Drawers are stiff or do not slide smoothly.	Misaligned drawer guides, debris in guides, or guides require lubrication.	<ul style="list-style-type: none">• Ensure drawer guides are properly aligned and securely fastened.• Clean any dust or debris from the metal guides.• Apply a small amount of silicone spray or wax to the metal guides for smoother operation.
Chest of drawers is wobbly.	Uneven floor surface or loose assembly connections.	<ul style="list-style-type: none">• Ensure the chest is placed on a flat, level surface.• Check all assembly screws and connections and tighten them if loose.• If necessary, use furniture pads or shims under the legs to stabilize.
Visible gaps between drawers or panels.	Incorrect assembly or loose connections.	<ul style="list-style-type: none">• Review the assembly instructions to ensure all panels are correctly oriented and joined.• Tighten all screws and cam locks to pull components together firmly.

SPECIFICATIONS

Brand	AKORD
Model	K120
Color	Artisan Oak with Graphite Grey Fronts
Product Dimensions (W x D x H)	120 cm x 40 cm x 77 cm (approximately 47.2 x 15.7 x 30.3 inches)
Product Weight	47.5 kg (approximately 104.7 lbs)
Material	16 mm thick laminated particle board
Edges	ABS resistant to abrasion
Drawers	6 drawers with metal guides
Assembly Required	Yes, self-assembly with included accessories and instructions.

WARRANTY AND SUPPORT

For any questions regarding your AKORD K120 Chest of Drawers, including assembly assistance, missing parts, or product defects, please contact the seller or manufacturer directly. Keep your purchase receipt as proof of purchase.

While specific warranty details are not provided in this manual, most furniture products come with a limited manufacturer's warranty covering defects in materials and workmanship. Please refer to the terms and conditions provided at the time of purchase or contact the seller, Furniture-Akord, for detailed warranty information.

For support, you may visit the AKORD brand store on Amazon: [AKORD Brand Store](#)

© 2024 AKORD. All rights reserved. Information in this manual is subject to change without notice.