



Manuals.plus /

› FINETONES /

› FINETONES 6-Drawer Tall Dresser (Model: US-43LUC-KIE68-ES2) Instruction Manual

FINETONES US-43LUC-KIE68-ES2

FINETONES 6-Drawer Tall Dresser Instruction Manual

Model: US-43LUC-KIE68-ES2

1. INTRODUCTION

Thank you for choosing the FINETONES 6-Drawer Tall Dresser. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1: The FINETONES 6-Drawer Tall Dresser, a white modern furniture piece with six spacious drawers, shown in a living room environment.

2. SAFETY INFORMATION

To ensure safe use of your dresser, please observe the following precautions:

- **Anti-Tip Kit:** Always install the included anti-tip kit to prevent the dresser from tipping over, especially in households with children.
- **Weight Distribution:** Distribute weight evenly across drawers. Place heavier items in lower drawers to enhance stability.
- **Weight Limits:** Do not exceed the maximum weight capacity for each drawer or the top surface.
- **Child Safety:** Do not allow children to climb on or play with the dresser. Keep small parts away from children during assembly.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all fasteners are securely tightened before use.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. Refer to the detailed parts list provided in

your separate assembly guide. If any components are missing or damaged, please contact FINETONES customer support.

4. SETUP AND ASSEMBLY

Assembly of the FINETONES 6-Drawer Tall Dresser requires following the step-by-step instructions provided in the separate assembly manual. It is recommended to have two people for assembly to ensure stability and ease of construction.

1. Unpack all components and lay them out on a clean, soft surface to avoid damage.
2. Identify all parts and hardware using the provided list.
3. Follow the numbered steps in the assembly manual carefully. Ensure all screws and connectors are tightened appropriately.
4. Once the main frame is assembled, install the drawer slides and then construct the drawers.
5. Attach the handles to the drawers.
6. Finally, install the anti-tip hardware to secure the dresser to a wall.



Image 2: Dimensional diagram of the dresser, showing overall height (123cm/48.4in), width (60cm/23.6in), and depth (40cm/15.7in), along with individual drawer dimensions.

5. OPERATING INSTRUCTIONS

The FINETONES 6-Drawer Tall Dresser is designed for organized storage. To operate the drawers:

- **Opening Drawers:** Gently pull the handle to open a drawer. Avoid excessive force.
- **Closing Drawers:** Push the drawer firmly until it is fully closed and flush with the dresser frame.
- **Loading Drawers:** Place items neatly inside the drawers. Avoid overfilling, which can cause drawers to stick or damage the slides.
- **Stability:** For optimal stability, avoid opening multiple drawers simultaneously, especially the top ones.

6. MAINTENANCE

Proper care will extend the life and appearance of your dresser:

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- **Environment:** Avoid placing the dresser in direct sunlight or near heat sources, which can cause warping or discoloration.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or obstruction.	Check that drawer slides are correctly installed and aligned. Ensure no items are blocking the drawer path.
Dresser feels unstable or wobbly.	Loose fasteners or uneven floor.	Tighten all assembly screws. Ensure the dresser is on a level surface; use shims if necessary. Verify anti-tip kit is securely installed.
Drawer handles are loose.	Screws securing handles are loose.	Tighten the screws from inside the drawer that secure the handles.

8. SPECIFICATIONS

Feature	Detail
Brand	FINETONES
Model Name	6 drawer dresser
Item Model Number	US-43LUC-KIE68-ES2
Product Dimensions	15.75"D x 23.63"W x 48.4"H
Color	White
Material	Engineered Wood
Finish Type	MDF
Number of Drawers	6
Item Weight	86.2 Pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

9. WARRANTY AND SUPPORT

For warranty information, customer support, or to order replacement parts, please refer to the contact details provided with your purchase documentation or visit the official FINETONES website. Please have your model number (US-43LUC-KIE68-ES2) and purchase date available when contacting support.