Fafeicy Fafeicyeqbd10vwtc

Fafeicy Wildlife Game Camera User Manual

Model: Fafeicyeqbd10vwtc

1. Introduction

Thank you for choosing the Fafeicy Wildlife Game Camera. This manual provides detailed instructions for the proper setup, operation, and maintenance of your camera. Please read this manual thoroughly before using the device to ensure optimal performance and longevity. This camera is designed for various applications including wildlife observation, home security, and general outdoor surveillance.

2. Product Overview

The Fafeicy Wildlife Game Camera is a robust and reliable device capable of capturing high-quality images and videos in various outdoor conditions. It features a 16MP camera for still photos and 1080P video recording with sound. The camera is equipped with 38 infrared LEDs for clear night vision and a fast 0.7-second trigger speed to ensure no moment is missed. Its IP66 waterproof rating allows for long-term outdoor placement.



Image 2.1: Angled front view of the Fafeicy Wildlife Game Camera, showcasing its camouflage casing and lens.

3. Package Contents

Verify that all items are present in your package:

- 1 x Wildlife Game Camera
- 1 x Mounting Tape
- 1 x User Manual



Image 3.1: The Fafeicy Wildlife Game Camera shown alongside its included mounting strap.

4. Setup

4.1 Battery Installation

The camera requires 4 or 8 AA batteries (not included). Open the camera's back cover to access the battery compartment. Insert the batteries according to the polarity markings (+/-) inside the compartment. Ensure the cover is securely closed to maintain the waterproof seal.

4.2 Memory Card Installation

This camera supports a Micro SD card up to 128GB (not included). Locate the Micro SD card slot inside the camera. Insert the card with the gold contacts facing down until it clicks into place. To remove, push the card in again until it springs out.



Image 4.1: Front and back views of the camera, illustrating the access points for batteries and memory card.

4.3 Mounting the Camera

Use the provided mounting tape to secure the camera to a tree or pole. The camera also features a standard tripod mount at the bottom for alternative mounting options. Position the camera to capture the desired area, ensuring it is stable and secure.



Image 4.2: Bottom view of the camera, showing the tripod mounting thread and strap loops.

5. Operating Instructions

5.1 Powering On/Off

To power on the camera, slide the power switch to the 'ON' position. The 2.0 TFT color screen will illuminate, indicating the camera is active. To power off, slide the switch to the 'OFF' position.

5.2 Mode Selection and Settings

Use the navigation buttons on the control panel to access the menu on the 2.0 TFT color screen. Here you can select between photo mode, video mode, or a combination. Adjust settings such as photo resolution (up to 16MP), video resolution (1080P), burst photo count (1-3 photos), video clip length (10 seconds to 3 minutes), and time-lapse options.

5.3 Capturing Images and Videos

Once configured, the camera will enter surveillance mode. The Passive Infrared (PIR) sensor, with a 120° detection angle and approximately 10m/33ft range, will detect motion. Upon detection, the camera will trigger within 0.7 seconds to capture images or videos according to your settings. For night recording, the 38pcs 940nm IR LEDs will automatically activate to provide illumination without disturbing wildlife.



Image 5.1: Front view of the camera, highlighting the lens and the array of infrared LEDs for night vision.

6. Maintenance

6.1 Cleaning

Regularly clean the camera lens and PIR sensor window with a soft, dry cloth to ensure clear images and proper motion detection. Avoid using abrasive cleaners or solvents.

6.2 Storage

When not in use for extended periods, remove the batteries to prevent leakage. Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.

6.3 Environmental Durability

The camera is designed with an IP66 waterproof rating, making it resistant to dust and strong jets of water. It can

withstand extreme outdoor temperatures ranging from -20°C to +70°C.

7. Troubleshooting

If you encounter issues with your camera, please refer to the following common problems and solutions:

- **Camera not powering on:** Ensure batteries are inserted correctly with proper polarity and are fully charged. Check for a low battery reminder (4.2V).
- **Poor image/video quality:** Clean the camera lens. Ensure the camera is positioned correctly and there are no obstructions. Check lighting conditions.
- **Motion detection issues:** Verify the PIR sensor window is clean and unobstructed. Adjust camera placement to optimize detection range and angle.
- **Memory card errors:** Ensure the Micro SD card is correctly inserted and formatted. Try a different compatible Micro SD card.

8. Specifications

Feature	Specification
Display	2.0 TFT Color Screen
Image Sensor	1MP Color CMOS
Maximum Photo Resolution	4640x3488 (16MP)
Photo Sizes	16MP, 12MP, 5MP, 3MP, 1.3MP
Video Resolution	1920x1080P (Full HD)
Trigger Speed	0.7 seconds
Infrared LEDs	38pcs 940nm IR LEDs
Burst Mode	1-3 photos per trigger
Video Clip Length	10 seconds to 3 minutes
PIR Detection Angle	120°
Lens Angle	90°
PIR Detection Distance	Approx. 10m / 33ft
Power Supply	4 or 8 x AA Batteries (not included)
Standby Time	4-8 months
Low Battery Reminder	4.2V
Operating Temperature	-20°C to +70°C
Waterproof Rating	IP66
Memory Support	Up to 128GB Micro SD Card (not included)

Video Capture Format	MPEG-4
Photo Sensor Technology	CMOS
Item Weight	12.7 ounces
Special Feature	Noise Reduction

9. Safety Information

Please adhere to the following safety guidelines:

- Always supply power according to the applicable power supply specifications (4 or 8 AA batteries).
- Do not attempt to disassemble or modify the camera, as this may void the warranty and cause damage.
- Keep the camera away from strong magnetic fields and corrosive substances.
- Dispose of batteries responsibly according to local regulations.

10. Warranty and Support

If you have any questions about the product, require technical assistance, or need to address any concerns, please contact our customer support team. We are committed to providing you with the best possible solution.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question