Whirlpool W10889841

Whirlpool W10889841 OEM Refrigerator Fresh Food Evaporator Cover Assembly

Model: W10889841

Product Overview

This Whirlpool W10889841 OEM Refrigerator Fresh Food Evaporator Cover Assembly is designed to cover the evaporator located at the back of your refrigerator's fresh food compartment. This assembly includes the fan motor and associated wiring, crucial for proper air circulation and cooling within the fresh food section.




Image 1: Whirlpool W10889841 Refrigerator Fresh Food Evaporator Cover Assembly.

What's in the Box: One Whirlpool W10889841 Genuine OEM Refrigerator Fresh Food Evaporator Cover

Assembly.

Important Safety Information

WARNING: Always disconnect power to your refrigerator before attempting any repairs or maintenance. Wear appropriate personal protective equipment, such as gloves and safety glasses. If you are unsure about any step, consult a qualified appliance technician. Improper installation or repair can lead to property damage, personal injury, or death.

Compatibility

This W10889841 Evaporator Cover Assembly is compatible with various Whirlpool refrigerator models, including but not limited to:

- WRF993FIFM
- WRF992FIFM
- WRF995FIFZ
- WRF992FIFH
- WRF992FIFE

It also replaces previous part numbers **W10772277** and **W10875099**. To ensure correct fitment, always verify compatibility with your specific appliance model number.



Image 2: Understanding OEM (Original Equipment Manufacturer) parts.

Installation Instructions

Replacing the evaporator cover assembly requires careful attention to detail. It is recommended that this

procedure be performed by a qualified service technician. If you choose to proceed yourself, ensure you have the correct tools and refer to your specific refrigerator model's service manual for detailed, step-by-step instructions.

General steps typically involve:

1. Disconnecting the refrigerator from its power source.
2. Removing any shelves or drawers obstructing access to the evaporator cover.
3. Carefully detaching the old evaporator cover assembly, noting the position of all wires and fasteners.
4. Connecting the new assembly's fan motor and wiring.
5. Securing the new evaporator cover assembly in place.
6. Replacing any removed components.
7. Restoring power to the refrigerator and checking for proper operation.




Image 3: Top-down view of the evaporator cover assembly, showing fan and wiring.

Your browser does not support the video tag.

Video: This video from Whirlpool Service Parts highlights the importance of using genuine OEM parts for appliance longevity and performance.

Maintenance

Regularly inspect the evaporator cover area for any ice buildup or debris. Ensure the fan motor operates quietly and efficiently. Keep the fresh food compartment clean to prevent blockages that could affect air circulation and the performance of the evaporator cover assembly.

Troubleshooting

If your refrigerator is experiencing issues such as inadequate cooling in the fresh food compartment, unusual noises from the back of the compartment, or excessive frost buildup on the evaporator coils, the evaporator cover assembly or its fan motor may be faulty. Consult your appliance's troubleshooting guide or a professional technician for diagnosis.

Specifications

Item Weight: 5.57 pounds

Product Dimensions: 6.38 x 25.19 x 19.25 inches

Model Number: W10889841

Warranty Information

This Whirlpool W10889841 OEM Refrigerator Fresh Food Evaporator Cover Assembly comes with a one-year warranty from Whirlpool. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Support and Contact Information

For further assistance, technical support, or to inquire about warranty service, please visit the official Whirlpool brand store page or contact Whirlpool customer service directly. You can find contact details on the Whirlpool website or your appliance's original documentation.