

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Selgo](#) /

› Replacement Clean Tank With Cap for Bissell TurboClean PowerBrush Pet Carpet Cleaner Machines - Part #1623828 User Manual

Selgo 1623828

Replacement Clean Tank With Cap for Bissell TurboClean PowerBrush Pet Carpet Cleaner Machines - Part #1623828

Brand: Selgo | Model: 1623828

PRODUCT OVERVIEW

This instruction manual provides essential information for the installation, operation, and maintenance of your Selgo Replacement Clean Tank with Cap. Designed as a high-quality replacement part, it ensures optimal performance and extends the lifespan of compatible Bissell TurboClean PowerBrush Pet Carpet Cleaner models. The tank is engineered for durability and features a leak-proof design to effectively manage cleaning solutions and collected debris.

COMPATIBILITY

This replacement clean tank with cap is specifically designed to fit the following Bissell TurboClean PowerBrush Pet Carpet Cleaner models:

- 2987
- 2806
- 28062
- 28068
- 29878
- 29879

Please verify your carpet cleaner's model number to ensure proper fit and function. The included cap is integral to the leak-proof seal.

COMPATIBLE TANK & CAP



Figure 1: Compatible Clean Tank and Cap. This image illustrates the correct clean tank and cap design for proper fit with specified Bissell models.

KEY FEATURES

- **Perfect Fit and Easy Installation:** Designed to perfectly fit specified Bissell TurboClean PowerBrush Pet Carpet Cleaner models. The installation process is quick and hassle-free.
- **Improved Cleaning Efficiency:** Ensures your carpet cleaner continues to deliver powerful cleaning performance, effectively removing dirt, stains, and pet messes.
- **Durable and Long-Lasting:** Crafted from high-quality materials to withstand regular use and provide reliable performance.
- **Leak-Proof Design:** The included cap ensures a secure and leak-proof seal, preventing spills and helping maintain suction power.
- **Pet-Friendly Cleaning:** Effectively tackles pet messes and odors, leaving carpets fresh and odor-free.

SETUP AND INSTALLATION

Replacing the clean tank is a straightforward process. Ensure your carpet cleaner is unplugged before proceeding.

1. **Remove Old Tank:** Locate the existing clean water tank on your Bissell TurboClean PowerBrush Pet Carpet Cleaner. Depending on your model, there may be a latch or button to release it. Carefully lift and remove the old tank.

2. **Prepare New Tank:** If not already attached, ensure the new cap is securely fastened to the replacement clean tank.
3. **Install New Tank:** Align the replacement clean tank with the designated slot on your carpet cleaner. Gently push down until it clicks securely into place. Ensure it is firmly seated to prevent leaks during operation.
4. **Fill Tank:** Refer to your carpet cleaner's original manual for instructions on filling the clean tank with the appropriate cleaning solution and water mixture.



Figure 2: Selgo Replacement Clean Tank with Cap. This image displays the transparent clean tank, ready for installation into a compatible carpet cleaner.

OPERATING THE CLEAN TANK

The clean tank is an essential component of your carpet cleaner's operation, holding the fresh cleaning solution and dispensing it during use. It works in conjunction with the dirty water tank to ensure effective cleaning.

- **Clean Water Supply:** The clean tank holds the mixture of water and cleaning formula. When the cleaner is in operation and the spray trigger is activated, this solution is dispensed onto the carpet.
- **Solution Flow:** The design of the tank and its cap ensures a controlled flow of cleaning solution, allowing for even application across the carpet surface.
- **Separate Tanks:** The clean tank is distinct from the dirty water collection tank, preventing cross-contamination and ensuring that only fresh solution is applied to your carpets.





Figure 3: Bissell TurboClean PowerBrush Pet Carpet Cleaner. The clean tank is located at the top of the machine, holding the fresh cleaning solution.

MAINTENANCE

Proper maintenance of your clean tank will ensure its longevity and the continued efficiency of your carpet cleaner.

1. **Empty After Use:** After each cleaning session, empty any remaining clean water and solution from the tank.
2. **Rinse Thoroughly:** Rinse the inside of the clean tank and its cap with warm water to remove any residue.
3. **Air Dry:** Allow the tank and cap to air dry completely before reassembling or storing to prevent mold or mildew growth.
4. **Inspect for Damage:** Periodically inspect the tank and cap for any cracks, wear, or damage that could lead to leaks. Replace if necessary.

TROUBLESHOOTING

If you encounter issues with your replacement clean tank, consider the following common solutions:

- **Leaking Tank:**
 - Ensure the cap is securely tightened.
 - Verify the tank is properly seated and clicked into place on the machine.
 - Check for any visible cracks or damage on the tank or cap. If damaged, replacement may be necessary.
- **Improper Fit:**
 - Double-check your Bissell carpet cleaner's model number against the compatibility list in this manual.
 - Ensure no debris is obstructing the tank's seating area on the machine.
- **No Solution Dispensing:**
 - Confirm the clean tank is filled with solution.
 - Ensure the tank is correctly installed and sealed.
 - Refer to your carpet cleaner's original manual for troubleshooting steps related to the machine's spray mechanism.

SPECIFICATIONS

Item Weight	13.4 ounces (0.38 Kilograms)
Package Dimensions	11.02 x 6.26 x 5 inches
Item Model Number	85450555031
Color	Transparent

Style	1623828
Number Of Pieces	1
UPC	623456330684

WARRANTY AND SUPPORT

For any questions regarding this replacement part, or for warranty information, please contact the manufacturer, Selgo, directly through their official channels or the retailer from whom the product was purchased. Please retain your proof of purchase for any warranty claims.