

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [MCombo](#) /

> [MCombo Outdoor Storage Shed Model 2 User Manual](#)

## MCombo 2

# MCombo Outdoor Storage Shed Model 2 User Manual

Model: 2 | Brand: MCombo

## 1. IMPORTANT SAFETY INFORMATION

---

**CAUTION:** This product requires assembly. Always follow the assembly instructions carefully. Keep away from open flames and high heat sources when using outdoors. Do not exceed the weight limit of the product.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble on a flat, stable surface.
- Do not overtighten screws to avoid damaging wood.
- Periodically check all fasteners to ensure they remain tight.
- This shed is designed for outdoor storage. Consider treating the wood for enhanced weather resistance, especially in uncovered areas.

## 2. PRODUCT OVERVIEW

---

The MCombo Outdoor Storage Shed Model 2 is a wooden cabinet designed for outdoor storage. It features a natural wood finish and Dutch doors, providing a functional and aesthetic solution for organizing garden tools, pool supplies, or other outdoor items. The shed is constructed primarily from fir wood.



*Figure 1: Front view of the MCombo Outdoor Storage Shed Model 2. This image shows the shed with its Dutch doors closed, highlighting its natural wood finish and compact design.*

### **3. SETUP AND ASSEMBLY**

Assembly is required for this product. Please follow the detailed instructions provided in the separate assembly manual included with your purchase. Ensure you have all necessary tools and components before starting.

#### **3.1. Before You Begin**

- Unpack all components and verify against the parts list.
- Clear a spacious, level area for assembly.
- Gather necessary tools (e.g., screwdriver, hammer).

#### **3.2. General Assembly Steps (Refer to separate manual for specifics)**

1. Assemble the base frame.
2. Attach the side and back panels.
3. Install internal shelves (if applicable).
4. Attach the roof panels.

5. Install the Dutch doors, ensuring proper alignment of hinges and magnetic latches. Adjust as needed.
6. Attach door handles and any optional locking mechanisms.
7. Verify stability and adjust feet if included.

## 4. OPERATING INSTRUCTIONS

---

The MCombo Outdoor Storage Shed is designed for straightforward operation.

### 4.1. Opening and Closing Doors

- To open, gently pull the door handles. The magnetic latches will release.
- To close, push the doors firmly until the magnetic latches engage. Ensure both top and bottom sections of the Dutch doors are securely closed to protect contents from elements.

### 4.2. Storage Capacity

Utilize the internal shelves and open compartments for organized storage. Distribute weight evenly and do not exceed the shed's stated weight capacity to maintain structural integrity.

## 5. MAINTENANCE

---

Regular maintenance will extend the lifespan and appearance of your MCombo Outdoor Storage Shed.

- **Wood Treatment:** The wood is not pre-treated for all weather conditions. It is highly recommended to apply a suitable wood sealant or weather-resistant stain immediately after assembly, especially if the shed will be exposed to direct sun, rain, or high humidity. This will help prevent warping and prolong the wood's life.
- **Cleaning:** Clean the shed periodically with a soft cloth and mild soap solution. Avoid harsh chemicals or abrasive cleaners.
- **Fastener Check:** Annually, inspect all screws and bolts and tighten them as necessary to ensure the shed remains stable and secure.
- **Door Alignment:** If doors become misaligned or difficult to close, check hinges and magnetic latches. Adjust as needed to ensure a proper seal.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Doors are warped or do not close properly.	Exposure to moisture without proper wood treatment; misaligned hinges or magnetic latches.	Apply wood sealant or stain. Adjust hinges. Reposition magnetic latches for better alignment. Consider adding additional latches if warping is severe.
Shed feels unstable or wobbly.	Uneven ground; loose fasteners.	Ensure shed is on a level surface. Adjust adjustable feet if present. Tighten all assembly screws.
Water ingress inside the shed.	Improperly sealed wood; gaps in assembly; doors not fully closed.	Apply wood sealant to all exterior surfaces. Check roof and panel connections for gaps and seal if necessary. Ensure doors are securely closed.

## 7. SPECIFICATIONS

---

**Brand:** MCombo

**Model Number:** 2

**Material:** Wood (Fir Wood for Top Material)

**Color:** Natural

**Product Dimensions:** 1"D x 1"W x 1"H (Note: These dimensions appear to be placeholders and should be verified with actual product measurements.)

**Item Weight:** 56 Pounds

**Door Style:** Dutch Doors

**Water Resistance Level:** Waterproof (Note: This refers to the design, but wood treatment is still recommended for longevity to prevent issues like warping.)

**Assembly Required:** Yes

**ASIN:** B0CHRDL46V

**GTIN:** 08429381060854

## 8. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the documentation included with your purchase or contact MCombo customer service directly. Contact details can typically be found on the manufacturer's website or on your purchase receipt.

**MCombo Customer Service:** Please visit the official MCombo website for the most current contact information.