

Manuals.plus /

› SoBuy /

› SoBuy FSR95-SCH Small Shoe Bench and Narrow Shoe Cabinet Instruction Manual

SoBuy FSR95-SCH

SoBuy Small Shoe Bench and Narrow Shoe Cabinet

Model: FSR95-SCH

Brand: SoBuy

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SoBuy Small Shoe Bench and Narrow Shoe Cabinet (Model FSR95-SCH). Please read all instructions carefully before assembly and use to ensure safe and proper functioning of the product.

SAFETY INFORMATION

- Always assemble the bench according to the provided instructions.
- Do not exceed the maximum load capacity of **120 kilograms (approximately 264 lbs)** for the bench seat.
- Keep the bench indoors to maintain its condition and structural integrity.
- Ensure all screws and fasteners are tightened securely during assembly and periodically check for looseness.
- Keep small parts away from children during assembly to prevent choking hazards.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present. The package includes:

- All necessary furniture panels (Engineered Wood with Melamine Veneer and PVC edge)
- Padded seat cushion
- Mounting Hardware (screws, dowels, hinges, handle, etc.)
- Detailed assembly instructions (separate document)

SETUP AND ASSEMBLY

The SoBuy Small Shoe Bench requires self-assembly. Detailed instructions are supplied with the product. Please follow these instructions carefully, step-by-step, to ensure correct and safe assembly.

General Assembly Tips:

- Clear a spacious area for assembly.
- Use a soft cloth or carpet to protect furniture parts from scratches during assembly.
- Identify all parts and hardware before starting.
- Do not overtighten screws, as this can damage the engineered wood.
- If you encounter any difficulties, refer to the included detailed instructions or contact customer support.



Figure 1: Product Dimensions. The bench measures 60cm (23.62 inches) in width, 30cm (11.81 inches) in depth, and 50cm (19.69 inches) in height. The padded seat is 4cm thick, and the top storage compartment is 9cm deep. The shoe compartment is 35cm high.

OPERATING INSTRUCTIONS

The SoBuy FSR95-SCH shoe bench offers both seating and storage solutions.

Using the Padded Seat

The top of the bench features a comfortable padded seat. It is designed for temporary seating, such as when putting on or taking off shoes. Ensure the bench is placed on a stable, level surface before use. Do not exceed the maximum weight recommendation of 120 kg.



Figure 2: Detail of the comfortable padded seat.

Accessing Top Storage

The padded seat lifts up to reveal a convenient storage compartment underneath. This space is ideal for small items like keys, gloves, shoe care products, or other entryway essentials.



Figure 3: Top storage compartment with the padded seat lifted.

Using the Shoe Storage Drawer

The lower section of the bench features a flip-down drawer designed for shoe storage. Pull the handle to open the drawer. Inside, there is a removable board that allows you to adjust the distance between shelves to accommodate different shoe sizes. This compartment is suitable for organizing multiple pairs of shoes.



Figure 4: Shoe storage drawer in open position.

Product Features in Action

Watch this video to see the SoBuy Narrow Shoe Cabinet Bench in use, demonstrating its storage capabilities and functional design.

Your browser does not support the video tag.

Video 1: Demonstration of the SoBuy Narrow Shoe Cabinet Bench, showcasing the lift-top storage and the flip-down shoe drawer.

MAINTENANCE

To ensure the longevity and appearance of your shoe bench, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry or slightly damp cloth to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if

necessary.

- **Environment:** Keep the bench away from direct sunlight and excessive moisture to prevent warping or discoloration.

TROUBLESHOOTING

If you encounter any issues with your SoBuy shoe bench, consider the following common solutions:

- **Wobbly Bench:** Ensure the bench is on a level surface. Check all assembly screws and tighten any that are loose.
- **Drawer Not Closing Properly:** Verify that no items are obstructing the drawer mechanism. Check if the removable board inside the shoe drawer is correctly positioned.
- **Damaged Parts:** If any part is damaged or missing upon arrival, do not proceed with assembly. Contact SoBuy customer support for assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions (D x W x H)	11.81" x 23.62" x 19.69" (30cm x 60cm x 50cm)
Material	Engineered Wood, Polyvinyl Chloride
Color	Black
Item Weight	13.5 Kilograms (approx. 29.7 lbs)
Maximum Weight Recommendation	120 Kilograms (approx. 264 lbs)
Number of Drawers	1 (flip-down shoe drawer)
Additional Features	Padded Seat, Lift-Up Top Storage
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official SoBuy website. You may also contact the seller directly through the platform where the product was purchased.