

[Manuals.plus](#) /

> [AGARO](#) /

> AGARO Royal Mop & Vacuum Cleaner User Manual

## AGARO Royal

# AGARO Royal Mop & Vacuum Cleaner User Manual

Model: Royal

## INTRODUCTION

The AGARO Royal Mop & Vacuum Cleaner is a versatile cordless appliance designed for efficient wet and dry cleaning of various hard floor types. This device integrates vacuuming, washing, mopping, and drying functions into a single unit, eliminating the need for separate tools. It features a powerful brushless motor, a smart display, and self-propelled movement for ease of use. This manual provides essential information for the safe and effective operation, maintenance, and care of your AGARO Royal Mop & Vacuum Cleaner.



*The AGARO Royal Mop & Vacuum Cleaner, showcasing its cordless design and compatibility with multiple hard floor surfaces.*

## WHAT'S IN THE BOX

Carefully unpack all components and ensure everything listed below is present and in good condition.

- Main Unit (Mop & Vacuum Cleaner)
- Handle
- Charging Dock
- Charging Adapter
- Cleaning Brush
- Cleaning Solution (sample)

*Included accessories: Main Unit, Charging Dock, Cleaning Brush, and Charging Adapter.*

## SETUP

### 1. Assembling the Unit

1. Insert the handle into the top of the main unit until it clicks securely into place.
2. Place the charging dock in a convenient location near a power outlet.
3. Connect the charging adapter to the charging dock and plug it into a power source.

### 2. Filling the Water Tanks

The AGARO Royal Mop & Vacuum Cleaner features a dual-tank system for clean and dirty water, each with a 700ml capacity.

- **Clean Water Tank:** Remove the clean water tank from the main unit. Fill it with clean water, preferably distilled or RO water for optimal performance. A small amount of cleaning solution can be added as per instructions. Reattach the tank securely.
- **Dirty Water Tank:** Ensure the dirty water tank is empty before starting operation. It is designed to collect soiled water and debris.



*The dual 700ml tank system for clean and dirty water. Use distilled or RO water for best results.*

### 1. Charging the Battery

Before first use, fully charge the appliance. Place the main unit onto the charging dock. The LED display will indicate the charging status. A full charge takes approximately 4.5 hours and provides up to 38 minutes of cordless use.



*The charging dock also initiates the self-cleaning function.*

### 2. Powering On and Mode Selection

The handle features control buttons for power, mode change, voice prompts, and self-cleaning. The LED display provides real-time information on battery level, suction power, and selected mode.

- Press the **Power Button** to turn the unit on.
- Press the **Mode Button** to cycle through available cleaning modes:
  - **Auto Mode:** Standard wet and dry cleaning for general messes.
  - **Intelligent Sterilization Mode:** Purifies water to enhance hygiene, suitable for households with children or elderly.
  - **Water Absorption Mode (Suction Mode):** Designed to handle liquid spills and sticky messes by maximizing suction.
- The **Voice Button** activates helpful voice prompts for notifications.

# 4 Operation Modes



Auto Mode



Self Cleaning Mode



Water Sterilization Mode



Suction Mode

AGARO

*Control buttons and available operation modes.*



## 3. Cleaning Floors

Once powered on and a mode is selected, the self-propelled design allows for effortless maneuvering. Guide the cleaner across the floor to vacuum, mop, and dry simultaneously. The powerful 16kPa suction handles both wet and dry debris, including sticky messes.

## 4. Important Usage Notes

- This appliance is designed for use on open surfaces of laminate, hardwood, marble, and tile floors.
- Avoid using the cleaner under low furniture such as sofas, beds, or almirahs, as this may impede proper operation or cause damage.
- The product is not intended for dry vacuuming only. It is a wet and dry cleaner.

# Not To Be Used Under:



Please Use on Open Surfaces of Laminate, Hardwood, Marble and Tile Floors Only.

*Areas to avoid when using the cleaner.*

## 5. Product Demonstration Video

Watch this video for a visual guide on setting up and operating your AGARO Royal Mop & Vacuum Cleaner.

Your browser does not support the video tag.

*Official product demonstration video for the AGARO Royal Mop & Vacuum Cleaner.*

## MAINTENANCE

### 1. Self-Cleaning Function

The AGARO Royal Mop & Vacuum Cleaner features an automatic self-cleaning function for its roller brush. After each use, place the unit back on its charging dock. Press and hold the **Self Cleaning Button** (usually indicated by a water drop icon) for 3 seconds. The unit will automatically flush the tube and clean the brush roller, ensuring it is odor-free and ready for the next use.

### 2. Emptying the Dirty Water Tank

Regularly empty the dirty water tank after each cleaning session to prevent odors and maintain optimal performance. Remove the tank from the main unit, dispose of the collected dirty water and debris, rinse the tank, and reattach it securely.

### 3. HEPA Filter Maintenance

The HEPA filter should be cleaned regularly and replaced periodically to maintain suction efficiency and air quality. Refer to the detailed instructions in the full product manual for specific cleaning and replacement intervals.

## TROUBLESHOOTING

If you encounter any issues with your AGARO Royal Mop & Vacuum Cleaner, please refer to the following general advice. For detailed troubleshooting steps or persistent problems, contact AGARO customer support.

- **No Power:** Ensure the unit is fully charged and correctly seated on the charging dock. Check the power adapter connection.
- **Reduced Suction:** Check if the dirty water tank is full and needs emptying. Inspect the roller brush and filter for blockages or excessive dirt. Clean or replace the HEPA filter as needed.
- **Water Leaks:** Verify that both clean and dirty water tanks are correctly installed and sealed. Ensure the unit is not overfilled.
- **Self-Cleaning Not Activating:** Confirm the unit is properly docked on the charging station before attempting to activate the self-cleaning function.

## SPECIFICATIONS

Feature	Specification
Brand	AGARO
Model Name	Royal
Special Feature	Lightweight
Filter Type	HEPA Filter
Surface Recommendation	Hard floors, Carpets
Power Source	Battery Powered
Voltage	220 Volts
Included Components	Vacuum cleaner
Is It Cordless?	Yes
Item Weight	3800 Grams
Capacity (Water Tanks)	700 Milliliters (each)
Colour	Black & White
Noise Level	80 Decibels
Motor Horsepower	2 Horsepower
Portable	Yes
Indoor Outdoor Usage	Indoor

Wattage	4000 milliamp_hours (Battery)
Item Dimensions L x W x H	27.1L x 26.5W x 109.5H Centimeters
Controller Type	Push Button
Control Method	Touch
Runtime	38 minutes
Battery Charge Time	4.5 Hours
Form Factor	Stick

## WARRANTY & SUPPORT

The AGARO Royal Mop & Vacuum Cleaner comes with a **2-year warranty**. For warranty claims, technical support, or any product-related inquiries, please contact AGARO customer service. Keep your purchase receipt as proof of purchase for warranty validation.