

[Manuals.plus](#) /

> [HP](#) /

> HP E22 G5 22" FHD IPS Monitor User Manual

## HP E22 G5

# HP E22 G5 22" FHD IPS Monitor User Manual

Model: E22 G5

## INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your HP E22 G5 22-inch FHD IPS Monitor. Please read this manual thoroughly before using your monitor to ensure proper functionality and to maximize your viewing experience.

## PRODUCT OVERVIEW

The HP E22 G5 is a 22-inch Full HD (1920x1080) IPS monitor designed for optimal productivity and comfort. It features a 5ms response time, anti-glare screen, flicker-free technology, and VESA mount compatibility. The monitor offers versatile connectivity options including DisplayPort, HDMI, and multiple USB ports.



Figure 1: Front view of the HP E22 G5 Monitor with the included Doczorm USB Port Expander.

## Key Features:

- **Display:** 22-inch FHD (1920x1080) IPS panel
- **Response Time:** 5ms
- **Ergonomics:** -5 to +23 degrees Adjustable Tilt, 4-way adjustability (Height, Tilt, Pivot, Swivel)
- **Eye Comfort:** Anti-Glare, Flicker-Free, HP Eye Ease (always-on low-blue light filter)
- **Connectivity:** 1 x HDMI, 1 x DisplayPort, 4 x USB-A, 1 x USB-B
- **Mounting:** VESA Mount (100mm) compatible
- **Brightness:** 250 nits

## SETUP

### 1. Unpacking the Monitor

Carefully remove all components from the packaging. Ensure the following items are present:

- HP E22 G5 Monitor
- Monitor Stand (Base and Riser)
- Power Cable
- HDMI Cable
- USB-B to USB-A Cable (for USB hub functionality)
- Doczorm USB Port Expander

### 2. Assembling the Stand

1. Attach the riser to the monitor panel. Ensure it clicks securely into place.
2. Connect the base to the riser. Tighten the thumb screw on the underside of the base to secure it.



Figure 2: Side view of the assembled HP E22 G5 Monitor.

### 3. Connecting the Monitor

Connect the monitor to your computer using one of the available video input ports.

- **HDMI Connection:** Connect one end of the HDMI cable to the HDMI port on your computer and the other end to the HDMI port on the monitor.
- **DisplayPort Connection:** Connect one end of the DisplayPort cable to the DisplayPort on your computer and the other end to the DisplayPort on the monitor.

For USB hub functionality, connect the USB-B port on the monitor to a USB-A port on your computer using the provided USB-B to USB-A cable. This enables the monitor's USB-A ports.

# Ports




Figure 3: Rear view of the HP E22 G5 Monitor detailing available ports: Security Lock, AC Power, 2x USB 3.2, 2x USB 3.2, 1x USB-B, 1x HDMI 1.4, 1x DisplayPort 1.2.

## 4. Powering On

Connect the power cable to the monitor's AC power input and then to a wall outlet. Press the power button on the monitor to turn it on.

## OPERATING THE MONITOR

### On-Screen Display (OSD) Menu

The monitor features an intuitive joypad OSD button for navigating the on-screen display menu. This menu allows you to adjust various settings such as brightness, contrast, color, input source, and more.



Figure 4: Location of the Joypad OSD Button and accessible ports on the HP E22 G5 Monitor.

## Ergonomic Adjustments

The HP E22 G5 monitor offers 4-way adjustability to enhance user comfort and productivity. Utilize the following adjustments:

- **Height Adjustment:** Adjust the monitor's height up to 150mm for optimal eye level.
- **Tilt Adjustment:** Tilt the screen from -5 degrees to +23 degrees to reduce glare and improve viewing angle.
- **Swivel Adjustment:** Swivel the monitor from -45 degrees to +45 degrees horizontally.
- **Pivot Adjustment:** Rotate the monitor 90 degrees for portrait mode viewing.

# Bring comfort to work

Do and feel your best with 4-way adjustability optimized by Ergonomic Setup Guide<sup>1</sup> and enhanced HP Eye Ease.




Figure 5: Illustrations of the HP E22 G5 Monitor's ergonomic adjustments: Height, Tilt (-5° to +23°), Pivot (90°), and Swivel (-45° to +45°).

## HP Eye Ease and Flicker-Free Technology

The monitor incorporates HP Eye Ease, an always-on, built-in low-blue light filter, and flicker-free technology to help reduce eye strain during extended use. These features are designed to maintain color accuracy while minimizing harmful blue light emissions.

## MAINTENANCE

### Cleaning the Monitor

- Always power off the monitor and unplug it from the power outlet before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner.
- Do not spray cleaner directly onto the screen.
- Avoid using harsh chemicals, solvents, or abrasive materials.

### General Care

- Keep the monitor away from direct sunlight, heat sources, and excessive moisture.

- Ensure proper ventilation around the monitor.
- Avoid placing heavy objects on the monitor or its cables.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No image on screen	Monitor not powered on; Incorrect input source; Loose video cable.	Ensure power cable is connected and monitor is on. Press OSD button to select correct input (HDMI/DisplayPort). Check video cable connections.
Image is blurry or distorted	Incorrect resolution; Graphics driver issue.	Set display resolution to 1920x1080. Update graphics drivers on your computer.
USB ports not working	USB upstream cable not connected.	Ensure the USB-B to USB-A cable is connected from the monitor to your computer.
Monitor flickering	Video cable issue; Graphics card issue.	Try a different video cable. Update graphics drivers. Test with another computer if possible.

## SPECIFICATIONS

Feature	Detail
Model	HP E22 G5
Screen Size	22 Inches
Panel Type	IPS
Resolution	1920 x 1080 (FHD)
Aspect Ratio	16:9
Response Time	5ms
Brightness	250 nits
Connectivity	1x HDMI 1.4, 1x DisplayPort 1.2, 1x USB-B (upstream), 4x USB-A (downstream)
Ergonomics	Height, Tilt (-5° to +23°), Swivel (-45° to +45°), Pivot (90°)
VESA Mount	100mm x 100mm
Dimensions (with stand)	8.31 x 19.24 x 19.41 inches
Weight (with stand)	9.12 pounds

# See it all, do it all

When the difference is in the details, this 21.5-inch diagonal FHD monitor displays the clarity you need to stay focused on the task at hand with 99% sRGB color depth and IPS technology.<sup>1</sup>




Figure 6: Diagram illustrating the dimensions of the HP E22 G5 Monitor.

## WARRANTY AND SUPPORT

### Warranty Information

Your HP E22 G5 monitor is covered by a standard manufacturer's warranty. Please refer to the warranty card included with your product or visit the official HP support website for detailed warranty terms and conditions specific to your region.

### Customer Support

For technical assistance, product inquiries, or service requests, please contact HP Customer Support. You can find contact information and additional resources on the official HP support website:

[www.hp.com/support](http://www.hp.com/support)

When contacting support, please have your monitor's model number (E22 G5) and serial number ready. The serial number is typically located on a label on the back of the monitor.



