

[Manuals.plus](#) /

› [Skullcandy](#) /

› Skullcandy Sesh Evo True Wireless Earbuds User Manual

Skullcandy SKEV0-SHCCI

Skullcandy Sesh Evo True Wireless Earbuds User Manual

Comprehensive guide for your Skullcandy Sesh Evo True Wireless Earbuds, model SKEV0-SHCCI.

INTRODUCTION

Welcome to the user manual for your Skullcandy Sesh Evo True Wireless Earbuds. These earbuds are designed to provide a seamless audio experience with advanced features like Tile tracking, multiple EQ modes, and robust water and dust resistance. This manual will guide you through setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device.

WHAT'S INCLUDED

Your Skullcandy Sesh Evo package includes the following items:

- Skullcandy Sesh Evo True Wireless Earbuds (Pure Mint)
- Charging Case
- CCI Deluxe USB Charging Plug
- Multiple sizes of ear gels for a comfortable fit



Image: The Skullcandy Sesh Evo True Wireless Earbuds in Pure Mint, shown with their matching charging case.

FEATURES

The Skullcandy Sesh Evo earbuds offer a range of features designed for convenience and high-quality audio:

- **True Wireless Freedom:** Enjoy audio without the hassle of wires.
- **Built-in Tile Technology:** Easily track down misplaced earbuds using the Tile app.
- **24 Hours Total Battery Life:** Extended listening time with the charging case.
- **Rapid Charge Capability:** Quick charging for minimal downtime.
- **IP55 Sweat, Water, and Dust Resistant:** Durable design for active lifestyles.
- **Built-in Microphone:** For hands-free calls and voice assistant interaction.
- **3 EQ Modes:** Optimize sound for music, movies, or podcasts.
- **Single-Button Controls:** Intuitive control over calls, tracks, and volume.
- **Bluetooth 5.0:** Stable and efficient wireless connection.

SETUP

Charging Your Earbuds

Before first use, ensure your earbuds and charging case are fully charged.

1. Place both earbuds into the charging case. Ensure they are properly seated; the indicator lights on the earbuds should illuminate.
2. Connect the provided CCI Deluxe USB Charging Plug to the charging case and a power source.
3. The LED indicators on the case will show charging progress. All four LEDs will illuminate solid white when fully charged.



Image: The Skullcandy Sesh Evo earbuds placed inside their open charging case, ready for charging.

Pairing with a Device

Follow these steps to pair your Sesh Evo earbuds with your Bluetooth-enabled device:

1. Remove both earbuds from the charging case. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Select "Sesh Evo" from the list of available devices.
4. Once connected, you will hear an audible confirmation, and the LED on the earbuds will stop flashing.

Note: If you have previously paired the earbuds, they will automatically connect to the last paired device when removed from the case.

OPERATING INSTRUCTIONS

Basic Controls

The Sesh Evo earbuds feature intuitive single-button controls on each earbud:

- **Play/Pause:** Press either earbud once.
- **Next Track:** Press the Right earbud twice.
- **Previous Track:** Press the Left earbud twice.
- **Volume Up:** Press the Right earbud and hold.
- **Volume Down:** Press the Left earbud and hold.
- **Answer/End Call:** Press either earbud once.
- **Activate Voice Assistant:** Press either earbud three times.

EQ Modes

Switch between three distinct EQ modes to enhance your listening experience:

1. While playing audio, press either earbud four times.
2. You will hear an audible prompt indicating the current mode: "Music Mode," "Movie Mode," or "Podcast Mode."
3. Repeat the action to cycle through the modes until you find your preferred setting.

Your browser does not support the video tag.

Video: An official product video demonstrating the features and operation of the Skullcandy Sesh Evo True Wireless Earbuds.

MAINTENANCE

To ensure the longevity and optimal performance of your Skullcandy Sesh Evo earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. For ear gels, remove them and clean with mild soap and water, then dry thoroughly before reattaching.
- **Charging Contacts:** Periodically inspect and gently clean the charging contacts on both the earbuds and inside the case to ensure proper connection.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water and Dust Resistance (IP55):** The Sesh Evo earbuds are rated IP55, meaning they are resistant to sweat, light splashes of water, and dust. They are not designed for submersion in water. Avoid exposing them to excessive moisture or harsh chemicals.



Image: A close-up view of a single Skullcandy Sesh Evo earbud, highlighting its design and ear tip.

TROUBLESHOOTING

If you encounter any issues with your Sesh Evo earbuds, try the following solutions:

- **Earbuds Not Charging:**

- Ensure the charging contacts on both earbuds and case are clean and free of debris.
- Verify the charging cable and power source are working correctly.
- Make sure the earbuds are properly seated in the case.

- **Earbuds Not Pairing/Connecting:**

- Ensure Bluetooth is enabled on your device.
- Turn off Bluetooth on other nearby devices that might be trying to connect.
- Forget "Sesh Evo" from your device's Bluetooth list and attempt to re-pair.
- Place earbuds back in the case, close the lid, wait a few seconds, then remove them to re-initiate pairing mode.

- **Sound Issues (No Sound, Low Volume, etc.):**

- Check the volume levels on both your earbuds and your connected device.

- Ensure the earbuds are properly seated in your ears.
- Try cleaning the ear tips and speaker mesh.

- **Misplaced Earbuds (Tile Tracking):**

- Download and open the Tile app on your smartphone.
- Follow the in-app instructions to activate and locate your Sesh Evo earbuds. The app can ring your earbuds if they are within Bluetooth range.

SPECIFICATIONS

Feature	Detail
Model Name	CCI01-SKBN
Item Model Number	SKEV0-SHCCI
Connectivity Technology	Bluetooth 5.0
Battery Life	Up to 24 hours total (with charging case)
Water Resistance	IP55 (Sweat, Water, and Dust Resistant)
Frequency Range	20 Hz - 20,000 Hz
Control Type	Volume Control, Call, Track, EQ Modes
Color	Pure Mint
Item Weight	4.6 ounces
Dimensions	7.24 x 4.25 x 1.65 inches (Package)

WARRANTY AND SUPPORT

Skullcandy products are built with quality and durability in mind. For information regarding your product's warranty, please refer to the warranty card included in your original packaging or visit the official Skullcandy support website. For further assistance, technical support, or to register your product, please visit [Skullcandy Support](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question