

MEMBER'S MARK Hard Arm Chair

Member's Mark Adult Hard Arm Chair Instruction Manual

MODEL: HARD ARM CHAIR

Introduction

This manual provides instructions for the proper setup, operation, maintenance, and troubleshooting of your Member's Mark Adult Hard Arm Chair. Designed for comfort and portability, this chair features a durable steel frame, breathable moisture-wicking fabric, padded arms, and a headrest. It is suitable for various outdoor activities.

Key Features:

- Steel frame construction
- Breathable, moisture-wicking fabric
- Padded arms and headrest
- Integrated cup holder
- Includes carry bag for storage and transport

Safety Information

Please read and understand all safety information before using the chair.

- **Maximum Weight Capacity:** Do not exceed 325 lbs (147 kg). Exceeding this limit may result in injury or damage to the chair.
- **Surface Use:** Always use the chair on stable, flat, and level surfaces to prevent tipping.
- **Temperature Warning:** The alloy steel frame can become hot in direct sunlight or cold in low temperatures. Exercise caution when handling the frame in extreme conditions.
- **Pinch Points:** Be aware of pinch points when unfolding or folding the chair. Keep fingers and other body parts clear of moving parts.
- **Children:** Keep children away from the chair during setup and folding. Adult supervision is recommended when children are near the chair.

Setup Instructions

1. Remove the chair from its carry bag.
2. Place the chair on a flat, stable surface with the legs pointing downwards.

3. Grasp the top of the chair frame and gently pull the arms outwards until the chair fully extends and locks into its open position. Ensure all four legs are firmly on the ground.
4. Verify that the chair is stable before use.



Figure 1: The Member's Mark Adult Hard Arm Chair fully unfolded and ready for use in an outdoor environment.

Operating Instructions

The chair is designed for straightforward use. Once unfolded, it provides a comfortable seating solution.

- **Seating:** Sit gently into the chair, ensuring your weight is evenly distributed.
- **Cup Holder:** The integrated cup holder is located on the side arm. Place beverages securely in the holder.



Figure 2: Detail of the integrated cup holder, designed to securely hold beverages.

Folding for Storage

1. Ensure no one is sitting in the chair and remove any items from the cup holder.
2. Grasp the chair frame and push the arms inwards, allowing the chair to collapse.
3. Gather the folded chair and place it into the provided carry bag for convenient transport and storage.



Figure 3: The chair folded and placed next to its carry bag, illustrating its compact storage.

Maintenance

Regular maintenance will extend the life of your chair.

- **Cleaning Fabric:** Spot clean the fabric with a mild soap and water solution. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before folding and storing.
- **Cleaning Frame:** Wipe the steel frame with a damp cloth to remove dirt and debris. Dry thoroughly to prevent rust.
- **Storage:** Store the chair in its carry bag in a cool, dry place when not in use. Avoid prolonged exposure to direct sunlight or extreme weather conditions to prevent material degradation.
- **Inspection:** Periodically inspect the chair for any signs of wear, damage, or loose components. Do not use if damaged.

Troubleshooting

If you encounter issues with your chair, refer to the following common solutions:

- **Chair does not fully unfold:** Ensure there are no obstructions in the folding mechanism. Apply

gentle, even pressure to pull the arms outwards until the frame locks into place.

- **Chair feels unstable:** Verify that all four legs are on a flat, level surface. Check that the frame is fully extended and locked. Avoid placing the chair on uneven terrain.
- **Difficulty folding:** Ensure no fabric is caught in the frame. Apply gentle inward pressure to the arms to initiate the folding action.

Specifications

Feature	Detail
Brand	MEMBER'S MARK
Model Name	Hard Arm Chair
Product Dimensions (Open)	24.5" W x 25.5" D x 39" H (62.2 cm W x 64.8 cm D x 99.1 cm H)
Chair Weight	10.8 lbs (4.9 kg)
Weight Capacity	325 lbs (147 kg)
Frame Material	Alloy Steel
Fabric Material	Breathable, moisture-wicking fabric
Special Feature	Portable, Padded Arms, Headrest, Cup Holder
Recommended Use	Camping, Outdoor Recreation
Included Components	Arm chair, Carry bag



Figure 4: Visual representation of the chair's dimensions: 39" H x 25.5" D x 24.5" W.






Warranty Information


Specific warranty details for the Member's Mark Adult Hard Arm Chair are not provided in this manual. Please refer to the product packaging or contact the retailer or manufacturer directly for information regarding warranty coverage.

Support

For further assistance, questions, or to report issues not covered in this manual, please contact the retailer where the product was purchased or the Member's Mark customer service department. Contact information can typically be found on the product packaging or the official Member's Mark website.

Related Documents - Hard Arm Chair

 <p>Member's Mark Assembly Instructions & User's Manual Member's Mark 6 Pack Multipurpose Disc Light Model: FRM10388LSSG Includes: 6 Pack Multipurpose Disc Light Customer Support: 1-800-888-8888 © 2017 Member's Mark</p>	<p>Member's Mark 6 Pack Multipurpose Disc Light Assembly and User Manual</p> <p>Assembly instructions and user manual for the Member's Mark 6 Pack Multipurpose Disc Light. Includes product information, components, hardware, tools needed, assembly steps for soil, concrete, and wall mounting, and battery precautions.</p>
 <p>Sam's.com (1710) Item: 10488LSSG Desc: 84-Inch Animated Skeleton Pirate Size: 84 x 21 x 120 120g</p> <p>*This page is not printed.</p>	<p>84-Inch Animated Skeleton Pirate Assembly Instructions and User Manual Member's Mark</p> <p>Detailed assembly instructions, user manual, safety guidelines, and troubleshooting for the Member's Mark 84-Inch Animated Skeleton Pirate decoration. Learn how to set up and operate your animated pirate.</p>
 <p>Member's Mark Assembly Instructions & User's Manual Member's Mark 12 FT Hanging Reaper Model: FRM10388LSSG Includes: 12 FT Hanging Reaper Customer Support: 1-800-888-8888 © 2017 Member's Mark</p>	<p>Member's Mark 12 FT Hanging Reaper Assembly Instructions and User Manual</p> <p>Assembly instructions and user manual for the Member's Mark 12 FT Hanging Reaper, including battery replacement, setup, and troubleshooting.</p>
 <p>Member's Mark Assembly Instructions & User's Manual Member's Mark Harper 4pc Deep Seating Set Model: FRM10388SST Includes: 4pc Deep Seating Set Customer Support: 1-800-888-8888 © 2017 Member's Mark</p>	<p>Member's Mark Harper 4pc Deep Seating Set Assembly Instructions & User's Manual</p> <p>Comprehensive assembly instructions and user manual for the Member's Mark Harper 4pc Deep Seating Set (Model: FRM10388SST), including safety information, care instructions, troubleshooting, and warranty details.</p>
 <p>Member's Mark PRO SERIES 5-BURNER GAS GRILL Assembly Instructions & User Manual Model: G62304 Includes: 5-Burner Gas Grill Customer Support: 1-800-888-8888 © 2017 Member's Mark</p>	<p>Member's Mark PRO SERIES 5-BURNER GAS GRILL: Assembly & User Manual (Model G62304)</p> <p>Comprehensive assembly instructions and user manual for the Member's Mark PRO SERIES 5-Burner Gas Grill (Model G62304). Includes safety guidelines, operation, maintenance, and troubleshooting for outdoor cooking.</p>



[Member's Mark Asher 70 In. Console Assembly Instructions & User Manual](#)

Detailed assembly instructions and user manual for the Member's Mark Asher 70 In. Console. Includes safety warnings, parts list, step-by-step assembly guide, care and use instructions, troubleshooting, and warranty information.