

CRAFTSMAN 31AM6C2FB93

CRAFTSMAN Select 26-Inch Gas Powered Two-Stage Snow Blower Instruction Manual

Model: 31AM6C2FB93

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for the safe and efficient operation, maintenance, and setup of your new CRAFTSMAN Select 26-inch Gas Powered Two-Stage Snow Blower. Please read it thoroughly before using the equipment.

The CRAFTSMAN Select 26-inch snow blower is designed for effective snow removal, featuring a powerful 243cc 4-cycle OHV engine and a 26-inch clearing width with a 20-inch intake height. It includes a push-button electric start for convenience and a self-propelled drive system with 6 forward and 2 reverse speeds for versatile maneuverability. Dual LED headlights enhance visibility in low-light conditions.



Figure 1: The CRAFTSMAN Select 26-inch Gas Powered Snow Blower, showcasing its robust design and red finish.

2. SAFETY INFORMATION

WARNING: Risk of carbon monoxide poisoning from engine exhaust. Always operate in a well-ventilated area. Wear protective equipment such as gloves and eye protection. Keep hands and clothing away from rotating parts.

Always ensure the area is clear of people, especially small children and pets, before and during operation. Never direct the discharge chute towards people or property. Familiarize yourself with all controls and their proper operation before starting the engine. Always turn off the engine and remove the key before performing any maintenance or clearing clogs.

3. SETUP

Your snow blower may require some assembly upon delivery. Refer to the detailed assembly instructions provided in the manufacturer's manual for specific steps. Key assembly points typically include attaching the handle, chute, and control rods.

3.1 Initial Checks

- **Engine Oil:** Ensure the engine oil level is correct before starting. Refer to the engine manual for oil type and capacity.
- **Fuel:** Fill the fuel tank with fresh, unleaded gasoline. Do not mix oil with gasoline.
- **Tire Pressure:** Check and maintain recommended tire pressure for optimal traction.
- **Skid Shoes:** Adjust the poly skid shoes to the appropriate height for your surface to prevent damage and rust stains.

Video 1: CRAFTSMAN Select Series Snow Blower. This video provides an overview of the Craftsman Select Series snow blower, highlighting its features and operation.

4. OPERATING INSTRUCTIONS

4.1 Starting the Engine

The snow blower features a convenient push-button electric start. Connect an extension cord to the electric start port, then press the button to ignite the engine. Alternatively, use the recoil starter by pulling the cord firmly.



Figure 2: A detailed view of the electric push-button start mechanism, ensuring easy ignition in cold weather.

4.2 Clearing Snow

- **Self-Propelled Drive:** Engage the drive control lever to move the snow blower forward or backward. Select from 6 forward and 2 reverse speeds to match snow conditions and your pace.
- **Chute Control:** Use the remote pitch lever to easily adjust the snow chute's direction up to 200 degrees and its pitch, allowing you to throw snow up to 40 feet away.
- **Auger Engagement:** Engage the auger control lever to activate the sawtooth steel augers, which are designed to cut through snow and ice efficiently.
- **Visibility:** Activate the dual LED headlights for improved visibility when operating in low-light conditions.



Figure 3: A user clearing snow with the CRAFTSMAN Select 26-inch Snow Blower, demonstrating its operational capability.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your snow blower.

- **Engine:** Follow the engine manufacturer's recommendations for oil changes, spark plug replacement, and air filter cleaning.
- **Augers and Impeller:** Periodically inspect the sawtooth augers and impeller for wear or damage. Replace worn parts as needed.
- **Skid Shoes:** Check the adjustable poly skid shoes for wear and adjust or replace them to protect surfaces and maintain proper clearing height.
- **Storage:** Before long-term storage, stabilize the fuel, clean the unit thoroughly, and store it in a dry, protected area.

6. TROUBLESHOOTING

This section covers common issues you might encounter. For detailed troubleshooting, refer to the complete owner's manual.

- **Engine Fails to Start:** Check fuel level, spark plug, and ensure the choke is set correctly. Verify the electric start is properly connected or use the recoil starter.
- **Poor Snow Clearing:** Inspect augers for obstructions or damage. Ensure skid shoes are set to the correct height.
- **Loss of Drive:** Check drive belt tension and condition.

7. SPECIFICATIONS

Feature	Specification
Brand	CRAFTSMAN
Model Number	31AM6C2FB93
Power Source	Gas Powered
Engine Type	4-Cycle OHV Engine
Engine Displacement	243 Cubic Centimeters
Clearing Width	26 Inches
Ideal Snow Depth	20 Inches (50.8 Centimeters)
Number of Speeds	8 (6 Forward, 2 Reverse)
Wheel Size	15 Inches
Product Dimensions (D x W x H)	48.63" x 28.75" x 32.38"
Item Weight	209 Pounds
Chute Rotation	200 Degrees
Throwing Distance	Up to 40 ft.
Special Features	Push-Button Electric Start, Dual LED Headlights, Adjustable Poly Skid Shoes








Figure 4: Diagram illustrating the product dimensions: 48.63 inches deep, 28.75 inches wide, and 32.38 inches high.

8. WARRANTY AND SUPPORT

Your CRAFTSMAN Select 26-inch Gas Powered Two-Stage Snow Blower comes with a three-year limited warranty, providing peace of mind against manufacturing defects and issues under normal use. For warranty claims, technical support, or to order replacement parts, please contact CRAFTSMAN customer service through their official website or the contact information provided in your full owner's manual.

© 2023 CRAFTSMAN. All rights reserved.

Related Documents - 31AM6C2FB93

 <p>CRAFTSMAN Operator's Manual Snow Thrower 4 Horsepower 4-Cycle Engine 21-inch Single Stage Auger Propelled Model 536.881400</p> <p>CAUTION: Before using this product, read the manual and follow all of the Safety Rules and Operating Instructions.</p> <p>Manual del usuario Quilates de 21 pulgadas 4 caballos de fuerza (hp) Remolcado Propulsado por ballesta Modelo 536.881400</p> <p>PRECAUCIÓN: Antes de usar este producto, lea este manual y siga todas las reglas de seguridad y las instrucciones de operación.</p> <p>Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A. © 2009</p>	<p>CRAFTSMAN 536.881400 Snow Thrower Operator's Manual Safety, Operation, Maintenance</p> <p>Download the official CRAFTSMAN 536.881400 Snow Thrower operator's manual. Find detailed instructions on safe operation, assembly, maintenance, and troubleshooting for your 4 HP, 21-inch single-stage snow thrower.</p>
 <p>CRAFTSMAN Operator's Manual Snow Thrower 3.8 Horsepower 4-Cycle Engine 21-inch Single Stage Auger Propelled Model 536.885202</p> <p>CAUTION: Before using this product, read the manual and follow all of the Safety Rules and Operating Instructions.</p> <p>Manual del usuario Quilates de 21 pulgadas 3.8 caballos de fuerza (hp) Remolcado Propulsado por ballesta Modelo 536.885202</p> <p>PRECAUCIÓN: Antes de usar este producto, lea este manual y siga todas las reglas de seguridad y las instrucciones de operación.</p> <p>Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A. © 2009</p>	<p>Craftsman 536.885202 Snow Thrower Operator's Manual</p> <p>This manual provides operating, safety, maintenance, and parts information for the Craftsman 3.8 Horsepower 4-Cycle 21-inch Single Stage Auger Propelled Snow Thrower, Model 536.885202.</p>
 <p>CRAFTSMAN Operator's Manual Snow Thrower 3.8 Horsepower 4-Cycle Engine 21-inch Single Stage Auger Propelled Model 536.885203</p> <p>CAUTION: Before using this product, read the manual and follow all of the Safety Rules and Operating Instructions.</p> <p>Manual del usuario Quilates de 21 pulgadas 3.8 caballos de fuerza (hp) Remolcado Propulsado por ballesta Modelo 536.885203</p> <p>PRECAUCIÓN: Antes de usar este producto, lea este manual y siga todas las reglas de seguridad y las instrucciones de operación.</p> <p>Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A. © 2009</p>	<p>Craftsman 536.885203 Snow Thrower Operator's Manual Safety, Operation, and Maintenance Guide</p> <p>Official operator's manual for the Craftsman 536.885203 snow thrower. Learn about safety precautions, how to operate, maintain, and troubleshoot your 3.8 HP, 21-inch single-stage, auger-propelled snow thrower.</p>
 <p>CRAFTSMAN Operator's Manual Snow Thrower 4 Horsepower 4-Cycle Engine 21-inch Single Stage Auger Propelled Model 536.881400</p> <p>CAUTION: Before using this product, read the manual and follow all of the Safety Rules and Operating Instructions.</p> <p>Manual del usuario Quilates de 21 pulgadas 4 caballos de fuerza (hp) Remolcado Propulsado por ballesta Modelo 536.881400</p> <p>PRECAUCIÓN: Antes de usar este producto, lea este manual y siga todas las reglas de seguridad y las instrucciones de operación.</p> <p>Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A. © 2009</p>	<p>Craftsman 536.881400 Snow Thrower Operator's Manual</p> <p>Comprehensive operator's manual for the Craftsman 536.881400 Snow Thrower, covering operation, safety, maintenance, and troubleshooting. Learn how to use and care for your 4 HP, 21-inch single-stage snow thrower.</p>
 <p>SEARS owner's manual CRAFTSMAN DUAL STAGE SNOW BLOWER Model C950-52930-0 70-HP, 21 inch</p> <p>CAUTION: Before using this product, read the manual and follow all of the Safety Rules and Operating Instructions.</p> <p>NEED PARTS? VISIT US AT www.sears.com OR www.sears.com/craftsman</p>	<p>Craftsman C950-52930-0 Dual Stage Snow Blower Owner's Manual</p> <p>This owner's manual provides essential safety instructions, operation guidelines, maintenance procedures, and troubleshooting tips for the Craftsman C950-52930-0 Dual Stage Snow Blower. Learn how to safely assemble, operate, and maintain your snow blower for optimal performance.</p>

CRAFTSMAN®

536.886140
22-Inch Dual Stage
120V Electric Start
SNOW THROWER



Caution:
Read and follow all Safety
Rules and Operating
Instructions before use
of this product.
Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.
©2005 Sears

[Craftsman 5 HP 22-Inch Dual Stage Electric Start Snow Thrower 536.886140 Owner's Manual](#)

Comprehensive owner's manual for the Craftsman 5 HP 22-Inch Dual Stage Electric Start Snow Thrower, Model 536.886140. Covers safety instructions, assembly, operation, maintenance, storage, troubleshooting, product specifications, and contact information for Sears Repair Services.