



[Manuals.plus](#) /

› [GOPLUS](#) /

› GOPLUS Portable Large Baby Playpen Instruction Manual

GOPLUS Portable Large Playpen

GOPLUS Portable Large Baby Playpen Instruction Manual

Model: Portable Large Playpen

1. INTRODUCTION

Thank you for choosing the GOPLUS Portable Large Baby Playpen. This playpen is designed to provide a safe, spacious, and engaging environment for your child to play and explore. It includes various accessories to enhance playtime and support your child's development. Please read this manual carefully before assembly and use to ensure proper setup and safe operation.



Image 1.1: The GOPLUS Portable Large Baby Playpen in a home setting, showing its spacious design and included play mat.

2. SAFETY INFORMATION

- **Adult Supervision Required:** Never leave your child unattended in the playpen. Constant adult supervision is essential.
- **Proper Assembly:** Ensure all parts are correctly assembled and securely locked before placing your child inside. Refer to the assembly instructions carefully.
- **Check for Damage:** Regularly inspect the playpen for any signs of wear, tear, or damage. Discontinue use if any part is broken or missing.
- **Hazard-Free Zone:** Keep the playpen away from open flames, heaters, electrical outlets, windows, and cords.
- **Weight and Age Limits:** This playpen is suitable for children aged 0-3 years. Do not exceed the maximum recommended weight of 100 kg.
- **Secure Doors:** Always ensure the zipper doors are fully closed and secured from the outside when your child is inside.
- **Stable Surface:** Place the playpen on a flat, stable, and level surface to prevent tipping. The non-slip suction cups on the base enhance stability.



Image 2.1: Demonstrating the reasonable height of the playpen walls and the transparent mesh for easy visibility, ensuring child safety.

3. PACKAGE CONTENTS

Before assembly, please verify that all components listed below are present in your package:

- 1 x Playpen Frame (metal pipes and connectors)
- 1 x Oxford Fabric Cover with Mesh Walls and Zipper Doors
- 1 x Double-Sided Play Mat (XPE material)
- 1 x Basketball Hoop
- 2 x Soccer Goals
- 50 x Ocean Balls
- 4 x Pull Rings
- 1 x Carry Bag
- 1 x Instruction Manual



Image 3.1: All included components and their respective quantities.

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your GOPLUS Playpen:

- 1. Unpack Components:** Lay out all metal pipes, connectors, and the fabric cover on a clean, flat surface.
- 2. Assemble Base Frame:** Connect the longest metal pipes to form the rectangular base using the appropriate corner connectors. Ensure they click securely into place.
- 3. Install Side Pipes:** Attach the vertical metal pipes to the base frame connectors.
- 4. Attach Top Frame:** Connect the remaining horizontal metal pipes to the top of the vertical pipes using the upper corner connectors, forming the top rectangular frame.
- 5. Drape Fabric Cover:** Carefully slide the Oxford fabric cover over the assembled metal frame. Ensure the mesh walls are facing outwards and the zipper doors are positioned correctly.
- 6. Secure Fabric:** Fasten the fabric cover to the frame using any integrated straps or Velcro closures. Ensure a snug fit.

7. **Attach Accessories:** Install the basketball hoop and soccer goals onto the designated areas of the playpen frame.
8. **Place Play Mat:** Unfold the double-sided play mat and place it inside the playpen, ensuring it covers the entire floor area.
9. **Add Pull Rings:** Attach the four pull rings to the top rail of the playpen for your child to use for standing assistance.
10. **Final Check:** Before use, double-check all connections for security and stability. Ensure there are no sharp edges or exposed parts.



Image 4.1: Key assembly details including secure connections and safety features.

5. OPERATING INSTRUCTIONS

Once assembled, the GOPLUS Playpen offers various features for your child's enjoyment:

- **Zipper Doors:** The playpen features external zipper doors. To allow your child to enter or exit, an adult must open the zippers from the outside. Always ensure the doors are closed and secured when the child is inside.
- **Play Mat:** The comfortable, double-sided XPE play mat provides a soft and safe surface for crawling, sitting, and playing. Its waterproof and non-slip properties ensure hygiene and safety.

- **Basketball Hoop:** Encourage active play by letting your child practice throwing the ocean balls into the integrated basketball hoop.
- **Soccer Goals:** The two soccer goals allow for fun ball games, promoting motor skills and coordination.
- **Ocean Balls:** The 50 colorful ocean balls provide endless fun and sensory stimulation.
- **Pull Rings:** The four pull rings are designed to help your child learn to stand and develop their balance and strength.

Plaisir sans Fin pour les Enfants !



Anneaux de Traction pour les Exercices en Position Debout



Filets de Football pour le Jeu de Football



Panier de Basket-ball pour le Tir au Basket-ball



50 Boules Océaniques Colorées pour Jouer

Image 5.1: Children engaging with the playpen's various features, including pull rings, basketball hoop, and soccer goals.

Tapis de Jeu Pliable



Image 5.2: Details of the comfortable and safe XPE play mat.

6. CARE AND MAINTENANCE

- **Cleaning the Fabric:** The Oxford fabric cover can be spot cleaned with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely.
- **Cleaning the Play Mat:** The XPE play mat is waterproof and can be easily wiped clean with a damp cloth. For deeper cleaning, use mild soap and water, then rinse and air dry.
- **Frame Cleaning:** Wipe the metal frame with a damp cloth as needed. Ensure all parts are dry to prevent rust.
- **Ball Cleaning:** The ocean balls can be washed with mild soap and water, then air dried.
- **Regular Inspection:** Periodically check all connections, zippers, and fabric for any signs of wear, damage, or loose parts. Tighten any loose connections.

7. TROUBLESHOOTING

If you encounter any issues with your playpen, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Playpen is unstable or wobbly.	Loose connections; uneven surface.	Ensure all metal pipes are fully inserted into connectors. Place on a flat, level surface. Check suction cups.
Zipper doors are difficult to open/close.	Fabric caught in zipper; zipper track dirty.	Ensure fabric is clear of the zipper path. Clean zipper teeth if necessary.
Play mat does not lie flat.	Improper placement; new mat needs to flatten.	Adjust the mat's position. Allow some time for the mat to naturally flatten after unpacking.
Missing parts.	Packaging error.	Refer to the 'Package Contents' section. Contact customer support if parts are missing.

8. SPECIFICATIONS

- **Brand:** GOPLUS
- **Color:** Dark Grey
- **Materials:** Metal (frame), Oxford Fabric (cover), XPE (play mat), Polypropylene (accessories)
- **Overall Dimensions (L x W x H):** 207 cm x 145 cm x 68 cm (81.5 in x 57.1 in x 26.8 in)
- **Soccer Goal Dimensions (L x W x H):** 44 cm x 44 cm x 34 cm (17.3 in x 17.3 in x 13.4 in)
- **Height with Basketball Hoop:** 100 cm (39.4 in)
- **Play Mat Dimensions (L x W):** 196 cm x 139 cm (77.2 in x 54.7 in)
- **Net Weight:** 7.4 kg (16.3 lbs)
- **Recommended Age:** 0-3 years
- **Maximum Weight Recommendation:** 100 kg (220 lbs)

9. STORAGE AND PORTABILITY

The GOPLUS Playpen is designed for easy disassembly and portability:

1. **Disassembly:** Reverse the assembly steps. Carefully detach the fabric cover, then disconnect the metal pipes from the connectors.
2. **Folding Mat:** Fold the XPE play mat according to its creases for compact storage.
3. **Packing:** Place all disassembled components, including the play mat, ocean balls, and accessories, into the provided carry bag.
4. **Storage:** Store the packed playpen in a cool, dry place away from direct sunlight and extreme temperatures.

10. WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact GOPLUS customer support. Please retain your purchase receipt for warranty purposes. Specific warranty details may vary by region and retailer. Refer to your point of purchase for detailed warranty information.

