Chefavor KQKX

Chefavor 7-in-1 Electric Indoor Grill Air Fryer Combo User Manual

Model: KQKX

1. Introduction

The Chefavor Electric Indoor Grill Air Fryer Combo is a versatile 7-in-1 kitchen appliance designed to simplify your cooking experience. It combines the functions of an Indoor Grill, Air Fryer, Roaster, Baker, Broiler, Crisper, and Dehydrator, allowing you to prepare a wide variety of meals with ease. Its innovative design and smart features ensure efficient and delicious results.



Figure 1.1: The Chefavor 7-in-1 Electric Indoor Grill Air Fryer Combo, showcasing its grilling capabilities with steaks and vegetables.

Key Features:

- **7-in-1 Functionality:** Indoor Grill, Air Fryer, Roast, Bake, Broil, Crisp, Dehydrate, and Preheat.
- **Smokeless Indoor Grilling:** Utilizes 360° Rapid Air Circulation technology for even cooking with less fat and oil.

- **Intuitive LED Display & Viewing Window:** Monitor cooking progress without interrupting the process.
- **Smart Thermometer:** Ensures precise cooking temperatures for perfect results.
- **Large Capacity:** 11QT capacity, suitable for 3-5 people.
- **Easy to Clean:** Non-stick, dishwasher-friendly frying basket, frying pan, and grill grate.

What's Included:

- Chefavor Air Fryer Combo Unit
- 3 qt Air Fryer Basket
- 5 qt Frying Pan
- 12" x 9" Grill Grate
- Smart Probe (conveniently stored under the handle)
- Instruction Manual (this document)

2. Setup

Before first use, ensure all packaging materials are removed. Place the unit on a stable, heat-resistant surface with adequate clearance for proper ventilation.



Figure 2.1: For optimal usage, ensure a height clearance of 18-20 inches above the table and a width clearance of 24-26 inches from the wall to allow sufficient space for the indoor grill.

Initial Cleaning:

Wash the frying basket, frying pan, and grill grate with warm, soapy water. Rinse thoroughly and dry completely before placing them back into the unit. Wipe the main unit with a damp cloth.

Placement:

Position the appliance on a flat, stable, and heat-resistant countertop. Ensure there is sufficient space around the unit for proper air circulation, as indicated in Figure 2.1. Do not place the unit near flammable materials or heat sources.

Power Connection:

Plug the power cord into a grounded electrical outlet. The appliance operates at 1800 watts.

3. Operating Instructions

The Chefavor Indoor Grill Air Fryer Combo offers multiple cooking functions accessible via its intuitive LED display.



Figure 3.1: The intuitive LED display and transparent viewing window allow for easy monitoring of cooking progress.

Selecting a Cooking Function:

Use the control panel to select your desired cooking function (e.g., Air Fry, Grill, Bake, Broil, Roast, Dehydrate). Adjust temperature and time settings as needed for your recipe.

Dual Cooking Style:

The appliance supports cooking with the hood open or closed, offering flexibility for various dishes.

- **Hood Closed:** Activates both top and bottom heating elements for comprehensive cooking, ideal for air frying, roasting, and baking.
- **Hood Open:** Primarily uses the bottom heating element, suitable for griddling or quick searing.



Figure 3.2: The Chefavor Indoor Grill can be used with the hood open for bottom heating or closed for dual heating.

Using the Smart Thermometer:

For precise cooking, especially with meats, utilize the integrated smart thermometer. Insert the probe into the thickest part of the food, avoiding bone. The display will show the current internal temperature, allowing you to achieve your desired doneness.



Figure 3.3: The smart thermometer simplifies cooking by allowing you to select your desired food type and level of doneness for perfect results.

Example Recipe: Shakshuka

This video demonstrates how to prepare Shakshuka using the Chefavor Indoor Grill Air Fryer Combo, highlighting the griddle function and ease of use.

Your browser does not support the video tag.

Video 3.1: Easy Cooking with Chefavor - Shakshuka. This video provides a step-by-step guide to making Shakshuka, demonstrating the appliance's griddle function and ease of operation.

4. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your Chefavor Indoor Grill Air Fryer Combo. Always unplug the appliance and allow it to cool completely before cleaning.

Removable Parts:

The frying basket, frying pan, and grill grate are designed with a non-stick coating and are dishwasher safe. For best results, place them on the top rack of your dishwasher.



Figure 4.1: The frying basket, frying pan, and grill grate are non-stick and dishwasher safe for effortless cleaning.

Main Unit Cleaning:

Wipe the exterior and interior of the main unit, including the electronic components and viewing window, with a soft, damp cloth. Do not immerse the main unit in water or any other liquid. Avoid using abrasive cleaners or scouring pads, as they may damage the surfaces.

5. Troubleshooting

If you encounter any issues with your Chefavor Indoor Grill Air Fryer Combo, please refer to the following common troubleshooting tips:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working electrical outlet. Check your household circuit breaker.
- **Food not cooking evenly:** Ensure the unit is placed on a level surface. For optimal air circulation, avoid overcrowding the cooking area.
- **Excessive smoke:** Ensure the drip tray is clean and free of excessive grease. Some smoke is normal when cooking high-fat foods.
- **Display not responding:** Unplug the unit from the power outlet, wait for a few minutes, then plug it back in to reset the system.

For persistent issues or technical support, please contact Chefavor customer service.

6. Specifications

Feature	Specification
Brand	Chefavor
Model Number	KQKX
Wattage	1800 watts
Fuel Type	Electric
Recommended Use	Indoor
Finish Type	Non-Stick
Material	Metal, Stainless Steel
Item Dimensions (L x W x H)	18.31 x 13.39 x 17.91 inches
Item Weight	23.7 Pounds
Heating Elements	2
Cooking System	Convection
UPC	757530683509, 757530683189, 757530683523

7. Warranty and Support

For detailed warranty information, please refer to the documentation included with your purchase or visit the official Chefavor website. Chefavor is committed to providing high-quality products and customer satisfaction.

Additional Resources:

- **Digital User Manual:** A digital version of this manual is available for download. Download User Manual (PDF)
- **User Guide:** An additional user guide is also available. Download User Guide (PDF)
- **Recipe Guide & How-To Videos:** Access an easy-to-follow recipe guide and plenty of how-to and recipe videos to maximize your cooking experience. These resources are typically available on the product's Amazon page or the Chefavor brand store.
- **Chefavor Brand Store:** Explore more products and resources from Chefavor. Visit Chefavor Store

© 2023 Chefavor. All rights reserved.