

DORTALA HW68178

DORTALA Wicker Patio Bistro Set (Model HW68178) Instruction Manual

Brand: DORTALA | Model: HW68178

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Do not overload chairs beyond the 350 lbs (158 kg) capacity.
- Use anti-slip footpads to prevent tip-overs and ensure stability.
- Exercise caution with the tempered glass tabletop to prevent breakage.
- Follow assembly instructions precisely.
- Keep small parts, such as cushion fasteners, away from children to prevent choking hazards.
- Ensure all bolts are securely tightened before use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Dining Table
- 2 x Single Chairs
- 2 x Cushions
- 1 x Instruction Manual
- Hardware Pack (Bolts, Washers, Allen Wrench)

ASSEMBLY INSTRUCTIONS

It is recommended to assemble the set on a soft, clean surface to prevent scratches. Do not fully tighten any screws until all components are loosely assembled and aligned.

Assembly Video Guide

Your browser does not support the video tag.

Official assembly video for the DORTALA Wicker Patio Bistro Set, demonstrating step-by-step construction of the chairs and table. This

video guides you through connecting all parts using the provided hardware.

Step-by-Step Assembly

1. Chair Assembly:

- Identify the chair components: seat, backrest, side panels.
- Attach the backrest to the seat using the specified bolts and washers.
- Connect the side panels to the assembled seat and backrest. Ensure all holes align before inserting and hand-tightening bolts.
- Once all bolts are in place, gradually tighten them with the Allen wrench. Avoid over-tightening.



Refer to the dimensions diagram for proper component identification and orientation during assembly.

2. Table Assembly:

- Identify the table frame and support bars.
- Assemble the main table frame using the appropriate bolts and washers.
- Attach any cross-support bars to enhance stability.
- Place the tempered glass tabletop onto the assembled frame. Ensure it sits securely and use the provided suction

cups to fix it in place.

- Gradually tighten all bolts on the table frame.

3. Final Adjustments:

- After assembling both chairs and the table, gently rock each piece to ensure stability.
- If any piece is uneven, slightly loosen the bolts, adjust the position, and then re-tighten.
- Place cushions on the chairs.



The set features weather-resistant PE rattan, stable steel support, and anti-slip foot pads for durability and safety.

PRODUCT FEATURES

The DORTALA Wicker Patio Bistro Set is designed for comfort and durability in outdoor environments.

- **Durable Construction:** Features a high-strength steel frame wrapped with weather-resistant PE rattan, ensuring sturdiness and longevity.
- **Comfortable Seating:** Includes thick, high-resilient cushions with curved backrests and ergonomic armrests for optimal

comfort.

- **Practical Tabletop:** Equipped with a premium tempered glass tabletop for safe use, secured by suction cups.
- **Space-Saving Design:** Chairs can be tucked underneath the dining table when not in use, optimizing space.
- **Easy Maintenance:** Cushions feature zippered, removable, and washable covers for convenient cleaning.

Comfortable and Breathable Cushions



Soft Touch



Removable and Washable Cover

The cushions are designed for comfort with a soft touch and feature removable, washable covers.

Practical Coffee Table



◀ Premium Tempered Glass



◀ Suction Cup

The practical coffee table features a premium tempered glass top secured by suction cups.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your patio bistro set.

- **Cleaning Rattan:** Wipe the PE rattan surfaces with a damp cloth and mild soap. Rinse thoroughly and dry completely. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Cushions:** Remove cushion covers and machine wash them on a gentle cycle with cold water. Air dry only; do not tumble dry. Spot clean cushion inserts as needed.
- **Cleaning Glass Top:** Use a glass cleaner and a soft cloth to clean the tempered glass tabletop.
- **Frame Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.
- **Storage:** During harsh weather conditions or off-season, it is recommended to store the set indoors or cover it with a weather-resistant furniture cover to protect it from elements.

SPECIFICATIONS

Attribute	Detail
Brand	DORTALA
Model	HW68178
Color	Turquoise (Cushions)
Material Type	PE Rattan, Steel, Tempered Glass
Style	Modern
Shape	Rectangular (Table)
Assembly Required	Yes
Chair Weight Capacity	350 lbs (158 kg) per chair
Table Weight Capacity	110 lbs (50 kg)
Included Components	1 x Dining Table, 2 x Single Chairs, 2 x Cushions, 1 x Instruction

TROUBLESHOOTING

- **Difficulty with Screw Alignment:** If screw holes do not align easily during assembly, do not force the screws. Loosely assemble all parts first, then gently adjust the components to align the holes before tightening any screws. This often resolves alignment issues.
- **Unstable or Wobbly Furniture:** Ensure all bolts are fully tightened. If wobbling persists, check that the furniture is on a flat, even surface. Adjust the anti-slip footpads if necessary to compensate for uneven ground.
- **Cushions Sliding:** If cushions slide excessively, consider adding non-slip pads or strips to the chair seats beneath the cushions.

WARRANTY AND SUPPORT

For warranty information, missing parts, or any product-related inquiries, please contact DORTALA customer support directly. Refer to the contact information provided on the product packaging or the official DORTALA website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CHVQYLGR>

More documents and user manuals: <https://manuals.plus/>