

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Osann](#) /

> [Osann One360 i-Size Child Car Seat Instruction Manual](#)

## Osann One360 i-Size (Model 98OSA108-301-322)

### Osann One360 i-Size Child Car Seat Instruction Manual

Model: One360 i-Size (98OSA108-301-322)

Brand: Osann

#### 1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the Osann One360 i-Size child car seat. This manual provides essential information for the correct installation, use, and maintenance of your car seat. Please read these instructions carefully before use and keep them in a safe place for future reference.

##### Important Safety Warnings:

- Always ensure the car seat is correctly installed and secured in your vehicle according to these instructions.
- Never leave a child unattended in the car seat.
- Ensure the child is properly secured with the harness system at all times.
- Do not modify the car seat in any way. Use only original Osann spare parts if replacement is necessary.
- In the event of an accident, even if the car seat appears undamaged, it must be replaced.
- Refer to your vehicle's owner's manual for information on child restraint system installation.

The Osann One360 i-Size is designed for children from 40 cm to 150 cm in height, approximately from birth up to 12 years of age. It complies with the i-Size (ECE R129) safety standard.

#### 2. PRODUCT FEATURES

The Osann One360 i-Size car seat offers a range of features designed for safety and convenience:

- **360° Rotation Function:** Allows easy access for placing and removing your child from either side of the vehicle.
- **Rearward and Forward Facing:** Supports rearward-facing travel from 40-105 cm (max. 18 kg) and forward-facing travel from 76-150 cm.
- **14-Position Height-Adjustable Headrest:** Ensures optimal head protection and comfort as your child grows.
- **Magnetic Belt Holders:** Conveniently hold the harness straps open while placing your child in the seat.
- **Integrated 5-Point Harness System:** For securing children from 40-105 cm. This harness system can be stored within the seat for use with the vehicle's 3-point belt for children from 100-150 cm.

- **Multiple Recline Positions:** Two recline positions for rearward-facing (R1: 40-75 cm; R2: 76-105 cm) and four sitting/resting positions in total.
- **Isofix Connectors:** Individually adjustable Isofix connectors for secure and stable installation in the vehicle.
- **Removable Comfort Insert:** Provides additional comfort and support for infants.



Image 2.1: Overview of Osann One360 i-Size car seat features, including removable comfort insert, 14-way height-adjustable headrest, magnetic shoulder strap holders, belt and buckle padding, automatically growing belt system, individually adjustable Isofix connectors, and 360° rotation for easy entry.



Image 2.2: The Osann One360 i-Size car seat, developed according to the new i-Size Norm ECE R129.

### 3. SETUP AND INSTALLATION

Proper installation is crucial for your child's safety. Follow these steps carefully.

#### 3.1 Installation with Isofix and Top-Tether (40-105 cm)

1. Position the car seat on the vehicle seat.
2. Extend the Isofix connectors by pressing the release button (usually located at the front of the base) and pulling them out.
3. Align the Isofix connectors with the Isofix anchor points in your vehicle and push them in until they click securely into place. Indicators on the connectors should turn green.
4. Push the car seat firmly against the vehicle seat back to remove any slack.
5. Attach the Top-Tether strap to the designated anchor point in your vehicle (refer to your vehicle's manual for location). Tighten the Top-Tether strap until the indicator shows it is correctly tensioned.



Image 3.1: Secure and easy attachment in the car with Isofix and Top-Tether.

### **3.2 Rearward-Facing Use (40-105 cm)**

For children from 40 cm to 105 cm (up to 18 kg), the car seat must be used in the rearward-facing position. Ensure the comfort insert is used for smaller infants (40-75 cm).

### **3.3 Forward-Facing Use (76-150 cm)**

For children from 76 cm (minimum 15 months), the car seat can be used in the forward-facing position. For children from 100 cm to 150 cm, the integrated 5-point harness system must be stored, and the child secured using the vehicle's 3-point seat belt.

### **3.4 Converting to Booster Mode (100-150 cm)**

When your child reaches 100 cm, the 5-point harness system can be easily stored within the car seat without disassembly. This converts the seat for use with the vehicle's 3-point seat belt. Follow the instructions in the full manual for detailed steps on storing the harness.

# Ab Geburt bis 12 Jahre



Rückwärts  
40-105 cm



Vorwärts  
76-105 cm



Vorwärts  
100-150 cm

Image 3.2: Usage stages from birth to 12 years: Rearward-facing (40-105 cm), Forward-facing (76-105 cm with harness), Forward-facing (100-150 cm with vehicle belt).

## 4. OPERATING INSTRUCTIONS

### 4.1 Securing Your Child with the 5-Point Harness (40-105 cm)

1. Place your child in the car seat.
2. Bring the shoulder straps over your child's shoulders and connect the two buckle tongues.
3. Insert the connected buckle tongues into the central buckle until you hear a click.
4. Pull the adjustment strap at the front of the seat to tighten the harness until it is snug against your child's body, ensuring no more than two fingers can fit between the strap and your child's collarbone.
5. To release the harness, press the red button on the central buckle.

Inklusive  
Magnethalterung



Image 4.1: Magnetic holders keep the harness straps out of the way for easy placement of your child.

#### 4.2 Adjusting the Headrest

The headrest can be adjusted to 14 different height positions. To adjust, locate the headrest adjustment lever (usually at the top back of the headrest), squeeze it, and slide the headrest up or down to the desired position. Ensure the headrest is positioned so that the shoulder straps are at or slightly below your child's shoulders when rearward-facing, and at or slightly above when forward-facing.

# 14- fach höhenverstellbare Kopfstütze



Image 4.2: The 14-way height-adjustable headrest ensures a perfect fit as your child grows.

## 4.3 Adjusting Recline Positions

The car seat offers multiple recline positions for comfort. Locate the recline adjustment handle (usually at the front or side of the base), pull or press it, and tilt the seat to the desired recline angle. Ensure the seat clicks into place in the chosen position.



Image 4.3: The car seat offers 4 sitting and resting positions for optimal comfort.

#### 4.4 Rotating the Car Seat

To rotate the car seat, ensure the child is not in the seat and the vehicle is stationary. Locate the rotation release lever (usually at the front of the base). Press or pull the lever and rotate the seat to the desired orientation (facing the door for entry/exit, or rearward/forward for travel). Ensure the seat locks securely into place before driving.



Image 4.4: The car seat is rotatable by 360° for convenient entry and exit from both sides.

## 5. MAINTENANCE

### 5.1 Cleaning Instructions

- **Fabric Covers:** The fabric covers are removable and washable. Refer to the care label on the covers for specific washing instructions (e.g., machine wash cold, gentle cycle). Do not tumble dry.
- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Harness System:** Wipe the harness straps with a damp cloth. Do not immerse the buckle in water or use lubricants, as this may affect its performance.

### 5.2 General Care

- Regularly check all parts of the car seat for signs of wear, damage, or loose components.
- Ensure all buckles, adjusters, and locking mechanisms function smoothly.
- Store the car seat in a cool, dry place away from direct sunlight when not in use for extended periods.

## 6. TROUBLESHOOTING

If you encounter any issues with your Osann One360 i-Size car seat, please refer to the following common solutions:

- **Difficulty with Isofix installation:** Ensure the Isofix connectors are fully extended and aligned correctly with the vehicle's anchor points. Push firmly until you hear a click and the indicators turn green.
- **Harness difficult to tighten/loosen:** Check that the harness straps are not twisted or caught under the seat. Ensure the adjustment strap is pulled straight.
- **Seat not rotating smoothly:** Ensure the rotation release lever is fully engaged. Check for any obstructions under the seat. The seat should be empty when rotating.
- **Headrest not adjusting:** Ensure the adjustment lever is fully squeezed while attempting to move the headrest.

If you are unable to resolve an issue, please contact Osann customer support for assistance.

## 7. SPECIFICATIONS

<b>Model</b>	One360 i-Size
<b>Model Number</b>	98OSA108-301-322
<b>Child Height Range</b>	40 cm - 150 cm
<b>Maximum Weight (with 5-point harness)</b>	18 kg
<b>Main Material</b>	Plastic
<b>Special Features</b>	i-Size, Isofix, 360° Rotation
<b>Number of Recline Positions</b>	4 (total)
<b>Number of Headrest Height Positions</b>	14
<b>Orientation</b>	Rearward-facing (40-105 cm), Forward-facing (76-150 cm)
<b>Harness Type</b>	5-point (up to 105 cm)
<b>Product Dimensions (L x W x H)</b>	48.5 x 43 x 58 cm
<b>Product Weight</b>	13.2 kg

## 8. WARRANTY AND SUPPORT

Osann products are manufactured to high-quality standards and come with a manufacturer's warranty. Please refer to the warranty card included with your purchase or visit the official Osann website for detailed warranty terms and conditions.

For technical support, spare parts, or any questions regarding your Osann One360 i-Size car seat, please contact Osann customer service through their official website or the contact information provided in your product packaging.