



Manuals.plus /

› Invicta /

› Invicta Men's Pro Diver Quartz Watch Model 44708 Instruction Manual

## Invicta 44708

# Invicta Men's Pro Diver Quartz Watch Model 44708 Instruction Manual

YOUR GUIDE TO OPERATION AND CARE

## 1. PRODUCT OVERVIEW

---

### 1.1 Introduction

This manual provides comprehensive instructions for the proper use and care of your new Invicta Men's Pro Diver Quartz Watch, Model 44708. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

### 1.2 Key Features

- 43 millimeter stainless steel case with a black dial.
- Powered by an accurate Quartz movement.
- 10 bar water pressure resistant (equivalent to 100 meters).
- Part of the Invicta Pro Diver collection.
- Includes a 2-year Invicta warranty.




Figure 1: Front view of the Invicta Men's Pro Diver Quartz Watch Model 44708, showcasing its black dial and stainless steel case.

## 2. INITIAL SETUP

---

## 2.1 Setting the Time and Date

1. To set the time, gently pull the crown (the knob on the side of the watch) out to the second click position.
2. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. To set the date, push the crown in to the first click position. Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this may damage the movement.
4. Once the time and date are set, push the crown back in completely to its original position to engage the movement and ensure water resistance.

## 2.2 Adjusting the Bracelet

The stainless steel bracelet of your watch can be adjusted to fit your wrist comfortably. This typically involves removing or adding links. Due to the precision required, it is recommended to have this adjustment performed by a qualified jeweler or watch technician to prevent damage to the bracelet or spring bars.



Figure 2: Rear view of the watch, illustrating the bracelet and clasp mechanism. Professional adjustment is recommended for link removal.

## 3. OPERATION

---

### 3.1 Water Resistance Guidelines

Your Invicta Pro Diver watch is water resistant up to 100 meters (10 bar). This rating makes it suitable for swimming, snorkeling, and recreational diving. However, it is not suitable for high-impact water sports or deep-sea diving. Always ensure the crown is fully pushed in and tightened (if screw-down type) before any water exposure.

### 3.2 Unidirectional Bezel Use

The watch features a unidirectional rotating bezel. This bezel can be used to time events, such as dive times or elapsed time for other activities. To use, rotate the bezel counter-clockwise until the zero marker aligns with the minute hand. As time passes, the minute hand will indicate the elapsed time on the bezel scale.



Figure 3: Close-up of the watch face, highlighting the minute markers and the unidirectional rotating bezel for timing.

## 4. CARE AND MAINTENANCE

---

### 4.1 Cleaning Your Watch

To maintain the appearance of your watch, clean it regularly with a soft, damp cloth. For stainless steel

bracelets, a soft brush can be used to remove dirt from between the links. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals. After exposure to saltwater, rinse the watch with fresh water and dry thoroughly.

## 4.2 Battery Replacement

The quartz movement in your watch is powered by a battery. When the battery runs low, the watch may stop or the second hand may jump in irregular intervals (End-of-Life indicator). Battery replacement should only be performed by an authorized Invicta service center or a professional watchmaker to ensure the watch's water resistance and proper functioning are maintained.

# 5. TROUBLESHOOTING

---

## 5.1 Watch Not Functioning

- **Check the Crown:** Ensure the crown is fully pushed in to its normal operating position. If it's pulled out, the watch will not run.
- **Battery Depletion:** If the watch has stopped completely, the battery may need replacement. Refer to Section 4.2.

## 5.2 Water Condensation Inside the Crystal

If you notice condensation or moisture inside the watch crystal, it indicates a potential breach in the water resistance. This requires immediate attention from an authorized service center to prevent further damage to the movement.

# 6. PRODUCT SPECIFICATIONS

---

## 6.1 Technical Details

Feature	Detail
Model Number	44708
Brand Name	Invicta
Display Type	Analog
Watch Movement Type	Quartz
Case Material Type	Stainless Steel
Case Diameter	43 Millimeters
Case Thickness	11.3 Millimeters
Band Material Type	Stainless Steel
Band Width	22 Millimeters
Band Length	185 Millimeters
Dial Color	Black
Crystal Type	Synthetic Sapphire
Water Resistance Depth	100 Meters (10 Bar)
Clasp Type	Foldover Clasp
Item Weight	170 Grams
Additional Features	Waterproof, Glow In The Dark

## 7. WARRANTY AND SUPPORT

---

### 7.1 Warranty Information

Your Invicta Men's Pro Diver Quartz Watch Model 44708 comes with a 2-year limited warranty from Invicta. This warranty covers manufacturing defects under normal use. Please refer to the warranty documentation included with your watch for full terms and conditions.

### 7.2 Customer Support

For any questions, service requests, or warranty claims, please contact Invicta customer support. Contact details can typically be found on the official Invicta website or in the warranty booklet provided with your purchase.