**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## CIO SMARTCOBY SLIM

# CIO SMARTCOBY SLIM Mobile Battery User Manual

Model: SMARTCOBY SLIM (CIO-MB20W2C-5000)

## 1. Introduction

Thank you for choosing the CIO SMARTCOBY SLIM mobile battery. This ultra-thin and lightweight power bank is designed for convenient on-the-go charging, featuring 20W Power Delivery (PD) fast charging, dual USB-C ports, and a 5000mAh capacity. This manual provides essential information for the safe and efficient use of your device. Please read it thoroughly before use and keep it for future reference.




**Image 1.1:** The CIO SMARTCOBY SLIM mobile battery in black, showcasing its compact and sleek design.

## 2. Package Contents

Please check that all the following items are included in your package:

- CIO SMARTCOBY SLIM Main Unit
- User Manual (Japanese/English)
- USB-C to USB-C Charging Cable




**Image 2.1:** Visual representation of the SMARTCOBY SLIM package contents and a summary of its product specifications.

## 3. Product Features

- **Ultra-Thin and Lightweight Design:** At just 12mm thick and approximately 108g, it's designed for ultimate portability, easily fitting into pockets or small bags. Its credit card-like size allows for comfortable stacking with your smartphone.
- **20W Power Delivery (PD) Fast Charging:** Supports up to 20W output from a single USB-C port, enabling rapid charging for smartphones (e.g., iPhone, Galaxy, Xperia) and tablets (e.g., iPad).
- **Dual USB-C Ports:** Equipped with two USB-C charging ports, allowing you to charge two devices simultaneously. The total output when charging two devices is 15W.
- **Pass-Through Charging:** Charge both the mobile battery and a connected device simultaneously from a single power outlet. The device connected to the power bank will charge first, followed by the power bank itself.
- **Durable Textured Surface:** The product features a rough textured finish, similar to a DSLR camera body, which helps prevent scratches and maintains its aesthetic appeal over time.
- **Digital Battery Display:** A clear digital display shows the remaining battery percentage, allowing you to monitor the power level precisely and recharge at the optimal time.
- **5000mAh Capacity:** Provides approximately one full charge for most smartphones, making it ideal for emergency power or extending daily usage.




**Image 3.1:** An overview of the SMARTCOBY SLIM's key features, highlighting its thinness, lightness, dual USB-C ports, 5000mAh capacity, 20W PD, and digital display.




**Image 3.2:** Demonstrates the SMARTCOBY SLIM's portability, showing its 12mm thickness, how it can be stacked with a phone, and how it easily fits into small spaces like a bag or pocket.




**Image 3.3:** A close-up view of the SMARTCOBY SLIM's digital display showing the battery percentage, ensuring clear and precise power monitoring.




**Image 3.4:** A detailed view of the SMARTCOBY SLIM's textured surface, designed to be scratch-resistant for long-lasting durability and appearance.




**Image 3.5:** Illustrates the 5000mAh capacity of the SMARTCOBY SLIM, showing approximate charge cycles for various smartphone models like iPhone 13 mini, iPhone 15, and Galaxy S23.

## 4. Setup

### 4.1 Initial Charging of the SMARTCOBY SLIM

1. Use the provided USB-C to USB-C cable.
2. Connect one end of the cable to either USB-C port on the SMARTCOBY SLIM.
3. Connect the other end of the cable to a USB power adapter (not included) with a minimum output of 5V/2A. For faster charging of the power bank, use a PD-compatible adapter.
4. The digital display will show the charging progress. The last digit will blink during charging.
5. Charging is complete when the display shows


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question