

[Manuals.plus](#) /

› [YITAHOME](#) /

› YITAHOME Patio Furniture Instruction Manual

YITAHOME MAYIH0009189MA

YITAHOME Patio Furniture Instruction Manual

Model: MAYIH0009189MA

PRODUCT OVERVIEW

The YITAHOME 2-Piece Patio Furniture Wicker Outdoor Loveseat is designed for comfortable outdoor leisure. This set includes a loveseat, a side table, and soft cushions, perfect for conversation areas in your backyard, balcony, or deck.



Figure 1: Complete YITAHOME 2-Piece Patio Furniture Set with Loveseat and Side Table.

The furniture features high-end handwoven rattan braced with a solid steel frame, ensuring weather resistance and durability. The wide seat space and thick cushions provide a cozy experience, and the cushion covers are detachable for easy maintenance.



Figure 2: The loveseat provides comfortable seating for two, ideal for balconies or small outdoor spaces.

SETUP AND ASSEMBLY

This patio furniture set is designed for convenient assembly. All necessary parts and instructions are included to ensure a straightforward setup process.

Assembly Steps:

1. Unpack all components and verify against the parts list provided in the packaging.
2. Follow the step-by-step instructions to assemble the loveseat frame. Ensure all screws are tightened securely.
3. Assemble the side table, attaching the tempered glass top. The glass top is designed to suction onto the frame for stability.
4. Place the soft cushions onto the loveseat.

5. Adjust the adjustable feet on the furniture legs to ensure stability on uneven surfaces.



Figure 3: Detailed dimensions of the loveseat and side table for planning your space. Loveseat: 45.3"L x 20.5"W x 32.2"H. Coffee Table: 35.4"L x 19.3"W x 17.7"H.

Assembly Video:

Your browser does not support the video tag.

Video 1: Official YITAHOME assembly guide for the 2-piece wicker loveseat. This video demonstrates the steps for putting together your new patio set.

OPERATING INSTRUCTIONS

The YITAHOME patio set is designed for comfortable and versatile use in various outdoor settings. Enjoy relaxing moments or entertain guests with ease.

Using the Loveseat:

- The loveseat provides ample seating space for two individuals.
- The thick cushions offer superior comfort for extended periods of relaxation.
- Position the loveseat in your desired outdoor area, ensuring it is on a stable, level surface.

Utilizing the Side Table:

- The elegant tempered glass side table provides a sturdy surface for drinks, snacks, books, or decorative items.
- The maximum weight capacity for the side table is 75 lbs (34 kg). Do not exceed this limit.



Figure 4: The side table is ideal for holding beverages and small items, enhancing your outdoor experience.



Figure 5: Features include comfortable and soft cushions, removable and washable covers, and adjustable feet for stability.

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your YITAHOME patio furniture. The materials are designed for all-weather use, but regular care is recommended.

Cleaning:

- For general cleaning of the rattan and steel frame, wipe with a dry cloth.
- The cushion covers are detachable and washable for easy maintenance. Refer to the care label on the cushions for specific washing instructions.
- For the tempered glass table top, use a soft, damp cloth and mild cleaner if necessary. Avoid abrasive materials.

ALL-Weather Wicker



Figure 6: The high-end handwoven rattan is designed for all-weather durability.

Storage:

- During prolonged periods of non-use or severe weather conditions (heavy rain, snow, extreme temperatures), it is recommended to store cushions indoors or in a weather-resistant storage box.
- Consider using a patio furniture cover to protect the entire set from dust, debris, and harsh elements when not in use.

TROUBLESHOOTING

This section addresses common issues you might encounter with your patio furniture.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Furniture feels wobbly.	Uneven surface or loose connections.	Adjust the furniture's adjustable feet. Check and tighten all bolts and screws.
Cushions appear dirty or stained.	Exposure to dirt, spills, or weather.	Remove cushion covers and wash according to care instructions. Spot clean small stains.
Rattan appears dull or dusty.	Accumulation of dust and environmental debris.	Wipe down the rattan with a dry or slightly damp cloth.
Glass table top is not stable.	Suction cups not properly engaged or table not level.	Ensure the glass top is properly seated on the suction cups. Adjust table feet for levelness.

SPECIFICATIONS

Feature	Detail
Brand	YITAHOME
Model Number	MAYIH0009189MA
Material	Wicker, Steel, Tempered Glass
Color	Light Brown + Beige
Loveseat Dimensions (L x W x H)	45.3 x 20.5 x 32.2 inches
Coffee Table Dimensions (L x W x H)	35.4 x 19.3 x 17.7 inches
Item Weight	48.9 pounds (Total)
Side Table Weight Capacity	75 lbs (34 kg)
Product Care Instructions	Wipe with Dry Cloth
Country of Origin	China

WARRANTY AND SUPPORT

YITAHOME is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact YITAHOME customer support for any inquiries regarding warranty coverage or product assistance.

For further support, visit the official YITAHOME store or contact their customer service team. You can often find helpful resources and FAQs on their website.

[Visit the YITAHOME Store](#)

© 2024 YITAHOME. All rights reserved.