

## ORALNER SF105-18G

# ORALNER 32-inch Electric Fireplace with Mantel User Manual

Model: SF105-18G

## 1. IMPORTANT SAFETY INFORMATION

---

Please read and understand this entire owner's manual, including all safety information, before plugging in or using this product. Failure to do so could result in fire, electric shock, or serious personal injury.

- This electric fireplace is designed for indoor use only.
- Do not operate the fireplace if the cord or plug is damaged, or if the heater has malfunctioned or been dropped.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Ensure the power outlet is properly grounded and rated for 120V/60Hz.
- Do not run power cord under carpeting, throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- The unit features an **Overheat Protection** system that automatically shuts off the heater if it reaches an unsafe temperature. If this occurs, unplug the unit, wait 10 minutes, and plug it back in.
- This product is **CSA Certified** and features a **UL Certified Plug** for enhanced safety.
- An **Anti-Tipping Device** is included to secure the mantel to a wall, preventing accidental tipping. Install this device as instructed during assembly.

## Safe above All



 Overheat Protection

 CSA Certification

 UL Certified Plug

 Anti-tipping Device

This image illustrates the safety features of the ORALNER electric fireplace, including certifications and the anti-tipping device.

## 2. PACKAGE CONTENTS

Before assembly, ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or use the product. Contact customer service for assistance.

- 1 x 18-inch Electric Fireplace Insert
- 1 x 32-inch Fireplace Mantel
- 1 x Remote Control
- 1 x User Manual (this document)
- Assembly Hardware Kit

## 3. SETUP AND ASSEMBLY

The fireplace mantel requires assembly. It is recommended to have two people for assembly. Assembly typically takes approximately one hour. Follow the step-by-step instructions provided in the separate assembly guide included with your package.

1. Unpack all components and lay them out on a soft, clean surface to prevent scratches.

2. Identify all parts using the provided parts list in the assembly guide. Parts are typically labeled for easy identification.
3. Assemble the wooden mantel structure according to the diagrams and instructions. Ensure all connections are secure.
4. Carefully insert the 18-inch electric fireplace insert into the designated opening in the assembled mantel.
5. Secure the anti-tipping device to the back of the mantel and to a wall stud using the provided hardware. This is a critical safety step.
6. Place the assembled fireplace on a flat, stable surface. Ensure adequate clearance from walls and other objects.



The ORALNER electric fireplace with mantel, ready for use after assembly.



This diagram provides detailed dimensions for both the mantel and the fireplace insert, crucial for planning placement.

## 4. OPERATING INSTRUCTIONS

---

The ORALNER electric fireplace can be operated using either the control panel on the unit or the included remote control.

### Control Panel and Remote Control Functions:

- **Power Button:** Turns the fireplace ON or OFF.
- **Heater Control:** Activates the heating function. The thermostat allows temperature adjustment from 62°F to 82°F. Use the 'Heater Up' and 'Heater Down' buttons on the remote to adjust.
- **Flame Control:** Adjusts the flame brightness. There are 3 levels of flame brightness (L1, L2, L3).
- **Timer Control:** Sets an automatic shut-off timer for 0.5 to 6 hours.



# 2-Way Operation

**Power Button**  
On/Off

**Heater Control**  
62°F-82°F

**Flame Control**  
L1/L2/L3

**Timer Control**  
0.5-6H

**Heater Up**

**Heater Down**

**26 ft**  
Effective Control Distance

Require 2 x AAA batteries (not included)

This image details the functions of both the fireplace control panel and the remote control. The remote has an effective control distance of 26 feet and requires 2 x AAA batteries (not included).

## Flame Effects and Heating:

The fireplace offers realistic 3D flame effects that can be used independently or with the heating function.

- **Flame Only Mode:** Enjoy the visual ambiance of flames without heat. This is ideal for decorative purposes or warmer weather.
- **Flame and Heat Mode:** Activate both the flame effect and the heater for warmth and ambiance. The heater provides up to 5000 BTU heat output, covering up to 400 sq ft.



## Two Operation Options

✔ Remote Control

✔ Touch Control



Power



Heater



Flame



Timer



Temp +



Temp -

This image highlights the dual control options and the various functions available for operating the fireplace.



This image demonstrates the flexibility of using the fireplace with or without the heating function, alongside a reminder of the anti-tipping device.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your electric fireplace.

- **Cleaning:** The surface of the fireplace is easy to clean. Use a soft, damp cloth to wipe down the exterior. Do not use abrasive cleaners or sprays.
- **Air Vents:** Periodically check the air inlet and air outlet vents for dust or obstructions. Gently clean with a soft brush or vacuum cleaner attachment to ensure proper airflow.
- **Storage:** If storing the fireplace for an extended period, unplug it and cover it to protect from dust and moisture.



This image points out key areas for maintenance, including the easy-to-clean surface and air vents.

## 6. TROUBLESHOOTING

If you experience issues with your ORALNER electric fireplace, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not plugged in, or main power switch off.	Ensure the unit is plugged into a working 120V/60Hz outlet. Check the main power switch on the unit.
Heater does not produce heat.	Heater function not activated, thermostat set too low, or overheat protection triggered.	Activate the heater function. Increase the thermostat setting. If overheat protection triggered, unplug for 10 minutes and restart.
Flame effect is not visible or dim.	Flame brightness set to lowest level or flame bulb issue.	Adjust flame brightness using the flame control button. If still an issue, contact customer support.

Problem	Possible Cause	Solution
Remote control not working.	Batteries dead or incorrectly inserted, or remote out of range.	Replace batteries (2 x AAA). Ensure batteries are inserted correctly. Operate remote within 26 feet of the unit.
Unusual noises during operation.	Minor operational sounds are normal. If loud or persistent, internal component issue.	Ensure unit is on a level surface. If noise persists and is concerning, discontinue use and contact customer support.

## 7. SPECIFICATIONS

---

Detailed technical specifications for the ORALNER Electric Fireplace with Mantel.

- **Brand:** ORALNER
- **Model Name:** Freestanding Electric Fireplace
- **Model Number:** SF105-18G
- **Product Dimensions (Mantel):** 9"D x 32"W x 30"H
- **Fireplace Insert Size:** 18"W x 17"H
- **Power Source:** Corded Electric
- **Voltage:** 120V/60Hz
- **Power Consumption:** 1400 Watts
- **Material:** Metal, Wood Frame
- **Finish Type:** Painted
- **Installation Type:** Freestanding
- **Heat Output:** 5000 British Thermal Units (BTU)
- **Heating Coverage:** Up to 400 sq ft
- **Thermostat Range:** 62°F - 82°F
- **Flame Effects:** 3-level brightness
- **Timer:** 0.5 - 6 hours
- **Control:** Remote Control, Touch Control
- **Remote Control Distance:** Up to 26 ft
- **Safety Features:** Overheat Protection, CSA Certification, UL Certified Plug, Anti-Tipping Device
- **Ventilation Type:** Vent Free
- **Item Weight:** 40 Pounds
- **Power Cord Length:** 6 Ft



This image provides a visual summary of the product's key specifications.

## 8. WARRANTY AND SUPPORT

---

This ORALNER electric fireplace comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or contact ORALNER customer support.

For technical assistance, missing parts, or any questions not covered in this manual, please contact ORALNER customer service through the retailer where the product was purchased or visit the official ORALNER website for support contact information.