Coolife YD000075

Coolife 20-inch Carry-On Luggage Instruction Manual

Model: YD000075 | Brand: Coolife

1. Introduction

Thank you for choosing the Coolife 20-inch Carry-On Luggage. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new suitcase. Please read these instructions carefully before use and retain them for future reference.

2. Key Features

- **Airline Approved Size:** Designed to meet most major airline size requirements (22"x14"x9") for carry-on luggage, helping you avoid checked baggage fees.
- **Smooth Handling:** Features a quiet two-wheel setup for upright pulling and a 3-level adjustable pure aluminum telescopic handle for stability and maneuverability.
- **Durable Hard Shell:** Constructed from lightweight yet ultra-durable ABS+PC material with a textured surface to resist scratches. Beveled edges enhance resilience. Comfortable top and side handles are included for easy lifting.
- **TSA-Approved Lock:** Integrated combination lock allows security officials to inspect your bag without damaging the lock.
- **Organized Interior:** Fully lined interior with strong cross straps and a zippered mesh pocket to secure contents and maximize packing space.



Image: The 20-inch Coolife Carry-On Luggage fits perfectly into an airplane's overhead bin, demonstrating its airline-approved dimensions.



Image: A traveler effortlessly pulls the luggage with its extended telescopic handle and smooth 360-degree spinner wheels.



Image: The spacious interior features adjustable cross straps and a zippered mesh pocket to keep belongings secure and organized.

3. Setup

3.1 Setting the TSA Combination Lock

Your luggage comes with a preset combination of 0-0-0. To set your personal combination:

1. Ensure the lock is set to the default 0-0-0.
2. Locate the small reset button (usually recessed) next to the dials. Use a pen or pointed object to press and hold this button.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set. Remember your combination as there is no master key.



Image: Visual guide for setting the integrated TSA combination lock.

4. Operating Instructions

4.1 Extending and Retracting the Telescopic Handle

To extend the handle, press the button located on the top of the handle and pull upwards. The handle has 3 adjustable levels. To retract, press the button and push downwards until it is fully stored.

4.2 Using the Spinner Wheels

The luggage features 360-degree spinner wheels for effortless multi-directional gliding. For optimal maneuverability, push the luggage upright on all four wheels. For rougher surfaces, tilt the luggage and pull it on two wheels.

4.3 Packing and Organization

Utilize the internal cross straps to compress your clothing and prevent shifting during transit. The zippered mesh pocket is ideal for smaller items, toiletries, or documents, keeping them separate and easily accessible.

5. Maintenance

5.1 Cleaning the Exterior

Wipe the hard shell exterior with a soft, damp cloth and mild soap. Avoid abrasive cleaners or solvents that could damage the surface. For stubborn marks, a gentle cleaner designed for plastics may be used.

5.2 Cleaning the Interior

The interior lining can be spot cleaned with a damp cloth and mild detergent. Allow to air dry completely before closing the luggage to prevent mildew.

5.3 Wheel and Handle Care

Periodically check the wheels for any debris or hair that might impede smooth rolling. Clean as necessary. Ensure the telescopic handle extends and retracts smoothly. Avoid forcing the handle if it feels stiff.

6. Troubleshooting

6.1 Lock Not Opening/Closing

Ensure the correct 3-digit combination is entered. If you forgot your combination, unfortunately, there is no master reset. You may need to try all possible combinations (000-999) or contact a locksmith.

6.2 Stiff or Stuck Telescopic Handle

Check for any obstructions in the handle mechanism. Ensure the release button is fully depressed when extending or retracting. Avoid applying excessive force.

6.3 Wheels Not Rolling Smoothly

Inspect the wheels for tangled hair, lint, or other debris. Carefully remove any obstructions. If a wheel is damaged, contact customer support for assistance.

Video: Demonstrates the durability of Coolife luggage through various stress tests, including crushing and dropping, highlighting its robust construction.

7. Specifications

Feature	Detail
Product Dimensions	22 x 15 x 9 inches
Item Weight	6.3 pounds
Capacity	38 Liters
Item Model Number	YD000075
Material	ABS+PC Hard Shell
Wheels	360-degree Spinner Wheels
Lock Type	TSA-Approved Combination Lock
Handle	3-Level Adjustable Pure Aluminum Telescopic Handle

8. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact Coolife customer service directly. Refer to the product packaging or the official Coolife website for the most up-to-date contact details.