

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Merax](#) /

› [Merax 270-Degree Power Swivel Recliner Instruction Manual \(Model SG000750AAC-MZJ\)](#)

Merax SG000750AAC-MZJ

Merax 270-Degree Power Swivel Recliner Instruction Manual

Model: SG000750AAC-MZJ

Brand: Merax

1. INTRODUCTION

Thank you for choosing the Merax 270-Degree Power Swivel Recliner. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read these instructions thoroughly before use and retain them for future reference.

2. SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Keep hands and feet clear of moving parts during recline and swivel operations.
- Do not allow children to play on or around the recliner unsupervised.
- Do not exceed the maximum weight capacity of 330 lbs (149 kg).
- Only use the recliner on a stable, level surface.
- Disconnect power before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Recliner Base
- Recliner Backrest
- Power Adapter
- Swivel Tray Table
- Cell Phone Holder
- Assembly Hardware (if applicable)

4. ASSEMBLY INSTRUCTIONS

Assembly is estimated to take approximately 30 minutes. Two people are recommended for easier assembly.

1. Carefully unpack all components and place them on a soft, clean surface to prevent scratches.
2. Attach the backrest to the seat base, ensuring the connection points align and lock securely.
3. Connect the power adapter to the recliner and then to a wall outlet.
4. Insert the swivel tray table and cell phone holder into their designated slots on the armrests.
5. Confirm all connections are stable and secure before initial use.



Image 1: Merax Power Swivel Recliner in extended position, showcasing the blue LED light strip.

Details



Image 2: Detailed view of the recliner's features, including hidden arm storage, two cup holders, USB charging port, and the 360-degree swivel tray table.

5. OPERATING INSTRUCTIONS

5.1 Power Recline Function

The recliner features electric buttons for adjusting the recline position. Locate the control panel on the side of the armrest.

- Press the forward button to recline the chair from 90 degrees (upright) to approximately 160 degrees (fully reclined).
- Press the backward button to return the chair to the upright position.

5.2 270-Degree Swivel Function

The recliner base allows for a 270-degree swivel motion.

- To swivel, gently push off the floor with your feet or use your hands on the armrests to rotate the chair in the desired direction.

270° Swivel

Provide incredible enjoyment



Image 3: The recliner demonstrating its 270-degree swivel capability, highlighted by the base LED lighting.

5.3 LED Light Strip

The recliner features an integrated blue LED light strip at the base.

- The LED light strip can be activated or deactivated via a dedicated button on the control panel.
- This feature provides ambient lighting and helps locate the chair in low-light conditions.



Cell phone stand

The phone holder helps to free up your hands and relax your tired body. You can mount your phone to it in order to watch a movie.



Ambient lighting

This Recliner with blue LED light strips, bring a sense of upscale ambiance for watching movies or relaxing. In addition, you can easily find your seat in the dark.

Image 4: Close-up of the cell phone stand and the ambient blue LED lighting at the base of the recliner.

5.4 Swivel Tray Table and Cell Phone Holder

The integrated accessories enhance convenience.

- The 360-degree swivel tray table can be used for laptops, tablets, or snacks. Adjust its position as needed.
- The cell phone holder provides a hands-free viewing experience. Insert your device into the holder and adjust the angle.

5.5 USB Charging Port

A USB charging port is located on the control panel.

- Connect your USB charging cable to the port to charge compatible electronic devices.

5.6 Hidden Arm Storage

Each armrest features a hidden storage compartment.

- Lift the armrest cover to access the storage space for remotes, books, or other small items.

Your browser does not support the video tag.

Video 1: Demonstration of the Merax Power Swivel Recliner's features, including recline, swivel, LED lighting, and accessory usage.

6. MAINTENANCE

6.1 Cleaning

- **Upholstery:** The PU leather upholstery should be wiped clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Frame:** Wipe the metal frame with a dry cloth.

6.2 General Care

- Regularly check all bolts and screws to ensure they remain tight.
- Avoid exposing the recliner to direct sunlight or extreme temperatures to prevent material degradation.

7. TROUBLESHOOTING

7.1 Recliner Not Operating

- Ensure the power adapter is securely plugged into both the recliner and a working wall outlet.
- Check if the wall outlet is receiving power by testing it with another device.
- Verify that all internal wiring connections are secure (refer to assembly steps if necessary).

7.2 Unusual Noises During Operation

- Ensure the recliner is on a level surface.
- Check for any obstructions around the moving parts of the recline mechanism or swivel base.
- Tighten any loose bolts or screws.

7.3 LED Light Not Functioning

- Ensure the recliner is powered on.
- Press the LED control button to toggle the light on/off.
- Check for any visible damage to the LED strip or its wiring.

8. SPECIFICATIONS

Feature	Detail
Model Name	SG000750AAC-MZJ
Brand	Merax
Upholstery Material	PU Leather (Faux Leather)
Frame Material	Iron + MDF
Seat Construction	Foam + MDF
Leg Material	Metal

Weight Capacity (per seat)	330 lbs (149 kg)
Product Dimensions	31.6"D x 24.49"W x 20.9"H
Reclining Position Count	2 to 5 (90 to 160 degrees)
Swivel Angle	270 Degrees
Special Features	Power Swivel, Hidden Arm Storage, LED Light Strip, Cup Holder, 360-Degree Swivel Tray Table, Cell Phone Holder, USB Charging
Product Care Instructions	Wipe Clean
Assembly Required	Yes (approx. 30 minutes)

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to order replacement parts, please contact Merax customer service. Refer to your purchase documentation for specific contact details and warranty terms.

Please have your model number (SG000750AAC-MZJ) and purchase date available when contacting support.