Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Swann R-SRPRO-4KMSBWB1-US

Swann Spotlight Outdoor Security Camera User Manual

Model: R-SRPRO-4KMSBWB1-US

Brand: Swann

1. Introduction

The Swann Spotlight Outdoor Security Camera is designed to provide reliable outdoor surveillance with its 1080p video recording capabilities, night vision, and Wi-Fi connectivity. Its weatherproof construction ensures durability in various outdoor conditions, making it an ideal solution for monitoring your property. This manual provides essential information for setting up, operating, and maintaining your security camera.



An image showing the white Swann Spotlight Outdoor Security Camera, a bullet-style camera with a black front housing the lens and sensors, mounted on a white wall-mount bracket.

2. Package Contents

Before you begin, please ensure all components are present in your package:

- Swann Spotlight Outdoor Security Camera (1080p)
- Mounting Screws and Wall Plugs
- Power Adapter
- Operating Instructions / Quick Start Guide

3. Setup and Installation

3.1 Planning Installation

Choose a suitable location for your camera. Consider areas that provide a clear view of the desired monitoring zone, are within reliable Wi-Fi range, and have access to a power outlet. Ensure the mounting surface is sturdy enough to support the camera securely.

3.2 Mounting the Camera

1. Mark the drill holes on your chosen surface using the camera's base as a template.
2. Drill pilot holes at the marked positions. If mounting into masonry or drywall, insert the provided wall plugs.
3. Secure the camera base to the surface using the provided screws.
4. Adjust the camera's angle and orientation for optimal viewing coverage.

3.3 Powering On

Connect the power adapter to the camera's power input port, then plug the adapter into a standard electrical outlet. The camera's indicator light will illuminate, signifying it is powered on and initiating its startup sequence.

3.4 App Connection

1. Download the **Swann Security** app from your smartphone's app store (available for iOS and Android).
2. Open the app and follow the on-screen prompts to create a new account or log in to an existing one.
3. Select the option to add a new device. The app will guide you through scanning the QR code located on your camera or manually entering its device ID.
4. Follow the in-app instructions to connect your camera to your home Wi-Fi network. Ensure your Wi-Fi password is correct.
5. Once connected, the camera's status light will change, and you will be able to view the live feed in the app.

4. Operating Your Camera

4.1 Live View

Access the live video feed of your camera anytime, anywhere, through the Swann Security app. This allows for real-time monitoring of your property.

4.2 Motion Detection & Alerts

The camera features motion-only alert capabilities. Configure motion detection settings within the app to customize sensitivity and define specific detection zones. Enable push notifications to receive instant alerts on your smartphone when motion is detected in the monitored area.

4.3 Recording & Playback

Your camera can record video footage. Depending on your setup, footage may be stored on a local microSD card (not included, if applicable) or via cloud storage (subscription may be required). Use the app's playback feature to review

recorded events.

4.4 Night Vision

The camera is equipped with automatic night vision, which activates in low-light conditions. This provides clear black and white video surveillance even in complete darkness.

5. Maintenance

5.1 Cleaning

Periodically clean the camera lens with a soft, lint-free, slightly damp cloth to ensure optimal image clarity. Avoid using harsh chemicals or abrasive materials that could scratch the lens or camera body. Wipe down the camera body to remove dust and debris.

5.2 Firmware Updates

Regularly check for and install firmware updates through the Swann Security app. Firmware updates often include performance improvements, new features, and security enhancements.

5.3 Wi-Fi Connection

Ensure your Wi-Fi network is stable and provides sufficient signal strength to the camera for continuous operation and reliable connectivity.

6. Troubleshooting

6.1 No Power / Camera Not Turning On

- Verify that the power adapter is securely connected to both the camera and a functional electrical outlet.
- Test the outlet with another device to ensure it is supplying power.

6.2 Camera Offline / No Live View in App

- Ensure your home Wi-Fi network is active and the camera is within its effective range.
- Restart your Wi-Fi router and the camera by unplugging and re-plugging their power sources.
- Check the camera's status within the Swann Security app.
- Confirm that the camera's firmware is up to date.

6.3 Poor Image Quality

- Clean the camera lens carefully as described in the Maintenance section.
- Check for any physical obstructions (e.g., spiderwebs, dirt) in the camera's field of view.
- Ensure adequate lighting conditions for optimal daytime performance.

6.4 False Motion Alerts

- Adjust the motion detection sensitivity settings within the Swann Security app.
- Define specific motion detection zones to exclude areas with frequent, non-threatening movement (e.g., trees swaying, distant traffic).

7. Specifications

Feature	Detail
Model Name	R-SRPRO-4KMSBWB1-US

Brand	Swann
Mounting Type	Wall Mount
Video Capture Resolution	1080p
Wireless Communication Technology	Wi-Fi
Item Dimensions (L x W x H)	5.94 x 2.76 x 2.76 inches
Item Weight	8 ounces
Alert Type	Motion Only
Video Capture Format	MPEG-4
Compatible Devices	Smartphone
Connectivity Protocol	HomePlug
Controller Type	Android

8. Warranty and Support

For detailed warranty information, technical support, and customer service, please visit the official Swann website or contact Swann customer support directly. It is recommended to retain your proof of purchase for any warranty claims or service requests.

© 2024 Swann. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHXS6FD1

More documents and user manuals: **https://manuals.plus/**