

Ltinist BX27

Ltinist BX27 Wireless Earbuds User Manual

Model: BX27

1. INTRODUCTION

Thank you for choosing the Ltinist BX27 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.4 connectivity, Environmental Noise Cancelling (ENC) microphones, deep bass, and IP7 waterproof rating, making them ideal for sports, workouts, and daily use. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

2. WHAT'S IN THE BOX

What's in the box?

- ① 1*Ltinist Wireless Earbuds
- ② 3*Eartips(S/M/L)
- ③ 1*Charging Case
- ④ 1*User Manual
- ⑤ 1*Type-C Charging Cable

*Please note that a poweradapter is not included



Image: Components included in the Ltinist BX27 package.

- 2x Wireless Earbuds (Left & Right)
- 1x Type-C Charging Cable
- 1x Charging Case
- 3x Eartips (S/M/L sizes)
- 1x User Manual

Note: A power adapter is not included.

3. PRODUCT OVERVIEW

The Ltinist BX27 earbuds are designed for comfort and performance, featuring an ergonomic design with ear hooks for a secure fit during physical activity. The charging case includes a dual LED digital display to show the remaining power of the case and the charging status of each earbud.



Image: Key features of the Ltinist BX27 Wireless Earbuds.

Key Features:

- **75 Hours Playtime:** Up to 15 hours per earbud on a single charge, with an additional 60 hours from the charging case.
- **Bluetooth 5.4 Technology:** Ensures faster, more stable connections with minimal interference.
- **IP7 Waterproof:** Resistant to sweat, rain, and minor water splashes, suitable for sports.
- **ENC Noise Cancelling Mics:** Provides clear call quality by isolating your voice from ambient noise.
- **Deep Bass & Hi-Fi Sound:** 14.2mm double-layer diaphragm drivers deliver rich audio with strong bass.
- **Touch Control:** Intuitive touch area for managing music, calls, and voice assistant.
- **Ergonomic Design:** Flexible ear hooks and lightweight build (only 4g per earbud) for comfortable and secure fit.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features a dual LED digital display to indicate the remaining power of the case and the charging status of each earbud.




Image: Battery life and charging display indicators.

- Place the earbuds into the charging case. Ensure they are properly seated.
- Connect the Type-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
- The LED display on the case will show the charging progress.
- A full charge for the earbuds takes approximately 1.5 hours, and the charging case takes about 2 hours.

4.2 Pairing with Your Device

The Ltinist BX27 earbuds support one-step auto pairing for convenient and fast connection.



ONE-STEP AUTO PAIRING

It only takes two steps to establish a link with "BX27". Open the headphone box and take out the Bluetooth headset. Search for Bluetooth devices on your phone and click "BX27"

Image: Auto pairing process.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
3. Select "BX27" from the list of found devices to connect.
4. Once successfully paired, the earbuds will automatically reconnect to your device when taken out of the case, provided Bluetooth is enabled on your device.

The connection range between the earbuds and your device is approximately 48 feet (14.63 meters).

5. OPERATING INSTRUCTIONS

5.1 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct ear tip size (S/M/L) and adjust the ear hooks for a secure fit.

COMFY&SECURE FIT FOR SPORT



Image: Guide to wearing the earbuds.

1. Select the ear tips that provide the best seal and comfort for your ears.
2. Place the ear hooks over your ears.
3. Gently insert the earbud into your ear canal and rotate it to find a comfortable and secure angle.

5.2 Touch Controls

The earbuds feature sensitive touch areas for easy control of various functions.



Action	Left Earbud (L)	Right Earbud (R)	Both (R/L)
Volume Control	Hold for 2S (Volume Down)	Hold for 2S (Volume Up)	
Play/Pause			Click Twice
Next Track		Click Once	
Previous Track	Click Once		
Answer/End Call			Click Once
Reject Call			Hold for 2S
Activate Voice Assistant			Click Three Times

6. MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they can resist sweat, rain, and minor water splashes. Do not submerge them in water or expose them to high-pressure water jets. Dry them thoroughly after exposure to moisture.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.

7. TROUBLESHOOTING

Common Issues and Solutions:

- **Earbuds not pairing:**
 - Ensure both earbuds are charged.
 - Turn off Bluetooth on your device, then turn it back on.
 - Forget/delete "BX27" from your device's Bluetooth list and try pairing again.
 - Place earbuds back in the case, close the lid, wait a few seconds, then open to re-initiate pairing mode.
- **Only one earbud working:**
 - Ensure both earbuds are charged.
 - Place both earbuds back into the charging case, close the lid, and then take them out again.
 - Try resetting the earbuds (refer to specific reset instructions if available in a full manual, typically involves holding touch areas while in case).
- **Poor sound quality or disconnections:**
 - Ensure the earbuds are within the 48-foot Bluetooth range of your device.
 - Check for interference from other wireless devices.
 - Clean the ear tips and earbud mesh to ensure no obstructions.
 - Ensure the earbuds are fully charged.

- **Earbuds not charging:**
 - Ensure the charging cable is securely connected to both the case and the power source.
 - Check if the charging case itself has power.
 - Clean the charging contacts on both the earbuds and inside the case.

8. SPECIFICATIONS

Feature	Detail
Model Name	BX27
Connectivity Technology	Wireless (Bluetooth 5.4)
Earbud Playtime (Single Charge)	Up to 15 Hours
Total Playtime (with Charging Case)	Up to 75 Hours
Charging Time (Earbuds)	Approx. 1.5 Hours
Charging Time (Case)	Approx. 2 Hours
Water Resistance Level	IP7 Waterproof
Audio Driver Size	14.2 mm
Frequency Range	20 Hz - 20,000 Hz
Control Type	Touch Control
Ear Placement	Over Ear
Item Weight	4.9 ounces (0.14 Kilograms)
Manufacturer	Ltinist

9. WARRANTY & SUPPORT

Ltinist products typically come with a 2-year warranty. For any product inquiries, technical support, or warranty claims, please refer to the contact information provided in your product packaging or visit the official Ltinist website. You can also find additional support and resources through the Amazon product page or by contacting Amazon customer service. For a digital copy of the user manual, you may refer to the PDF document available at[Ltinist BX27 User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question