

Asustor AS1102TL

Asustor Drivestor 2 Lite AS1102TL 2-Bay NAS Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your Asustor Drivestor 2 Lite AS1102TL 2-Bay Network Attached Storage (NAS) device. Please read this manual thoroughly before using the product to ensure proper setup and functionality. The Asustor Drivestor 2 Lite AS1102TL is designed for personal private cloud storage and backup solutions for home and small office environments.

SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the device or injury to yourself:

- Ensure the device is placed on a stable, flat surface to prevent it from falling.
- Do not expose the device to water, moisture, or extreme temperatures.
- Use only the power adapter provided with the device.
- Do not block ventilation openings. Ensure adequate airflow around the device.
- Disconnect the power cable before performing any maintenance or installation procedures.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.

PACKAGE CONTENTS

Verify that all items listed below are included in your product package:

- Asustor Drivestor 2 Lite AS1102TL Unit x1
- Quick Installation Guide x1
- AC Power Cord x1
- AC Power Adapter x1
- RJ-45 LAN Cable (Cat 5e) x1
- Thumb Screws (for 3.5" HDD) x8



Image: Contents of the Asustor Drivestor 2 Lite AS1102TL package, showing the NAS unit, power cord, adapter, LAN cable, and HDD screws.

PRODUCT OVERVIEW

Familiarize yourself with the physical components of your Asustor Drivestor 2 Lite AS1102TL NAS.

Front Panel



Image: Front view of the Asustor Drivestor 2 Lite AS1102TL, highlighting the power button, LED indicators for power, system status, network, and disk activity, and a front USB 3.2 Gen 1 port.

- **Power LED:** Indicates power status.
- **System Status LED:** Indicates system operational status.

- **Network LED:** Indicates network activity.
- **Hard Drive LED:** Indicates hard drive activity.
- **Power Button:** To power on/off the device.
- **USB 3.2 Gen 1 Port:** For connecting external USB devices.

Rear Panel



Image: Rear view of the Asustor Drivestor 2 Lite AS1102TL, showing the exhaust fan, reset button, USB 2.0 port, Gigabit Ethernet port, DC input, and K-Lock security slot.

- **Exhaust Fan:** For cooling the system.
- **Reset Button:** To reset the device (use a paperclip).
- **USB 2.0 Port:** For connecting external USB devices.
- **Gigabit Ethernet Port:** For network connection.
- **DC Input:** For connecting the power adapter.
- **K-Lock:** Kensington security slot.

SETUP

1. Hard Drive Installation

The Asustor Drivestor 2 Lite AS1102TL supports two 3.5-inch SATA hard disk drives (HDDs). Follow these steps for tool-free installation:

1. Gently slide open the NAS cover.
2. Insert the 3.5-inch HDDs into the drive bays. Ensure they are securely seated.
3. Secure the HDDs using the provided thumb screws.
4. Slide the NAS cover back into place until it clicks.



Image: Step-by-step guide for installing 3.5-inch hard drives into the Asustor Drivestor 2 Lite AS1102TL without tools.

2. Initial Network Connection

1. Connect one end of the RJ-45 LAN cable to the Gigabit Ethernet port on the rear of the NAS.
2. Connect the other end of the LAN cable to your router or network switch.
3. Connect the AC power adapter to the DC input port on the NAS, then plug the power cord into an electrical outlet.
4. Press the power button on the front panel to turn on the NAS.

3. Software Installation and Initialization

Once the hardware is set up and powered on, you will need to initialize the NAS and install the operating system (ADM). You can do this using the Asustor Control Center utility or by accessing the NAS via a web browser.

1. Download and install the Asustor Control Center utility from the official Asustor website on a computer connected to the same network.
2. Launch the Control Center. It will automatically detect your NAS.
3. Follow the on-screen instructions to initialize the NAS, create a storage volume, and install the ADM (Asustor Data Master) operating system. This process typically involves setting up an administrator password and network settings.
4. Alternatively, you can find the NAS IP address from your router's DHCP client list and access it directly via a web browser (e.g., [http://\[NAS_IP_ADDRESS\]:8000](http://[NAS_IP_ADDRESS]:8000)).



Image: Illustration of the initial setup process using a mobile device, showing steps from detection to successful configuration.


OPERATING THE NAS

The Asustor Drivestor 2 Lite AS1102TL offers various functionalities for data management, multimedia, and backup.

Basic File Access and Management

After initial setup, you can access your NAS files through network shares on your computer or via Asustor's mobile apps.

- **Network Shares:** Map network drives on Windows, macOS, or Linux to access shared folders directly.
- **File Explorer (ADM):** Use the web-based File Explorer within the ADM interface for file management.
- **Mobile Apps:** Download Asustor's AiData app for mobile access to your files.



Plug and Play

Simple, intuitive and easy to use

Image: A user interacting with a smartphone, demonstrating the ease of use and 'plug and play' nature of the Asustor NAS for quick access.

Cross-Platform Multi-User Access

The NAS supports multiple users and various operating systems, allowing seamless data sharing across different devices.

Cross-Platform Multi-User Access




Image: Various devices (desktop, laptop, tablet, smartphone) connected to the Asustor NAS, showcasing its capability for cross-platform and multi-user file access.

Photo Management

Organize and manage your photo collection with dedicated applications. The NAS allows for easy upload, browsing, and sharing of photos.



Image: Displays of photo management interfaces on mobile and desktop, demonstrating how the Asustor NAS facilitates easy organization and access to personal photo libraries.

Multimedia Center

Transform your NAS into a home multimedia hub. Stream videos, music, and photos to various devices.

- **4K Transcoding:** The Realtek RTD1619B processor supports 4K transcoding, allowing you to stream high-resolution content smoothly to devices that may not natively support the original format.
- **App Support:** Install multimedia applications like LooksGood, Plex, or Emby from the App Central to enhance your media experience.




Image: A home entertainment setup featuring a television displaying a media library interface, with the Asustor NAS acting as the central media server, supporting applications like Plex and Emby.

Data Protection and Backup

Utilize the NAS for robust data backup and recovery solutions.

- **Btrfs/iSCSI Snapshots:** Create snapshots of your data volumes to protect against accidental deletion, ransomware, or data corruption. Snapshots allow for quick restoration to previous states.
- **Backup Solutions:** Configure various backup tasks, including local backup, remote backup, cloud backup, and synchronization with public cloud services.



Image: A graphical representation on a computer screen demonstrating the Btrfs snapshot feature, showing how multiple recovery points can be managed for data protection.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your NAS.

- **Firmware Updates:** Regularly check for and install ADM firmware updates via the ADM interface to ensure your system has the latest features, security patches, and bug fixes.
- **Disk Health Checks:** Periodically run S.M.A.R.T. tests on your hard drives through the Storage Manager in ADM to monitor their health and predict potential failures.
- **Cleaning:** Keep the NAS unit clean and free of dust. Use a soft, dry cloth to wipe the exterior. Ensure the ventilation fan and vents are not obstructed by dust buildup.
- **Power Management:** Configure power-saving features like hard drive hibernation and system sleep mode to reduce power consumption and extend drive lifespan. The device supports Wake on LAN (WOL).

TROUBLESHOOTING

This section addresses common issues you might encounter with your Asustor Drivestor 2 Lite AS1102TL.

Problem	Possible Cause	Solution
NAS does not power on.	Power cable disconnected; faulty power adapter; power button issue.	Check power cable connections. Ensure the power adapter is working. Try a different power outlet.

Problem	Possible Cause	Solution
Cannot find NAS on the network.	Network cable disconnected; incorrect network settings; firewall blocking.	Verify LAN cable connection. Restart your router. Check your computer's firewall settings. Use Asustor Control Center to locate the NAS.
Hard drives not detected.	Drives not properly seated; faulty drives.	Ensure drives are fully inserted into the bays. Test drives individually if possible.
Slow transfer speeds.	Network congestion; faulty network cable; drive performance issues.	Check network cable (use Cat 5e or higher). Reduce network traffic. Check drive health in ADM.
Forgot ADM password.	Password lost.	Use the reset button on the rear panel (press for 3 seconds) to reset network settings and administrator password without affecting data.

SPECIFICATIONS

Key technical specifications for the Asustor Drivestor 2 Lite AS1102TL:

- **Model:** AS1102TL
- **CPU:** Realtek RTD1619B 1.7GHz Quad-Core Processor
- **RAM:** 1GB DDR4
- **Flash Memory:** 4GB eMMC
- **Drive Bays:** 2 x 3.5" SATA HDD/SSD
- **Network:** 1 x Gigabit Ethernet Port
- **USB Ports:** 1 x USB 3.2 Gen 1 (Front), 1 x USB 2.0 (Rear)
- **Dimensions (HxWxD):** 165 x 102 x 218 mm (6.5 x 4.01 x 8.58 inches)
- **Weight:** 1.86 kg (4.11 lbs)
- **Material:** Metal
- **Power Consumption:** Varies with usage and drive configuration.
- **Operating System:** ASUSTOR Data Master (ADM)



Image: Visual representation of the Realtek RTD1619B Quad Core 1.7GHz processor, highlighting its capabilities for 4K transcoding, Gigabit Ethernet, and 1GB DDR4 RAM.

WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included in your product package or visit the official Asustor website. Technical support is available through the Asustor support portal, where you can find FAQs, knowledge base articles, and contact information for customer service.

Asustor Official Website: www.asustor.com

Related Documents - AS1102TL



[ASUSTOR AS7212RDX/AS7216RDX Quick Installation Guide](#)

This guide provides essential steps for the quick installation of ASUSTOR AS7212RDX and AS7216RDX Network Attached Storage (NAS) devices, covering hardware setup, initial configuration, and basic troubleshooting.

	<p>ASUSTOR AS5004U Quick Installation Guide</p> <p>Step-by-step guide for installing and setting up the ASUSTOR AS5004U NAS expansion unit, including hardware installation, connections, and LED indicator information.</p>
	<p>ASUSTOR AS7212RDX / AS7216RDX Schnell-Installationsanleitung</p> <p>Diese Schnell-Installationsanleitung führt Sie durch die Einrichtung Ihrer ASUSTOR AS7212RDX und AS7216RDX NAS-Geräte. Erfahren Sie, wie Sie Hardware installieren, Software konfigurieren und Ihr System in Betrieb nehmen.</p>
	<p>ASUSTOR AS5402T / AS5404T Quick Installation Guide</p> <p>This guide provides instructions for the quick installation of ASUSTOR AS5402T and AS5404T NAS devices, covering hardware setup, software installation, and basic troubleshooting.</p>
	<p>ASUSTOR FS6806X/FS6812X Quick Installation Guide</p> <p>A comprehensive guide for the quick installation and setup of ASUSTOR FS6806X and FS6812X Network Attached Storage (NAS) devices, covering hardware installation, software configuration, and basic troubleshooting.</p>
	<p>ASUSTOR AS-T10G3 10-Gigabit Ethernet Card Quick Installation Guide</p> <p>This guide provides step-by-step instructions for installing the ASUSTOR AS-T10G3 10-Gigabit Ethernet expansion card into ASUSTOR NAS devices, including models from the AS67, AS65R, and AS71R series. It covers package contents, necessary tools, installation procedures, and basic troubleshooting.</p>


Documents - Asustor – AS1102TL



[\[pdf\] Installation Guide Guide Accessories](#)

ASUSTOR AS1102TL QIG Microsoft Office User ENU 4230818 20230512 gb asustor docs ||| ||| Quick Installation Guide Applicable I AS1102TL Ver.2.3.0903 2015-3-2 Ver. 4.2.3.0818 Table of Contents NOTICES . 3 SAFETY PRECAUTIONS 4 1. PACKAGE CONTI 2. OPTIONAL ACCESSORIES . 6 3. HARDWARE INSTALLATION GUIDE . 7 TOOLS NEEDE Quick Installation Guide Applicable Models: **AS1102TL** Ver.2.3.0903 2015-3-2 Ver. 4.2.3.0818 Table of Con NOTICES..... 3 SAFETY PRE...

lang:i-klngon score:50 filesize: 1.14 M page_count: 22 document date: 2023-08-30



[\[pdf\]](#)

ASUSTOR AS1102TL QIG Microsoft Office User TRK 4230818 gb asustor docs |||

Hızlı Kurulum Kılavuzu Uygulanabilir Modeller: **AS1102TL** VVeer.2r..34.0.920.33 .2008115-83-2 indekiler
UYARILAR.....

3 GVENLIK NLEMLERİ

lang:i-klngon score:40 filesize: 1.2 M page_count: 21 document date: 2023-09-01



[\[pdf\]](#)


ASUSTOR AS1102TL QIG Microsoft Office User ESP 4230818 20230512 gb asustor docs |||

Gua de instalacin rpida Modelos aplicables: **AS1102TL** Ver.2.3.0903 2015-3-2 Ver. 4.2.3.0818 ndice

AVISOS.....

3 MEDIDAS DE SEGURIDAD....

lang:i-klngon score:39 filesize: 1.21 M page_count: 21 document date: 2023-08-30



[\[pdf\]](#) Installation Guide Guide

ASUSTOR AS1102TL QIG Microsoft Office User Instrukcja obsługi Asustor Drivestor 2 Lite Gb LAN 90 AS1102TL0 MA30 od PLN 9i
2024 Porównanie cen Cenowarka Polska ab3628b89467d8710a7879b3556673633745 gzhls at blob ldb 7 9 0 |||

Quick Installation Guide Jednostka **AS1102TL** Ver.2.3.0903 2015-3-2 Ver. 4.2.3.0818 Spis treści ANONSE

..... 3

ZASADY BEZPIECZESTWA

lang:i-klngon score:35 filesize: 1.2 M page_count: 21 document date: 2023-08-30



[\[pdf\]](#)

ASUSTOR AS1102TL QIG Microsoft Office User Instrukcja obsługi Asustor Drivestor 2 Lite Gb LAN 90 AS1102TL0 MA30 od PLN 9i
2024 Porównanie cen Cenowarka Polska fc68e26b85fdcf01bab10c25b6e5b08472e0 gzhls at blob ldb 3 e 5 8 |||

Schnell-Installationsanleitung Eingesetzte Modelle: **AS1102TL** Ver.2.3.0903 2015-3-2 Ver. 4.2.3.0818 Inhalt

HINWEISE.....

3 SICHERHEITSHIN...

lang:i-klngon score:35 filesize: 1.18 M page_count: 21 document date: 2023-08-30



[pdf] User Manual Datasheet

ASUSTOR Datasheet Arno Doncks Fotos hochauflösend speichern können Und über ASUSTORs App Central Unterstützung von O Business Google Drive Dropbox ASUS AS1102TL DB DE cdn reichelt de documents datenblatt E910 ||| https://www.asustor.com/de/ Das beste Preis-Leistungs-Verhältnis AS1102TL Ausgestattet mit Realtek RTD- 1.7GHz Quad-Core Prozessor 1 GB DDR4-RAM Hohe Leistung, 4K-Decodierung Unterstützt Wake on LAN 1 Btrfs/iSCSI Snapshots Werkzeuglose Montage https://docs.google.com/spreadsheets/d/1MfY... lang:de score:31 filesize: 4.18 M page_count: 26 document date: 2024-02-09

[pdf] Quick Start Guide Guide

LEON HandleidingAsustor DRIVESTOR 4 Pro Gen2 AS3304T v2 Coolblue NASv1manuals coolblue be de asustor drivestor pro gen as3304t HandleidingHandleidingAsustor NASAsustor FLASHSTOR 6 FS6706T NASv1v1manuals v2manuals flashstor fd6706t HandleidingHandleidingHandleidingAsustor 12 FS6712X NASv1v1v1manuals fd6706tmanuals fd6712x HandleidingHandleidingHandleidingHandleidingAsustor 2 AS3302T NASv1v1v1v1manuals fd6712xmanuals lite as1102tl HandleidingHandleidingHandleidingHandleidingManualAsustor NASASUSTOR NASv1v1v1v1v1manuals as1102tlmanuals nl ||| ||| U: Guide For Network Attached Storage Ver. 4.0.0.0304 For ADM 4.0 1 Introduction 5 Getting Started with ASUSTOR Data Master ADM Installing ASUSTOR NAS and ADM 8 Logging in to ASUSTOR Data Master . 8 Taskbar . 9 Pre-Installed Apps .16 ||| User Guide For Attached Storage Ver. 4.0.0.0304 For ADM 4.0 1 Introduction 5 Getting Started with ASUSTOR Data Master ADM . 8 Installing ASU: NAS and ADM 8 Logging in to ASUSTOR Data Master . 8 Taskbar . 9 Pre-Installed Apps .16 ||| User Guide For Network Attached St Ver. 4.0.0.0304 For ADM 4.0 1 Introduction 5 Getting Started with ASUSTOR Data Master ADM . 8 Installing ASUSTOR NAS and AI Logging in to ASUSTOR Data Master . 8 Taskbar . 9 Pre-Installed Apps .16 ||| User Guide For Network Attached Storage Ver. 4.0.0. ADM 4.0 1 Introduction 5 Getting Started with ASUSTOR Data Master ADM . 8 Installing ASUSTOR NAS and ADM 8 Logging in to ASUSTOR Data Master . 8 Taskbar . 9 Pre-Installed Apps .16 User Guide For Network Attached Storage Ver. 4.0.0.0304 For ADM 4.0 1 Introduction 5 Getting Started with ASUST Data Master ADM lang:nl score:29 filesize: 9.25 M page_count: 153 document date: 2021-06-07




[pdf] Datasheet

ASUSTOR Datasheet Arno Doncks product id 69 android app Page 14 Use your wireless network to videos on NAS phone or tablet AS50 51 30 AS33 25 AS31 32 ASUS AS1102TL DB EN cdn reichelt de documents datenblatt E910 ||| https://www.asustor.com/en/ It s the Little NAS That Can AS1102TL Equipped with Realtek RTD1619B 1.7C quad-core processor 1 GB DDR4 RAM Enjoy, download, upload and stream content with 4K transcoding. S Wake on LAN WOL Btrfs/iSCSI Snapshots Tool-free installation https://docs.google... lang:en score:29 filesize: 4.17 M page_count: 23 document date: 2024-02-09

[pdf] Datasheet Warranty Catalog

Datasheet Drivestor 2 Lite AS1102TL ENG προϊόντοςAsustor NAS Tower με θέσεις για HDD AS1102TLba43e02e48c79a627eede001ae87f61e DatasheetDrivestor LiteAS1102TLENGt support gr image catalog ba43e02e48c79a627eede001ae87f61e LiteAS1102TLENG inline true ||| AS1102TL It s the Little NAS That Can Realtek RTD1619B Quad-Core CPU 1GB DDR4 RAM 1x USB 3.2 C port Enjoy, download, upload and stream content with 4K transcoding Btrfs/iSCSI Snapshots Supports Wak LAN Realtek Quad-Core 2x 3.5 SATA HDD Gigabit Ethernet 1 GB DDR4 1 x USB 3.2 Gen1x1 1 x... lang:en score:28 filesize: 2.66 M page_count: 5 document date: 2023-10-03






[pdf] Datasheet

Datasheet ADM5 0 CS5 CHT source 20250212 Asustor FS6806X New FLASHSTOR 12 Pro Gen2 FS6812X AMD Ryzer 2 3GHz 3 8GHz 16GB SO DIMM ECC DDR5 4800 64GB 12x M 2 asustor materials datasheet ||| ASUSTOR Data Master ADM 5.0 ADM 5.0 ADM ADM ADM Defender ADM Defender IP NAS Ap ... usic NA AiSecure AiSecure Email M.2 xx LED LCD DRIVESTOR 2 Lite **AS1102TL** Realtek RTD1619B 1.7 GHz 1Gf 2x 3.5 SATA III - 1 x USB 3.2 Gen1x1; 1 x USB 2.0 1 ... lang:en score:26 filesize: 5.15 M page_count: 8 document date: 2025-02-13



[pdf] Datasheet Borchure

ASUSTOR Datasheet Télécharger le fichier Serveur NAS Asustor Drivestor 2 Lite AS 1102TL baies Noir à prix bas brochure comme pour asustor as 1102tl 12169 1fodiscount ressources site document product ||| https://www.asustor.com/fr/ Grande Valeur, Grande Performance **AS1102TL** quip du processeur quad-core Realtek RTD1619B 1,7 GHz 1 Go de RAM DDR4 Profitez, tchargez, chargez et diffusez du contenu avec le transcodage 4K Prlse en charge de Wake on LAN WOL Btrfs/iSCSI Snapshots Installation san... lang:fr score:25 filesize: 10.61 M page_count: 56 document date: 2024-07-26



[pdf] Datasheet Warranty

Store more in a flash! Asustor 2 days ago — Bluetooth Dongle Speaker Support USB Printer DAC IR Receiver Supports iOS Remot · Plex Media Server is currently well Datasheet ADM4 3 Global ENG asustor materials datasheet ||| Store more in a flash Performance King Boundless Functionality Intuitive UI Incredible Value W ... your pers property. Hardware Specifications Personal to Home New New New DRIVESTOR 2 Lite **AS1102TL** Proces: Realtek RTD1619B 1.7 GHz Quad-Core Processor Memory 1GB DDR4 non-upgradeable... lang:en score:24 filesize: 1.27 M page_count: 8 document date: 0000-00-00



[pdf] Datasheet

Datasheet ADM5 0 Global ENG ESP Asustor FS6806X New FLASHSTOR 12 Pro Gen2 FS6812X AMD Ryzen V3C14 Quad Core 2 up to 8 16GB ECC DDR5 4800 SO DIMM Expandable max 64GB 12x asustor materials datasheet ||| Ms que solo almacenamiento Descubra lo extraordinario con ASUSTOR Performance King Funcionalidad s vigilar sus bienes personales. Especificaciones del hardware Personal to Home DRIVESTOR 2 Lite **AS1102TL** Processor Realtek RTD1619B 1.7 GHz Quad-Core Processor Memory 1GB DDR4 non-upgradeable... lang:es score:24 filesize: 2.89 M page_count: 8 document date: 2025-03-28



[\[pdf\] Datasheet Warranty](#)

Datasheet ADM5 ENG More Than Just Storage Discover the Extraordinary with ASUSTOR2 daughterboard 185 5x233x230 mm 4 6 14lb 250W 45W 20W 2 3W Single Pro G1 G2 Flashstor series Firewall Helps Prevent Unauthorized Datasheet US 202508asustor m datasheet 202508 |||

More Than Just Storage Discover the Extraordinary with ASUSTOR Performance King Boundless Function watch over your personal property. Hardware Specifications Personal to Home DRIVESTOR 2 Lite **AS1102** Processor Realtek RTD1619B 1.7 GHz Quad-Core Processor Memory 1GB DDR4 non-upgradeable... lang:en score:16 filesize: 4.6 M page_count: 8 document date: 2025-08-13

[Computer Storage Devices Price List - SSDs, HDDs, NAS, SD Cards](#)

Comprehensive price list and specifications for a wide range of computer storage devices including SSDs, H-NAS systems, SD cards, and USB drives from leading brands like SanDisk, Samsung, Kioxia, Seagate, WD more. Find capacities, speeds, and pricing.

lang:es score:15 filesize: 2.52 M page_count: 2 document date: 2025-09-28

[Global Cybermind Accessories Pricelist - Storage Solutions](#)

Comprehensive pricelist for various storage solutions including Micro SD cards, SD cards, USB flash drives, portable SSDs from brands like SanDisk, Kioxia, Transcend, Seagate, Crucial, Kingston, and more. Also inc NAS devices from Synology, Asustor, and QNAP, along with internal and external hard drives.

lang:es score:14 filesize: 2.43 M page_count: 2 document date: 2025-07-22

[Global Cybermind Technologies Pte Ltd - Storage Device Price List](#)

A comprehensive price list for various storage devices including Micro SD cards, SD cards, USB flash drive, portable SSDs, external drives, NAS devices, and internal HDDs from leading brands like Lexar, Kioxia, Sar Samsung, Transcend, Seagate, WD, Asustor, QNAP, and Toshiba, distributed by Global Cybermind Techn Pte Ltd.

lang:es score:14 filesize: 2.43 M page_count: 2 document date: 2025-08-13

[\[pdf\]](#) Safety Datasheet Accessories

Accessories Pricelist JULY.xlsx ACC 2 cdn files myshopline file store 1699507075863 |||

Global Cybermind Technologies Pte Ltd 1 Rochor Canal Road, #04-24/25/48, Sim Lim Square, Singapore 1 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 759 AS5402T 649 A...

lang:es score:14 filesize: 2.42 M page_count: 2 document date: 2024-07-26

[\[pdf\]](#) Safety Datasheet Accessories

Accessories Pricelist JANUARY.xlsx ACC 20 cdn files myshopline file store 1699507075863 |||

Global Cybermind Technologies Pte Ltd 1 Rochor Canal Road, #04-24/25/48, Sim Lim Square, Singapore 1 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 599 AS5402T 649 A...

lang:es score:14 filesize: 2.42 M page_count: 2 document date: 2025-01-09

[\[pdf\]](#) Safety Datasheet Accessories

Accessories Pricelist SEPTEMBER.xlsx ACC 7 cdn files myshopline file store 1699507075863 |||

Global Cybermind Technologies Pte Ltd 1 Rochor Canal Road, #04-24/25/48, Sim Lim Square, Singapore 1 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 759 AS5402T 649 A...

lang:es score:14 filesize: 2.48 M page_count: 2 document date: 2024-09-04

[\[pdf\]](#) Safety Datasheet Accessories

Accessories Pricelist AUGUST xlsx ACC 4 cdn files myshopline file store 1699507075863 |||

Global Cybermind Technologies Pte Ltd 1 Rochor Canel Road, #04-24/25/48, Sim Lim Square, Singapore 1 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 759 AS5402T 649 A...

lang:es score:14 filesize: 2.43 M page_count: 2 document date: 2024-08-16

[\[pdf\]](#) Safety Datasheet Accessories

Casher Samsung Evo Micro SD Card Kioxia Exceria Plus Read 100 Write 85 High Endurance 100 Accessories Pricelist MARCH cdn myshopline file store 1699507075863 |||

Global Cybermind Technologies Pte Ltd 1 Rochor Canel Road, #04-24/25/48, Sim Lim Square, Singapore 1 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 599 AS5402T 649 A...

lang:es score:14 filesize: 805.47 K page_count: 2 document date: 2025-03-08

[\[pdf\]](#) Safety Datasheet Accessories

Accessories Pricelist NOVEMBER xlsx Kioxia Exceria High 6 80 8 50 Plus 32GB USB2 0 20 00 64GB 17 70 13 60 128GB 22 Micro : ACC 15 cdn files myshopline file store 1699507075863 |||

Global Cybermind Technologies Pte Ltd 1 Rochor Canel Road, #04-24/25/48, Sim Lim Square, Singapore 1 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 599 AS5402T 649 A...

lang:es score:14 filesize: 2.42 M page_count: 2 document date: 2024-11-01

Model	AS3302T v2	AS3304T v2	AS3302T	AS3304T	AS5202T	AS5304T	AS5402T	AS6402T
Processor	Intel Core i3-12100	Intel Core i5-12400						
Memory	16GB DDR5	32GB DDR5						
Storage	1TB NVMe	2TB NVMe						
Graphics	Intel Arc A750							
OS	Windows 11							

[pdf] Safety Datasheet Accessories

Accessories Pricelist FEBRUARY.xlsx ACC 21cdn files myshopline file store 1699507075863 21 |||
 Global Cybermind Technologies Pte Ltd 1 Rochor Canal Road, #04-24/25/48, Sim Lim Square, Singapore 1
 DS723 749 DS923 849 DS1522 1099 DS1621 1369 DS1821 1509 Asustor Standalone **AS1102TL** 299 AS1
 459 AS3302T 409 AS3304T 559 AS5202T 499 AS5304T 599 AS5402T 649 A...
 lang:es score:14 filesize: 2.42 M page_count: 2 document date: 2025-02-12

Model	AS1102TL	AS1104T	AS1104T Pro Gen2	AS1104T Pro Gen2
Processor	AMD Ryzen V3C14	AMD Ryzen V3C14	AMD Ryzen V3C14	AMD Ryzen V3C14
Memory	16GB DDR4	16GB DDR4	16GB DDR4	16GB DDR4
Storage	1TB NVMe	1TB NVMe	1TB NVMe	1TB NVMe
Graphics	Realtek RTD1916B	Realtek RTD1916B	Realtek RTD1916B	Realtek RTD1916B
OS	Windows 11	Windows 11	Windows 11	Windows 11

[pdf] Datasheet

2024 All Product Comparison CHT Model Asustor FS6806X 6x M 2 PCIe NVMe M 2280 1x 10 Gigabit Single JBOD RAID 0 1 5 6
 Drive AMD Ryzen V3C14 3GHz asustor materials datasheet |||
 Model M.2 xx LED LCD DRIVESTOR 2 Lite **AS1102TL** Realtek RTD1916B 1.7 GHz 1GB DDR4 2x 3 SATA
 DRIVESTOR 4 AS1104T Realtek RTD1296 1.4 GHz 1GB DDR4 4x 3 SATA III DRIVESTOR 2 Pro Gen2
 DRIVESTOR 4 Pro Gen2 AS3302T v2 AS3304T v2 Realtek RTD1916B 1.7 GHz 2GB DDR4 ...
 lang:nl score:14 filesize: 575.89 K page_count: 7 document date: 2024-11-22

asustor

EU Declaration of Conformity

We, the undersigned,
 Mr. Johnny Chen
 17, No. 236, Street 10, Singapore 410231, Singapore

Declare the following apparatus:
 Model Name: **AS1102TL, AS1104T v2, AS1104T Pro Gen2**

The above-mentioned apparatus conforms to the following CE marking:
 EMC Directive 2014/53/EU until April 19th, 2016 and Directive 2014/30/EU from April 20th, 2016
 CE marking: **EMC**
 EMC Directive 2014/53/EU until April 19th, 2016 and Directive 2014/30/EU from April 20th, 2016
 CE marking: **EMC**
 EMC Directive 2014/53/EU until April 19th, 2016 and Directive 2014/30/EU from April 20th, 2016
 CE marking: **EMC**

CE

Signature: *Johnny Chen* Place of Issue: Singapore
 Printed Name: Johnny Chen Original Declaration Date: September 18, 2023
 Position: President Year to begin affixing CE marking: 2024

[pdf] Declaration of Conformity

AS1102TL AS3302T v2 AS3304T EU Declaration of Conformity JohnnyChen Декларация за съответствие Asustor Мрежови диск
 ниска цена от JAR Computers 1705628718 jarcomputers images custom docs |||
 EMC Directive 2004/108/EC until April 19th, 2016 and Directive 2014/30/EU from April 20th, 2016 AB 2023
 lang:nl score:12 filesize: 821.47 K page_count: 1 document date: 2023-08-10