

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [COKUNST](#) /

> [COKUNST Y3 Electric Salt and Pepper Grinder User Manual](#)

COKUNST Y3

COKUNST Y3 Electric Salt and Pepper Grinder User Manual

Model: Y3

1. INTRODUCTION

Thank you for choosing the COKUNST Y3 Electric Salt and Pepper Grinder. This manual provides essential information for the safe and efficient operation of your new appliance. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Keep the appliance out of reach of children.
- Do not immerse the main body of the grinder in water or other liquids.
- Use only dry spices such as peppercorns, sea salt, or other similar dry granular spices. Do not use wet spices or herbs.
- Ensure the charging port is dry before connecting the USB cable.
- Do not attempt to disassemble or repair the grinder yourself. Contact customer support if issues arise.
- Avoid contact with moving parts during operation.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x COKUNST Y3 Electric Grinder
- 1 x USB Type-C Charging Cable
- 1 x User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your COKUNST Y3 Electric Grinder:

- **Transparent Visual Bin:** Holds up to 4 oz (120 ml) of spices, allowing you to monitor content levels.
- **One-Button Switch:** Activates the grinding mechanism.

- **Visual Power Reminder:** Four blue LED indicators display the battery level.
- **USB Type-C Charging Port:** Hidden port for convenient recharging.
- **Adjustable Coarseness Knob:** Located at the bottom for selecting grind size.
- **Suction Dust Cover:** Protects the grinding outlet and prevents condiment spread.



Image: Overview of the COKUNST Y3 Electric Grinder, highlighting its key features like the visual power reminder, one-button switch, and USB charging port.

40z Large Capacity Visual Bin Pepper Mill



Image: The COKUNST Y3 Electric Grinder with its dimensions (7.7 inches height, 2.3 inches diameter) and the 4 oz (120 ml) visual bin capacity.

5. SETUP

5.1 Filling the Grinder

1. Unscrew the transparent visual bin from the main body of the grinder by twisting it counter-clockwise.
2. Fill the bin with your desired dry spices (e.g., peppercorns, salt crystals). Do not overfill.
3. Screw the visual bin back onto the main body by twisting it clockwise until secure.




Image: A hand demonstrating how to unscrew the transparent bin from the grinder's main body.



Image: A hand filling the transparent bin with peppercorns using a spoon.

5.2 Charging the Device

The grinder is equipped with a USB Type-C charging port. The four blue LED indicators will show the battery level. When the battery is low, the indicators will flash or fewer lights will be illuminated.

1. Locate the hidden Type-C charging port on the side of the grinder.
2. Connect the provided USB Type-C cable to the grinder and plug the other end into a suitable USB power adapter (not included).
3. The blue LED indicators will light up during charging and turn off when fully charged.

Your browser does not support the video tag.

Video: Demonstrates how to charge the COKUNST Y3 Electric Grinder using the USB Type-C cable, showing the charging port and battery indicator lights.

6. OPERATING INSTRUCTIONS

6.1 Adjusting Grind Coarseness

You can adjust the grind coarseness to your preference:

1. Open the suction dust cover at the bottom of the grinder.
2. Locate the adjustable knob.
3. Turn the knob clockwise for finer particles and counter-clockwise for coarser particles.

Rotatable Knob

Adjust Grinding Coarseness




Image: A diagram illustrating the rotatable knob at the bottom of the grinder for adjusting grind coarseness, with indicators for fine and coarse settings.



Image: A hand adjusting the grind coarseness knob located at the base of the grinder.

6.2 Grinding Spices

The COKUNST Y3 grinder features one-handed operation:

1. Open the suction dust cover at the bottom of the grinder.
2. Press and hold the black button on the side of the grinder to start grinding. An LED light will illuminate the grinding area.
3. Release the button to stop grinding.
4. Close the suction dust cover after use to prevent spills and keep the grinding mechanism clean.

Automatic Pepper Grinder with Suction Dust Cover

Enjoy your delicious time with your family



Image: A hand operating the electric grinder over a plate of food, showing the grinding action and the illuminated LED light.



Image: A hand holding the grinder over a plate, demonstrating the open dust cover and the dispensing of spices.

7. MAINTENANCE

7.1 Cleaning

- The visual bin and the grinding mechanism can be separated for cleaning.
- Unscrew the visual bin and empty any remaining spices.
- Wipe the exterior of the grinder with a damp cloth. Do not use abrasive cleaners.

- The visual bin can be rinsed with water. Ensure it is completely dry before reattaching.
- Use a small brush (not included) to clean any spice residue from the grinding mechanism.
- The grinder is **not** dishwasher safe.

7.2 Storage

Store the grinder in a cool, dry place when not in use. Ensure the suction dust cover is closed to prevent dust and moisture from entering the grinding mechanism.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinder not operating	Low battery	Recharge the grinder using the provided USB cable.
Grinder jams or stops	Spice particles too large or mechanism clogged	Empty the bin, clean the grinding mechanism, and ensure spices are suitable for grinding.
Inconsistent grind	Coarseness setting needs adjustment	Adjust the coarseness knob at the bottom of the grinder.
Spices spilling from bottom	Dust cover not closed properly	Ensure the suction dust cover is securely closed after each use.

9. SPECIFICATIONS

Feature	Detail
Model Number	Y3
Material	Aluminum
Color	Silver
Item Weight	9.6 ounces (0.6 Pounds)
Product Dimensions	2.3 x 2.3 x 7.7 inches
Operation Mode	Automatic
Capacity	4 Oz / 120 MI
Dishwasher Safe	No
Charging Port	USB Type-C

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official COKUNST website. Please have your model number (Y3) and purchase date available when contacting support.

