

Surge Gamepad Pro (Pillars of Creation)

Surge Gamepad Pro (Pillars of Creation)

WIRELESS PRO CONTROLLER INSTRUCTION MANUAL

Model: Gamepad Pro (Pillars of Creation) | Brand: Surge

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your new Surge Gamepad Pro (Pillars of Creation) Wireless Controller. Designed for multi-platform compatibility, this controller offers advanced features including dynamic lighting, programmable macro buttons, rumble vibration, and motion controls to enhance your gaming experience.

Product Overview

The Surge Gamepad Pro is engineered for extended gameplay and immersive experiences. Key features include:

- 600mAh Battery:** Enjoy up to 18 hours of gameplay on a single charge.
- Multi-Platform Compatibility:** Seamlessly connect with Nintendo Switch, Windows PC, Steam Deck, Android 10.0+, and iOS 13.4+ devices.
- Translucent Shell:** A unique semi-transparent design with dynamic LED rings creates a captivating visual effect.
- 3 Dynamic Lighting Modes:** Choose from Aurora wave pattern, breathing effect, and stick follow for stunning visuals.
- Adjustable LED Lighting:** Customize your controller's look with 8 color options and independent intensity control for button and thumbstick LEDs.
- Programmable Macro Buttons:** Two rear macro buttons allow for custom button combinations.
- Rumble Vibration:** Four levels of dual rumble vibration provide immersive feedback.
- Motion Controls:** Integrated 6-axis motion control for enhanced gameplay.
- 3.5mm Audio Port:** Connect your headset directly to the controller for audio.



Front view of the Surge Gamepad Pro (Pillars of Creation) Wireless Controller, showcasing its unique cosmic design and illuminated thumbsticks.



Rear view of the controller, highlighting the programmable macro buttons (MR and ML) and the USB-C charging port.



An illustrative graphic demonstrating the 8 available LED colors and 3 dynamic lighting modes (Aurora Wave, Breathing Effect, Stick Follow) of the controller.



A graphic detailing key specifications: two macro buttons, a 20-foot wireless play range, and a 600mAh rechargeable battery.

Official Product Videos

Your browser does not support the video tag.

Video demonstrating the "Aurora Wave" lighting mode on the Surge Gamepad Pro, showcasing the dynamic color transitions around the thumbsticks and buttons.

Your browser does not support the video tag.

Video illustrating the "Stick Follow" lighting mode, where the LED colors change in response to thumbstick movements.

Setup

Charging the Controller

Before first use, fully charge the controller using the provided USB-C cable. Connect the USB-C end to the controller's charging port (located on the top edge) and the USB-A end to a compatible USB power source (e.g., console, PC, USB wall adapter). The LED indicators will show charging status and turn off when fully charged.

Pairing with Devices

The Surge Gamepad Pro supports Bluetooth connectivity across multiple platforms:

- **Nintendo Switch:** From the HOME Menu, select "Controllers" > "Change Grip/Order". While the screen is displaying "Press L + R on the controller", press and hold the SYNC button on the top of the Gamepad Pro until the player LEDs begin to flash. Once paired, the player LED(s) corresponding to the controller number will remain lit.
- **Windows PC / Steam Deck:** Ensure your PC or Steam Deck has Bluetooth enabled. Go to Bluetooth settings and select "Add a device". Press and hold the SYNC button on the controller until it appears in the list of available devices. Select "Surge Gamepad Pro" to pair.
- **Android / iOS Devices:** Enable Bluetooth on your mobile device. Press and hold the SYNC button on the controller. Select "Surge Gamepad Pro" from the Bluetooth device list on your phone or tablet to connect.

Operating Instructions

Adjusting LED Lighting

The controller features customizable LED lighting. Use the dedicated lighting control buttons (refer to the controller diagram in the packaging) to cycle through 8 color options and 3 dynamic lighting modes (Aurora Wave, Breathing Effect, Stick Follow). You can also adjust the intensity or turn off the button and thumbstick LEDs independently.

Programming Macro Buttons

The two rear macro buttons (MR and ML) can be programmed to execute complex button sequences. Refer to the detailed programming instructions in the full user manual (usually included in the product packaging) for specific steps on how to record and assign macros.

Turbo Settings and Rumble Vibration

The controller offers 3 adjustable turbo settings for rapid-fire input and 4 levels of dual rumble vibration for enhanced haptic feedback. Consult the full user manual for instructions on how to adjust these settings to your preference.

Maintenance

To ensure the longevity and optimal performance of your Surge Gamepad Pro:

- Clean the controller regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the controller or subjecting it to strong impacts.
- Do not attempt to disassemble or modify the controller, as this will void the warranty.

Troubleshooting

If you encounter issues with your Surge Gamepad Pro, try the following steps:

- **Controller not connecting:** Ensure Bluetooth is enabled on your device. Try re-pairing the controller by holding the SYNC button. Make sure the controller is charged.
- **Input lag or disconnection:** Move closer to your device to reduce interference. Ensure no other strong wireless signals are present nearby.

- **Buttons unresponsive:** Check if the controller is fully charged. Try resetting the controller (refer to the full manual for reset procedure, if available).
- **LEDs not working:** Ensure the lighting features are enabled and not set to minimum intensity.

For persistent issues, please refer to the official Surge support resources or contact customer service.

Specifications


Feature	Detail
Brand	Surge
Model	Gamepad Pro (Pillars of Creation)
ASIN	B0CHZ6NHT4
Battery Capacity	600mAh Lithium
Battery Life	Up to 18 hours
Connectivity	Bluetooth (up to 20ft wireless range)
Compatibility	Nintendo Switch, Windows PC, Steam Deck, Android 10.0+, iOS 13.4+
Motion Control	6-axis motion control
Vibration	Dual rumble (4 levels)
Audio Port	3.5mm
Product Dimensions	5.91 x 4.72 x 2.76 inches
Item Weight	0.63 ounces
Country of Origin	China

Warranty and Support

For warranty information, product registration, or technical support, please visit the official Surge website or contact their customer service. You can find more products and information at the [Surge Store on Amazon](#).

Please retain your proof of purchase for any warranty claims.

Related Documents - Gamepad Pro (Pillars of Creation)

	SURGE SwitchPad Pro Wireless Controller for Nintendo Switch User Manual User manual for the SURGE SwitchPad Pro Wireless Pro Controller (Model: IX-SW055) for Nintendo Switch. Includes setup, features, charging, synchronization, troubleshooting, and FCC statements.
---	---

	<p>SURGE QuickType SG20021 User Manual for PlayStation 5 DualSense Controllers</p> <p>Official user manual for the SURGE QuickType SG20021 Bluetooth chat pad, providing setup instructions, precautions, maintenance tips, and FCC compliance information for PlayStation 5 DualSense controllers.</p>
	<p>Mytrix Sakura Pink Pro Wireless Controller User Manual</p> <p>User manual for the Mytrix Sakura Pink Pro Wireless Controller, detailing its features, connectivity, and usage for Nintendo Switch, Windows PC, iOS, and Android devices.</p>
	<p>GameSir T4 Cyclone Wireless Controller - User Manual and Features</p> <p>Comprehensive guide to the GameSir T4 Cyclone Wireless Controller, detailing its Hall Effect joysticks, magnetic D-pad, multi-platform compatibility (Switch, PC, Mobile), and ergonomic design for enhanced gaming.</p>
	<p>EasySMX ESM-9124 Wireless Controller User Manual</p> <p>This manual provides detailed instructions for the EasySMX ESM-9124 Wireless Switch Pro Controller, covering product description, diagram, connection methods for Android, iOS, PC, and Switch, light management, turbo function settings, dual vibration adjustment, key programming, controller reset, charging indicators, and packing list.</p>
	<p>Mytrix Wireless Pro Controller User Manual - Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the Mytrix Wireless Pro Controller (MTNSPC-M01). Learn how to connect to Nintendo Switch, PC, iOS, Android, and Steam Deck. Discover features like programmable buttons, LED lighting, turbo, and vibration via the Keylinker app.</p>