Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KOPIDOE VC016

KOPIDOE Compressed Air Duster & Car Vacuum Cleaner User Manual

Model: VC016 | Brand: KOPIDOE

Introduction

This manual provides detailed instructions for the safe and effective use of your KOPIDOE Compressed Air Duster and Car Vacuum Cleaner. This versatile device combines the functions of an air duster, a handheld vacuum, and a pump, making it ideal for various cleaning and inflation tasks. Please read this manual thoroughly before operation and retain it for future reference.



Figure 1: KOPIDOE Compressed Air Duster and Car Vacuum Cleaner with included nozzles and brushes.

Package Contents

Verify that all items are present in the package:

- 1 x Compressed Air Duster & Car Vacuum Cleaner (Model: VC016)
- 6 x Nozzles (various types for different applications)
- 3 x Brushes
- 1 x Filter
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)



Figure 2: Illustration of the KOPIDOE Air Duster and all included accessories.

Setup

Before first use, ensure the device is fully charged.

1. **Charging the Device:**

   Connect the provided Type-C charging cable to the charging port on the device and to a 5V-2A adapter, computer USB port, car charger, or power bank. The 3 blue battery indicator lights on the back will flash alternately during charging. Once fully charged (approximately 3-3.5 hours), the green light will remain on. Ensure the device is turned off before charging.



Figure 3: Charging the device using the USB-C cable and various power sources. A full charge provides up to 40 minutes of usage.

2. **Attaching Nozzles/Brushes:**

   Select the appropriate nozzle or brush for your cleaning task. Attach it firmly to either the blowing port or the vacuuming port of the device. Refer to the "Operating Instructions" section for specific attachment guidance for blow and vacuum modes.

Operating Instructions

Your KOPIDOE device offers three primary functions: air blowing, vacuuming, and inflation. Follow these steps for optimal performance.

1. Power On/Off and Speed Control

- **Power On/Off:** Press and hold the power button for 3 seconds to turn the device on or off.
- **Adjusting Speed:** Once powered on, short-press the power button to cycle through the three wind speed modes:
  - **Gear 1 (55000 RPM):** Ideal for delicate items like lenses, projectors. (Runtime: 30-40 mins)
  - **Gear 2 (85000 RPM):** Suitable for keyboards, desktops, windows. (Runtime: 25-30 mins)
  - **Gear 3 (100000 RPM):** For heavy-duty cleaning of PC cases, furniture, car vents. (Runtime: 15-23 mins)
- **LED Light:** Press and hold the light button for 3 seconds to turn the integrated LED light on or off. This light assists in cleaning dark areas.

Figure 4: Controls for power, speed adjustment, and LED light activation.

2. Blow Mode Operation

Use this mode for dusting, blowing debris, or inflating.

1. Ensure the dust cover is installed on the vacuum intake port to prevent dust from entering the motor during blowing.
2. Attach the desired blowing nozzle or brush to the front output port.

3. Power on the device and select the appropriate speed.
4. Direct the airflow towards the area to be cleaned or the item to be inflated.



Figure 5: Using the blow mode to clean a keyboard.




Figure 6: Using the blow mode for PC case cleaning.



Figure 7: Using the blow mode for car interior cleaning.



Figure 8: Using the blow mode for blowing fire (e.g., for BBQ charcoal).



Figure 9: Using the blow mode for inflating items like swimming rings.

3. Vacuum Mode Operation

Use this mode to vacuum dust, crumbs, and small debris.

1. Remove the dust cover from the vacuum intake port.
2. Install the filter and the desired vacuum nozzle (e.g., the slightly longer and thicker nozzle) into the vacuum intake port. Ensure the black rubber ring in the filter is properly seated.
3. Power on the device and select the appropriate speed.
4. Direct the vacuum nozzle towards the area to be cleaned.




Figure 10: Using the vacuum mode to clean a keyboard.




Figure 11: Using the vacuum mode for car interior cleaning.



Figure 12: General usage of the vacuum mode for various surfaces.

Your browser does not support the video tag.

Video 1: Demonstration of how to properly use the vacuum mode of the electric air duster. (Source: KOPIDOE Official Store)

Your browser does not support the video tag.

Video 2: Overview of the Handheld Electric Air Duster & Vacuum for Computer, PC, and Car. (Source: KOPIDOE Official Store)

Maintenance

Regular maintenance ensures the longevity and optimal performance of your device.

1. **Cleaning the Filter:**

After using the vacuum mode, it is recommended to clean the filter. Remove the dust collection cup and filter. The filter is washable. Rinse it under running water and allow it to air dry completely before reinserting it into the device. Do not use the device with a wet filter.

2. **Cleaning the Device Body:**

   Wipe the exterior of the device with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure no water enters the charging port or air vents.

3. **Storage:**

   Store the device in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully charged before long-term storage to preserve battery health.

Troubleshooting

If you encounter issues with your KOPIDOE device, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; Power button not pressed long enough.	Charge the device fully. Press and hold the power button for 3 seconds.
Weak airflow/suction.	Low battery; Filter clogged; Nozzle/brush improperly attached; Wrong mode selected.	Recharge the device. Clean the filter. Ensure nozzle is firmly attached. Verify correct mode (blow/vacuum) and dust cover position.
LED light not working.	Light button not pressed long enough.	Press and hold the light button for 3 seconds.
Device overheats.	Prolonged continuous use.	Turn off the device and allow it to cool down for at least 15-20 minutes before resuming use.

Specifications

Feature	Detail
Model Name	VC016
Motor Speed	Up to 100,000 RPM
Battery Capacity	6000 mAh (Built-in 3*2000mAh)
Charging Time	3-3.5 hours (with 5V-2A adapter)
Runtime	1st Gear: 30-40 mins; 2nd Gear: 25-30 mins; 3rd Gear: 15-23 mins
Charging Port	USB Type-C
Dimensions	6.9 x 2.2 x 1.4 inches (approx.)
Weight	375g (approx.)
Filter Type	HEPA Filter (Washable)
Special Features	3-speed wind control, LED light, Multi-use (Duster, Vacuum, Pump)



Figure 13: Dimensions and key features of the KOPIDOE Air Duster.



Figure 14: Details on the super suction power and motor specifications.

Warranty and Support

KOPIDOE offers a lifetime warranty for this product, ensuring peace of mind regarding its quality and performance.

- For warranty claims or technical support, please contact KOPIDOE customer service through the retailer where the product was purchased or visit the official KOPIDOE store on Amazon.
- Please have your purchase receipt and product model number (VC016) ready when contacting support.

For more information and product updates, visit the KOPIDOE Official Store.

© 2024 KOPIDOE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJ2FXLMJ

More documents and user manuals: **https://manuals.plus/**