

[Manuals.plus](#) /

> [BRECIIOUS](#) /

> BRECIIOUS Slow Masticating Juicer Instruction Manual

BRECIIOUS ZM1506

BRECIIOUS Slow Masticating Juicer Instruction Manual

Model: ZM1506

INTRODUCTION

Thank you for choosing the BRECIIOUS Slow Masticating Juicer. This cold press juicer is designed to efficiently extract juice from various fruits and vegetables, preserving maximum nutrients and vitamins through its slow masticating technology. Its quiet motor and user-friendly design make it an ideal addition to any kitchen. Please read this manual thoroughly before operation to ensure safe and optimal performance.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the juicer is properly assembled before use.
- Do not operate the juicer with damaged cord or plug.
- Keep hands and utensils out of the feed chute during operation. Use the food pusher provided.
- The juicer features a 1.8-inch small diameter feed chute for safety, preventing accidental insertion of hands.
- All food-contact parts are 100% BPA-free.
- Do not immerse the motor base in water or other liquids.
- Unplug the juicer from the outlet when not in use and before cleaning.
- This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.

PRODUCT OVERVIEW

The BRECIIOUS Slow Masticating Juicer consists of several key components designed for efficient juicing and easy

maintenance.

- **Motor Base:** Houses the powerful and quiet motor, and control buttons.
- **Feed Chute:** Where fruits and vegetables are inserted. Designed with a small diameter for safety.
- **Auger:** The upgraded 7-auger grinds produce maximum juice yield and minimize oxidation.
- **3-Section Super Filter:** Maximizes juice smoothness and reduces pulp.
- **Juice Outlet:** For extracted juice.
- **Pulp Outlet:** For expelled pulp.
- **Control Panel:** Features REV (Reverse), Hard, Soft, and OFF buttons.



Figure 1: Fully assembled BRECIIOUS Slow Masticating Juicer.



Figure 2: Close-up of the multi-function control buttons (REV, Hard, Soft, OFF).

SETUP

The juicer is designed for easy assembly and disassembly.

1. Place the motor base on a stable, flat surface.
2. Align the juicing chamber with the motor base and twist to secure.
3. Insert the auger into the juicing chamber.
4. Place the 3-section super filter over the auger.
5. Attach the feed chute assembly to the juicing chamber, ensuring it clicks into place.
6. Position the juice collection cup under the juice outlet and the pulp collection cup under the pulp outlet.



Simple to Use

Easy to assemble, One-touch Disassemble

Figure 3: Components ready for simple assembly.



One Touch Disassemble

Easy to Clean After Using

Figure 4: One-touch disassemble feature for convenience.

OPERATING INSTRUCTIONS

Prepare your fruits and vegetables by washing them thoroughly. Cut larger items to fit the 1.8-inch feed chute.

1. Plug in the juicer.
2. Select the appropriate speed mode:
 - **Soft Mode:** For softer fruits and vegetables (e.g., oranges, kiwi, strawberries).
 - **Hard Mode:** For harder fruits and vegetables (e.g., celery, carrots, apples).
3. Slowly feed the prepared ingredients into the feed chute. Use the food pusher to guide them down.
4. The juicer will automatically separate juice into the juice cup and pulp into the pulp cup.
5. If clogging occurs, press the **REV (Reverse)** button to clear the blockage.
6. Once juicing is complete, press the **OFF** button and unplug the appliance.



Cold Press Juicer

Low and Cold Press to Retain Nutrients and vitamin

Figure 5: Cold press technology ensures high nutrient retention.



Small Feed Chute

Whoever Makes the Juice is Safer (Child, teenager, etc)

Figure 6: Small feed chute for enhanced safety during operation.

Your browser does not support the video tag.

Video 1: Official demonstration of the BRECIIOUS Slow Masticating Juicer in action, highlighting its features and quiet operation.

MAINTENANCE & CLEANING

Regular cleaning ensures the longevity and hygiene of your juicer.

- Unplug the juicer before cleaning.
- Disassemble all detachable parts by pressing the one-touch disassemble button.
- Rinse all detachable parts under running water. Use the provided cleaning brush to remove any pulp residue from the filter.
- All detachable components are dishwasher safe for convenient cleaning.
- Wipe the motor base with a damp cloth. Do not immerse it in water.
- Ensure all parts are completely dry before reassembling or storing.



Easy to Clean

All Detachable Components can be Placed in the Dishwasher

Figure 7: Easy to clean design with dishwasher-safe components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; improper assembly.	Ensure power cord is securely plugged in. Reassemble parts correctly until they click into place.
Juicer stops during operation or clogs.	Too much produce at once; hard ingredients.	Press the REV button to clear blockage. Reduce amount of produce fed at one time. Cut hard ingredients into smaller pieces.
Low juice yield or wet pulp.	Incorrect speed setting; filter clogged.	Ensure correct speed mode (Hard/Soft) is selected for the produce. Clean the filter thoroughly.

SPECIFICATIONS

- **Brand:** BRECIIOUS
- **Model Name:** ZM1506
- **Color:** Black
- **Product Dimensions:** 14.84"D x 6.97"W x 14.6"H
- **Item Weight:** 6.17 pounds
- **Power Source:** Corded Electric
- **Maximum Power:** 150 Watts
- **Voltage:** 120 Volts (AC)
- **Number of Speeds:** 2 (Hard, Soft)
- **Special Features:** Quieter operation (<60DB), 95-110 RPM low speed, Easy to clean, Easy to assemble, BPA-free, Reverse function, High juice yield (90%), Suitable for various fruits and vegetables.
- **Product Care Instructions:** Dishwasher Safe (detachable parts)

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the warranty card included in your product packaging or contact BRECIIOUS customer service through the retailer's platform. Your satisfaction is our mission.