

[Manuals.plus](#) /

> [BRECIOUS](#) /

> Slow Masticating Juicer, Brecious Cold Press Juicers with 2 Speed Modes & Quiet Motor, Juicers Machines Vegetable and Fruit with Reverse Function, Celery Juicer, BPA-Free, Easy to Clean (Silver)

## BRECIOUS ZM1506

# BRECIOUS Slow Masticating Juicer Instruction Manual

Model: ZM1506

Brand: BRECIOUS

## IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using the appliance and retain them for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- Ensure the juicer is unplugged from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep hands and utensils out of the feeding chute during operation to prevent injury and damage to the juicer. Always use the provided food pusher.
- Ensure all parts are correctly and securely assembled before operating the juicer.
- The juicer features a 1.8-inch small diameter feed chute to ensure safe use, especially around children.
- All food-contact parts are 100% BPA-free and designed without any blades or sharp edges for enhanced safety.

## PRODUCT OVERVIEW AND COMPONENTS

---

The BRECIOUS Slow Masticating Juicer is engineered for efficient and quiet juice extraction, preserving maximum nutrients and vitamins through its cold press technology.

### Components:

- Main Motor Base (with control buttons)

- Feeding Chute
- Auger (Upgraded 7-segment spiral)
- Strainer/Filter (3-Section Super Filter)
- Juice Outlet
- Pulp Outlet
- Juice Cup
- Pulp Container
- Pusher
- Cleaning Brush



Image: The complete Brecious Slow Masticating Juicer in silver, showing the main unit, juice cup, and pulp container, with fresh grapes and lemons.



Image: A close-up view of the juicer's motor base, highlighting the "Brecious" brand name and the control buttons.

## SETUP AND ASSEMBLY

---

Follow these steps to assemble your juicer before first use. Ensure the unit is unplugged during assembly.

1. Place the main motor base on a stable, flat surface.
2. Insert the juicing chamber onto the motor base. Align the arrows on the chamber and the base, then twist clockwise until it locks into place.
3. Insert the auger (spiral part) into the juicing chamber.
4. Place the strainer/filter over the auger, ensuring it sits correctly.
5. Attach the front cap to the juicing chamber, twisting it clockwise to secure it firmly.
6. Position the juice cup under the juice outlet and the pulp container under the pulp outlet.
7. Insert the food pusher into the feeding chute.



Image: A person demonstrating the simple assembly of the juicer, showing the main body and detachable parts on a kitchen counter.

Your browser does not support the video tag.

Video: Official Brecious video demonstrating the assembly and operation of the slow masticating juicer.

## OPERATING INSTRUCTIONS

---

### Preparing Ingredients:

- Wash all fruits and vegetables thoroughly.
- Cut ingredients into pieces small enough to fit the 1.8-inch feeding chute.
- Remove hard pits from fruits (e.g., peaches, cherries, avocados).

### Juicing Process:

1. Plug in the juicer to a suitable power outlet.
2. Select the appropriate speed mode using the multi-function buttons:
  - **Soft Mode (85-95 RPM):** Ideal for soft fruits like oranges, kiwi, strawberries, and tomatoes.

- **Hard Mode (95-110 RPM):** Suitable for harder vegetables and fruits such as celery, carrots, apples, kale, wheatgrass, beets, and ginger.
3. Slowly feed prepared ingredients into the feeding chute. Use the pusher to gently guide them down. Do not force ingredients.
  4. The juicer will automatically separate juice into the juice cup and pulp into the pulp container.
  5. If clogging occurs, press the "REV" (Reverse) button to clear the blockage. Hold for a few seconds, then release. Repeat if necessary.



## Simple to Use

Easy to assemble, One-touch Disassemble

Image: The juicer in operation, showing an apple being fed into the chute and green juice flowing into the collection cup.



## Small Feed Chute

Whoever Makes the Juice is Safer (Child, teenager, etc)

Image: A close-up of the juicer's control panel, showing the "REV", "Hard", "Soft", and "OFF" buttons.



## 3 Section Super Filter

Maximizes the silky smoothness of the juice and less pulp

Image: An overhead view of the juicer's small 1.8-inch feed chute, emphasizing its safety feature.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and longevity of your juicer. Clean the appliance immediately after each use.

1. Turn off the juicer and unplug it from the power outlet.
2. Press the "Push" button on the side of the juicing chamber and twist counter-clockwise to detach it from the motor base.
3. Disassemble all detachable parts: front cap, strainer, auger, and juicing chamber.
4. Rinse all detachable components under running water. Use the provided cleaning brush to remove any pulp residue from the strainer and other intricate parts.
5. All detachable components are dishwasher safe for convenient cleaning. Place them on the top rack of your dishwasher.
6. Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
7. Allow all parts to dry completely before reassembling or storing the juicer.



# Easy to Clean

All Detachable Components can be Placed in the Dishwasher

Image: Hands demonstrating the one-touch disassembly feature of the juicer, showing how the juicing chamber detaches from the main unit.



Image: A split image showing the cleaning process: one side shows a hand using a brush to clean the filter under running water, and the other side shows detachable parts inside a dishwasher.

## TROUBLESHOOTING

If you encounter any issues with your juicer, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Juicer does not turn on	Not plugged in; Parts not assembled correctly; Overheat protection activated.	Ensure power cord is securely plugged in; Reassemble all parts correctly; Unplug and let cool for 30 minutes before restarting.
Excessive pulp in juice	Strainer is clogged; Ingredients not cut small enough.	Clean the strainer thoroughly; Cut ingredients into smaller pieces.

Problem	Possible Cause	Solution
Juicer stops during operation	Overload; Ingredients too hard or large.	Press "REV" button to clear blockage; Turn off, clear, and restart. Ensure ingredients are appropriate for selected speed.
Loud noise or vibration	Improper assembly; Hard ingredients.	Check that all parts are securely locked; Ensure ingredients are suitable for the juicer.

For further assistance, please contact BRECIIOUS customer support.

## SPECIFICATIONS

---

- **Brand:** BRECIIOUS
- **Model Name:** ZM1506
- **Color:** Silver
- **Product Dimensions:** 14.84"D x 6.97"W x 14.6"H
- **Item Weight:** 6.17 pounds
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts (AC)
- **Number of Speeds:** 2 (Soft, Hard)
- **Special Features:** Quieter operation (<60DB), 95-110 RPM low speed, Easy to clean, easy to use, easy to assemble, BPA free, Quiet Motor, reverse function, High juice yield (90%), suitable for various fruits and vegetables.
- **Product Care Instructions:** Dishwasher Safe (detachable parts)

## WARRANTY AND SUPPORT

---

This BRECIIOUS product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions regarding coverage and duration.

For technical support, replacement parts, or any inquiries regarding your juicer, please visit the official BRECIIOUS website or contact their dedicated customer service team. Contact information can typically be found on the product packaging or the brand's official website.