

[Manuals.plus](#) /

› [Ambimall](#) /

› Ambimall Fully Dimmable Floor Lamp User Manual

Ambimall B0CJ2S4XPC

Ambimall Fully Dimmable Floor Lamp User Manual

Brand: Ambimall | Model: B0CJ2S4XPC

1. PRODUCT OVERVIEW

The Ambimall Fully Dimmable Floor Lamp is designed to provide versatile and comfortable lighting for various indoor spaces such as living rooms, bedrooms, offices, and study areas. This modern standing lamp features a convenient rotary switch for brightness adjustment and an adjustable lamp head to direct light precisely where needed. It includes an energy-efficient LED bulb, ensuring long-lasting and flicker-free illumination.



Image 1.1: The Ambimall Fully Dimmable Floor Lamp positioned in a modern living room, demonstrating its aesthetic integration and ambient lighting capabilities.

2. KEY FEATURES

- **0-100% Dimmable Brightness:** Equipped with a 9W dimmable LED light bulb and a rotary switch, allowing seamless adjustment of light intensity from 0% to 100% to suit any activity or mood.

Fully Dimmable 0~100% Brightness



Image 2.1: Visual representation of the lamp's dimming capabilities, illustrating various brightness levels achievable with the rotary switch.

- **Customizable Lighting Angle:** The lamp head can rotate 270 degrees horizontally and 90 degrees vertically, providing flexible light direction for reading, crafting, or general room illumination.

Standing Lamp with Rotating Lamp Head



Image 2.2: The adjustable lamp head allows users to direct light precisely, as shown with a person reading comfortably.

- **Bright and Long-lasting LED Bulb:** Includes an E26 base LED bulb that emits a 3000K warm glow and has a lifespan of up to 30,000 hours, offering flicker-free and eye-friendly lighting.
- **Stable and Durable Construction:** Features a sturdy metal frame and a heavy base, ensuring the lamp remains securely in place and is resistant to accidental knocks.

3. SETUP AND ASSEMBLY

Assembly of the Ambimall Floor Lamp is designed to be straightforward and typically takes only a few minutes. No special tools are required.

Assembly Steps:

1. Carefully unpack all components from the packaging. Ensure all parts listed in the packaging contents are present.
2. Screw the pole sections together clockwise until securely tightened.
3. Attach the assembled pole to the heavy base by screwing it clockwise until firm.
4. Assemble the fabric lampshade according to the instructions provided in the box, typically by attaching the metal rings and

securing the fabric with Velcro.

5. Screw the included 9W LED bulb into the E26 lamp holder.
6. Place the lampshade onto the lamp holder.
7. Plug the power cord into a suitable electrical outlet.



Image 3.1: Overview of lamp dimensions and components, including the included LED bulb.

4. OPERATING INSTRUCTIONS

Brightness Adjustment:

The Ambimall Floor Lamp features a rotary switch located on the lamp pole for easy brightness control. To adjust the brightness:

- Rotate the switch clockwise to increase the brightness.
- Rotate the switch counter-clockwise to decrease the brightness.
- Continue rotating counter-clockwise until the lamp clicks off to turn it completely off.

Adjusting Lamp Head Angle:

The lamp head can be manually adjusted to direct light as desired:

- Gently pivot the lamp head horizontally up to 270 degrees.
- Tilt the lamp head vertically up to 90 degrees.
- Ensure the lamp is stable before adjusting the head.

5. MAINTENANCE

Cleaning:

To maintain the appearance and functionality of your lamp:

- Always unplug the lamp before cleaning.
- Wipe the metal parts with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- For the fabric lampshade, use a lint roller or a soft brush to remove dust. Spot clean with a damp cloth if necessary, and allow to air dry completely.

Bulb Replacement:

The included LED bulb has a long lifespan, but if replacement is needed:

- Ensure the lamp is unplugged and the bulb has cooled down.
- Unscrew the old bulb from the E26 lamp holder.
- Screw in a new E26 base LED bulb. For dimmable functionality, ensure the replacement bulb is also dimmable. The maximum compatible wattage is 60 Watts.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Power cord not plugged in; faulty bulb; power outage.	Ensure the power cord is securely plugged into a working outlet. Check if the bulb is screwed in correctly and replace if necessary. Verify power to the outlet.
Light flickers or is inconsistent.	Loose bulb; incompatible dimmer (if using external); unstable power supply.	Tighten the bulb. Ensure you are using the lamp's built-in rotary dimmer. Check for stable power supply.
Lamp head does not adjust smoothly.	Dust or debris in the joint; overtightened joint.	Clean the joint area. Do not force the adjustment; ensure it moves freely.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact Ambimall customer support.

7. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	Ambimall
Model	B0CJ2S4XPC

Specification	Detail
Lamp Type	Floor Lamp
Product Dimensions	11.8"D x 16.54"W x 63.4"H
Base Material	Metal
Shade Material	Fabric
Shade Color	Beige (for this variant)
Finish Type	Matte
Switch Type	Rotary
Light Source Type	LED
Bulb Base	E26
Wattage	9 Watts (included bulb)
Maximum Compatible Wattage	60 Watts
Brightness	920 Lumen
Color Temperature	3000 Kelvin
Special Features	0-100% Dimmable, Adjustable Lamp Angle
Power Source	Corded Electric
Assembly Required	Yes
Item Weight	8.03 pounds

8. WARRANTY AND SUPPORT

Ambimall stands behind the quality of its products. This floor lamp comes with a **5-year warranty** from the date of purchase. If you have any questions, require assistance with assembly, operation, or encounter any issues with your Ambimall Floor Lamp, please do not hesitate to contact our customer support team. We are committed to addressing your concerns promptly. For support, please visit the official Ambimall store page on Amazon or refer to the contact information provided with your product packaging.

[Visit the Ambimall Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question