SteFik ZVCA100B, 49.4000, Aquawelt 919.0, ZVC752, Aquos 829.5, 819.5

SteFik Non-Woven Fabric Dust Bag Instruction Manual

Compatible with ZELMER ZVCA100B, Aquawelt 919.0, ZVC752, Aquos 829.5 Series

1. Introduction

This instruction manual provides essential information for the proper installation, use, and maintenance of your SteFik Non-Woven Fabric Dust Bags. These bags are designed to be compatible with specific ZELMER vacuum cleaner models, ensuring optimal performance and a cleaner home environment. Please read this manual thoroughly before using the product.

2. Product Overview

The SteFik Non-Woven Fabric Dust Bags are high-efficiency filter bags crafted from durable non-woven material. They are engineered to effectively capture fine dust particles, dirt, and allergens, contributing to improved indoor air quality. Each bag features a robust construction designed for longevity and resistance to tearing or leakage during use and disposal.



Image 2.1: A stack of multiple SteFik non-woven fabric dust bags, showcasing their white material and blue plastic mounting collars.



Image 2.2: A single SteFik non-woven fabric dust bag, laid flat, displaying its front side with the blue plastic collar and white filter material.




Image 2.3: A detailed close-up view of the non-woven fabric material used in the dust bag, highlighting its fine texture and construction.

3. Setup and Installation

Follow these steps to correctly install a new SteFik dust bag into your compatible ZELMER vacuum cleaner. Always ensure the vacuum cleaner is unplugged from the power outlet before performing any maintenance or installation.

1. **Power Off and Unplug:** Disconnect your vacuum cleaner from the main power supply to prevent accidental activation.
2. **Open Vacuum Compartment:** Locate and open the dust bag compartment on your ZELMER vacuum cleaner. Refer to your vacuum cleaner's specific manual for compartment access instructions.
3. **Remove Old Bag:** Carefully remove the full dust bag. Most compatible models feature a sealing mechanism on the bag's collar to prevent dust leakage during removal. Dispose of the used bag responsibly.
4. **Insert New Bag:** Take a new SteFik non-woven fabric dust bag. Align the blue plastic collar of the new bag with the bag holder inside the vacuum cleaner compartment. Push firmly until the bag is securely seated. Ensure the bag is fully unfolded inside the compartment without obstructing any filters or mechanisms.



Image 3.1: A close-up view of the blue plastic collar of the dust bag, showing the opening and the sealing flap, crucial for proper installation.



Image 3.2: A single SteFik non-woven fabric dust bag, viewed from the front, illustrating its design for insertion into the vacuum cleaner compartment.

5. **Close Compartment:** Close the dust bag compartment securely. Ensure it latches properly.
6. **Reconnect Power:** Plug the vacuum cleaner back into the power outlet.

4. Operating Instructions

Once the dust bag is correctly installed, your vacuum cleaner is ready for operation. The SteFik dust bags are designed for standard dry vacuuming tasks. For optimal performance:

- Operate your vacuum cleaner as per its manufacturer's instructions.
- Regularly check the dust bag indicator on your vacuum cleaner (if available).
- Replace the dust bag when it is full or when suction power noticeably decreases.

5. Maintenance

Proper maintenance of your dust bags ensures efficient vacuuming and extends the life of your appliance. SteFik dust bags are designed for single use and are not washable or reusable.

- **Regular Replacement:** Replace the dust bag promptly when it is full. Overfilling can reduce suction power and potentially damage your vacuum cleaner.
- **Disposal:** Dispose of used dust bags in accordance with local waste disposal regulations. The bag's sealing mechanism helps contain dust during disposal.
- **Storage:** Store unused dust bags in a cool, dry place, away from direct sunlight and moisture, to maintain their integrity.



Image 5.1: The back view of a single SteFik non-woven fabric dust bag, showing the sealed edges and overall construction.

6. Troubleshooting

If you encounter issues while using your vacuum cleaner with SteFik dust bags, consider the following:

- **Reduced Suction:**
  - Check if the dust bag is full and needs replacement.
  - Ensure the dust bag is correctly installed and fully seated in its compartment.
  - Inspect for any blockages in the vacuum cleaner's hose or attachments.
- **Dust Leakage:**
  - Verify that the dust bag's plastic collar is securely fitted into the vacuum cleaner's bag holder.
  - Ensure the dust bag compartment door is fully closed and latched.

If problems persist, consult your vacuum cleaner's original instruction manual or contact customer support.

7. Specifications

Product Type	Non-Woven Fabric Dust Bag
Material	Non-Woven Fabric
Color	Gray
Package Contents	15 pieces per package
Compatibility	ZELMER ZVCA100B, 49.4000, Aquawelt 919.0 St, ZVC752, Aquos 829. OSP 819.5
Item Weight (approx.)	1 Grams (per bag)
Brand	SteFik

8. Support

For any questions regarding the SteFik Non-Woven Fabric Dust Bags or assistance with their use, please contact our customer support. We are committed to helping you resolve any issues and ensure your satisfaction.
Please note: Specific warranty information for this consumable product is not provided. Refer to your purchase documentation for return policies.

© 2023 SteFik. All rights reserved.