

[Manuals.plus](#) /

› [ZenStyle](#) /

› ZenStyle 3 ft Adjustable Folding Table (Rectangular, 30"x20") User Manual

ZenStyle 0436 (Rectangular, 30"x20")

ZenStyle 3 ft Adjustable Folding Table (Rectangular, 30"x20") User Manual

Model: 0436

INTRODUCTION

Thank you for choosing the ZenStyle 3 ft Adjustable Folding Table. This manual provides essential information for the safe and effective use, setup, and maintenance of your new table. Please read it thoroughly before use and retain it for future reference.

SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- Do not exceed the maximum weight recommendation of 110 pounds.
- Ensure the table is fully stable and all leg mechanisms are locked before placing items on it.
- Be mindful of pinch points when unfolding or folding the table legs and tabletop. Keep hands and fingers clear of moving parts.
- Place the table on a flat, stable surface to prevent tipping.
- Do not stand or sit on the table.
- Keep children away from the table during setup and folding.

PRODUCT FEATURES

The ZenStyle 3 ft Adjustable Folding Table is designed for versatility and convenience, offering the following key features:

- **Folds Flat:** No assembly required. Unfolds in seconds for immediate use. Steel legs fold for convenient storage and portability.
- **Compact & Sleek Design:** Dimensions (Open): 30" L x 19.6" W x 19.3" - 29" H. Dimensions (Closed): 36.4" L x 19.6" W x 2.75" H. Provides ample space for 2 adults.

- **Solid Tabletop & Easy to Clean:** Constructed from heavy-duty blow-molded High-Density Polyethylene (HDPE), 20% thicker than standard hollow tables. The resin surface is waterproof, scratch, and impact-resistant, making it easy to clean and suitable for both indoor and outdoor use.
- **Durable and Strong:** Features powder-coated steel round tubing legs with a bracing design for enhanced strength and stability. Honeycomb design disperses pressure, supporting up to 110 pounds. Non-marring foot caps protect floors and prevent slipping.
- **Adjustable Height:** The table offers multiple height settings to suit various activities and user preferences.

SETUP INSTRUCTIONS

The ZenStyle folding table requires no assembly. Follow these steps to set up your table:

1. **Unfold the Table:** Place the folded table on a flat surface. Gently pull the two halves of the tabletop apart until they are fully extended and flat.
2. **Extend the Legs:** Locate the folded legs underneath the tabletop. Swing each set of legs outwards until they are fully extended.
3. **Secure the Legs:** Ensure the support beams in the center of the legs are properly engaged and locked into place. The legs should feel sturdy and not wobble.
4. **Adjust Height (if applicable):** If your model features adjustable height, locate the adjustment pins on the legs. Press the pins and slide the leg extensions to your desired height, ensuring the pins snap securely into the corresponding holes.



Image: The ZenStyle folding table fully set up for outdoor use.



Image: The ZenStyle folding table in a kitchen setting, demonstrating its versatility.

OPERATING INSTRUCTIONS

Using your ZenStyle folding table is straightforward:

- **Placement:** Position the table on a flat, stable surface, whether indoors or outdoors.
- **Weight Distribution:** Distribute weight evenly across the tabletop. Avoid concentrating heavy items in one spot.
- **Folding for Storage:** To fold the table, first remove all items from the surface. Release the leg locking mechanisms and fold the legs inwards. Then, fold the tabletop in half using the central hinge. Secure the folded halves with the integrated handle or latch if present.

EASY TO TAKE

Fold into Compact Case with Soft Handle



Image: The table folded and being carried, highlighting its portability.



EASY TO STORE

Efficient Storage to Maximize Space Utilization

Image: Several folded tables stacked, demonstrating efficient storage.

MAINTENANCE

Proper care will extend the life of your ZenStyle folding table:

- **Cleaning:** Wipe the table surface with a damp cloth. For tougher stains, a mild soap solution can be used. Avoid abrasive cleaners that may damage the surface.
- **Storage:** Store the table in a dry place when not in use, especially if used outdoors, to protect the metal frame from rust and prolong the life of the plastic top.
- **Inspection:** Periodically check all bolts and hinges to ensure they are secure. Tighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your table, consider the following:

- **Table is Wobbly:** Ensure all legs are fully extended and locked into their respective positions. Check that the table is on a flat, even surface.
- **Difficulty Folding/Unfolding:** Ensure no debris is obstructing the hinges or leg mechanisms. Apply

gentle, even pressure. Do not force the components.

- **Legs Not Locking:** Verify that the adjustment pins (if applicable) are fully engaged in the height adjustment holes. Check for any bent or damaged parts that might prevent proper locking.

For persistent issues, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	ZenStyle
Model Number	0436
Product Dimensions (Open)	19.6"D x 30"W x 19.3"-29"H
Product Dimensions (Closed)	36.4" L x 19.6" W x 2.75" H
Item Weight	22.3 Pounds
Maximum Weight Recommendation	110 Pounds
Frame Material	Plastic, Alloy Steel (Powder Coated)
Top Material Type	High Density Polyethylene (HDPE)
Color	White
Shape	Rectangular
Required Assembly	No
Is Foldable	Yes
Product Care Instructions	Wipe with Damp Cloth




Image: Detailed dimensions of the table, including adjustable height and folded size.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official ZenStyle website. You can also contact ZenStyle customer service directly through their Amazon store page: [Visit the ZenStyle Store](#).