



Manuals.plus /

› Seventable /

› Seventable ED014 Nightstand with Charging Station and LED Lights User Manual

Seventable ED014

Seventable ED014 Nightstand User Manual

Model: ED014 | Brand: Seventable

1. INTRODUCTION

Thank you for choosing the Seventable ED014 Nightstand. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your product. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image: The Seventable ED014 Nightstand, featuring its integrated LED lighting and charging station, positioned next to a bed.

2. SAFETY INFORMATION

- Keep all packaging materials away from children to prevent choking hazards.
- Ensure all components are securely fastened before use. Loose parts can cause instability.
- Do not exceed the maximum weight capacity of 25 kg (55 lbs) for the tabletop and 5 kg (11 lbs) for each drawer.
- Place the nightstand on a flat, stable surface. Use the adjustable feet to level the unit and prevent wobbling.
- Keep electrical components (charging station, LED lights) away from water and moisture.
- Do not attempt to modify the electrical components. Contact qualified personnel for any repairs.
- Unplug the nightstand from the power outlet before cleaning or moving.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.



Image: An exploded view diagram illustrating all components and hardware included for the nightstand assembly.

Components:

- Top Panel
- Middle Shelf
- Bottom Frame
- Side Frames (2)
- Fabric Drawers (3)
- Charging Station Unit
- LED Light Strip

Hardware:

- Screws (various types)
- Allen Wrench
- Adjustable Feet (4)
- Remote Control for LED Lights

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes 10-15 minutes. Follow these steps carefully. A Phillips head screwdriver (not included) may be required in addition to the provided tools.

1. **Step 1: Assemble the Frame.** Attach the side frames to the bottom frame using the provided screws. Ensure all connections are secure.

2. **Step 2: Install Middle Shelf.** Secure the middle shelf to the side frames.
3. **Step 3: Attach Top Panel.** Fasten the top panel to the assembled frame.
4. **Step 4: Install Charging Station.** The charging station can be installed on either the front or back side of the middle shelf. Secure it with the designated screws.
5. **Step 5: Apply LED Light Strip.** Adhere the LED light strip to the underside of the top panel or the middle shelf as desired. Connect it to the charging station unit.
6. **Step 6: Insert Drawers.** Unfold the three fabric drawers and insert them into the designated compartments.
7. **Step 7: Adjust Feet.** Screw in the four adjustable feet at the bottom of the nightstand. Adjust them to ensure the unit is level and stable on your floor.



Image: Diagram illustrating the initial steps of assembling the nightstand's metal frame.



Gardez votre table de nuit bien rangée

3 tiroirs pratiques pour l'essentiel

Image: Diagram showing how to secure the middle shelf within the nightstand frame.



Éclairage d'ambiance intelligent

20 couleurs 21 modes

8 niveaux de réglage

Image: Diagram detailing the attachment of the top panel to complete the main structure.



Les autres

- ✘ Prises apparentes sur le dessus
- ✘ Câbles en désordre & rangement limité
- ✘ Risques de renversement de liquides



Le nôtre

- ✔ Prises discrètes intégrées sous la table
- ✔ Espace de rangement optimisé
- ✔ Design anti-renversement

Image: Diagram illustrating the installation of the charging station and LED light strip.



Image: A close-up view of one of the fabric drawers, highlighting its handle and texture.



Image: A detailed view of the adjustable foot, demonstrating its leveling capability.

5. OPERATING INSTRUCTIONS

5.1 Charging Station

The integrated charging station provides convenient power access for your devices.

- **Power Connection:** Plug the 2-meter power cord from the charging station into a standard wall outlet.
- **AC Outlets:** The station includes 2 AC outlets (120V/12A) for larger electronics like lamps or laptops.
- **USB Ports:** Two USB ports (5V/3A) are available for charging smartphones, tablets, and other USB-powered devices.
- **Usage:** Simply plug your devices into the appropriate outlets/ports. The charging station is designed for simultaneous charging of multiple devices.



Image: A detailed view of the integrated charging station, showing its two AC outlets and two USB ports in use.



Image: A close-up of the charging station, detailing its 120V/12A AC outlets and 5V/3A USB ports.

5.2 LED Lights

The LED light strip offers customizable ambient lighting for your room.

- **Power On/Off:** Ensure the nightstand is plugged in. Use the provided remote control to turn the LED lights on or off.
- **Color Selection:** Choose from 20 RGB colors to match your mood or decor.
- **Dynamic Modes:** Select from 21 dynamic modes for various lighting effects.
- **Speed and Brightness:** Adjust the speed of dynamic modes (8 settings) and the brightness of the lights (8 settings) using the remote control.



Image: The nightstand illuminated with blue LED lights, with the remote control shown in the foreground for adjusting settings.




Image: A close-up view of the remote control used to operate the LED lights, showing various color and mode buttons.

6. MAINTENANCE

- **Cleaning:** Wipe the engineered wood surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Fabric Drawers:** The fabric drawers are resistant to dust. For cleaning, gently wipe with a damp cloth. Do not machine wash.
- **Electrical Components:** Ensure the nightstand is unplugged before cleaning around the charging station or LED lights. Use a dry cloth to wipe these areas.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.



Image: A hand demonstrating how to clean the nightstand's surface with a damp cloth, highlighting its easy-to-clean material.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Nightstand is wobbly.	Uneven floor; loose connections.	Adjust the leveling feet at the bottom of the nightstand. Check and tighten all assembly screws.
Charging station not working.	Not plugged in; power outage; faulty device cable.	Ensure the nightstand's power cord is securely plugged into a live outlet. Check if the wall outlet has power. Try a different charging cable for your device.
LED lights not turning on.	Not plugged in; remote battery dead; LED strip connection loose.	Verify the nightstand is plugged in. Replace the remote control battery. Check the connection of the LED strip to the charging station unit.
Drawers do not slide smoothly.	Drawer not fully inserted; obstruction.	Ensure the fabric drawers are fully unfolded and correctly placed in their compartments. Check for any items obstructing the drawer's movement.

8. SPECIFICATIONS

Feature	Detail
Model Number	ED014 (hq-bzh014-02)
Brand	Seventable
Color	Black
Material	Engineered Wood, Metal Frame, Fabric Drawers
Overall Dimensions (L x W x H)	29.97 x 39.88 x 59.94 cm (11.8 x 15.7 x 23.6 inches)
Drawer Dimensions (L x W x H)	28 x 35 x 10 cm (11.0 x 13.8 x 3.9 inches)
Item Weight	6.3 kg (13.9 lbs)
Tabletop Weight Capacity	Up to 25 kg (55 lbs)
Each Drawer Weight Capacity	Up to 5 kg (11 lbs)
Charging Station	2 AC Outlets (120V/12A), 2 USB Ports (5V/3A)
Power Cord Length	2 meters (6.5 feet)
LED Lights	20 RGB Colors, 21 Dynamic Modes, 8 Speed Settings, 8 Brightness Settings
Special Features	Adjustable Feet, Water-resistant surface



Image: A technical diagram detailing the overall dimensions of the nightstand, drawer dimensions, and weight capacities for the tabletop and drawers.

9. WARRANTY AND SUPPORT

Seventable products are designed for quality and durability. For warranty information, missing parts, or technical support, please contact Seventable customer service through the retailer where the product was purchased. Please have your model number (ED014) and purchase date available when contacting support.

Note: Spare parts availability information is not provided by the manufacturer.

