Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GAOMON PHO_0YOJ2Y3N

GAOMON Storage Chest User Manual

Model: PHO_0YOJ2Y3N

Product Overview

The GAOMON Storage Chest is a versatile and robust furniture piece designed to enhance organization and comfort in various living spaces. It features ample internal storage, a comfortable cushioned lift-top, and safety hinges for secure operation. Its modern design with a brown wooden finish and metal frame makes it a suitable addition to bedrooms, entryways, and living rooms.



Image: The GAOMON Storage Chest with its lid open, revealing the spacious interior for storage.

Safety Information

- Ensure all components are securely fastened during assembly to prevent instability.
- The storage chest is equipped with safety hinges to prevent the lid from slamming shut. Always ensure these hinges are functioning correctly.
- Do not exceed the maximum weight capacity of 300 lbs on the top surface and 220 lbs inside the compartment.
- Keep small children away from the chest during opening and closing to avoid accidental pinching, despite safety features.
- Place the chest on a flat, stable surface to prevent tipping.



Image: A detailed view of the safety hinge, designed to prevent the lid from slamming.

Setup and Assembly

Assembly of the GAOMON Storage Chest typically requires two people for ease and safety. All necessary hardware and tools are usually included. Follow the step-by-step instructions provided in the packaging. Below are general steps and visual aids for reference.

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list.
2. **Assemble the Frame:** Connect the metal frame components as per the diagram.
3. **Attach Side and Bottom Panels:** Secure the engineered wood panels to the assembled frame.
4. **Install Hinges and Lid:** Attach the safety hinges to the main body and then secure the cushioned lid. Ensure hinges operate smoothly.
5. **Final Check:** Confirm all screws and fasteners are tightened and the chest is stable.



Image: All components laid out for assembly.



Image: Assembling the robust metal frame.



Image: Attaching the engineered wood panels.



Image: Installing the cushioned lid with safety hinges.

Operating Instructions and Usage

The GAOMON Storage Chest is designed for multi-functional use, serving both as a storage solution and a comfortable seating option.

Opening and Closing the Lid:

- To open, lift the lid using the front cut-out. The safety hinges will hold the lid open, preventing it from falling unexpectedly.
- To close, gently push the lid downwards. The safety hinges will provide a controlled descent, preventing a sudden slam.

Recommended Uses:

- **Entryway Bench:** Use as a convenient spot to sit while putting on or taking off shoes. Store shoes, bags, or other

entryway essentials inside.

- **Bedroom Storage:** Ideal for storing extra blankets, pillows, seasonal clothing, or linens at the foot of a bed.
- **Living Room Organizer:** Can function as a coffee table alternative, a footrest, or a discreet storage unit for toys, magazines, or media accessories.



Image: The storage chest functioning as an entryway bench.



Image: The chest used as a comfortable footrest in a living room setting.



Image: The chest used for storing bedding in a bedroom.

Maintenance and Care

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cushion Care:** The faux leather cushion can be wiped clean with a damp cloth. For spills, blot immediately and clean with a mild soap solution if necessary.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Moisture:** While durable, the engineered wood is not water resistant. Avoid prolonged exposure to moisture or direct sunlight to prevent warping or fading.

Troubleshooting

Problem	Possible Cause	Solution
Lid does not stay open or slams shut.	Safety hinges are not properly installed or are damaged.	Ensure hinges are correctly aligned and securely fastened. If damaged, contact customer support for replacement parts.
Chest feels wobbly or unstable.	Screws are loose or assembly was incomplete. Uneven floor surface.	Retighten all assembly screws. Ensure the chest is placed on a level surface. Use furniture pads if needed to level.
Difficulty opening or closing the lid.	Obstruction inside the chest or hinges are stiff.	Check for items blocking the lid's path. Apply a small amount of lubricant to the hinge joints if they are stiff.

Specifications

Feature	Detail
Brand	GAOMON
Model Number	PHO_0YOJ2Y3N
Color	Brown
Material	Engineered Wood, Metal Frame
Product Dimensions (L x W x H)	39.4" x 15.7" x 18.1"
Top Load Capacity	Up to 300 lbs
Internal Storage Capacity	Up to 220 lbs
Special Features	Space Saving, Safety Hinges, Cushioned Lift-top
Closure Type	Flip Top
Item Weight	46.6 lbs
UPC	196336740939



Image: Detailed dimensions and load capacities of the storage chest.

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact GAOMON customer service. Refer to your purchase documentation for specific warranty terms and contact details.
Customer Service: Please refer to the contact information provided with your product packaging or visit the official GAOMON website for support.

© 2025 GAOMON. All rights reserved.
For more information, visit GAOMON Brand Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJ5BW7MG

More documents and user manuals: **https://manuals.plus/**