

coldSky CY-608

coldSky Rechargeable Fabric Shaver

MODEL: CY-608 USER MANUAL

1. Introduction

Thank you for choosing the coldSky Rechargeable Fabric Shaver. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and keep it for future reference.



Image 1.1: Before and after using the coldSky Fabric Shaver on a sweater, demonstrating its effectiveness in removing lint and pills.

2. Product Features

- **Rechargeable with LED Digital Display:** The high-definition LED screen displays remaining battery power, selected speed level, and charging status. The built-in rechargeable battery charges fully in approximately 1 hour, reducing the need for frequent battery replacements.
- **Enhanced Cleaning Efficiency:** Equipped with an upgraded 6-leaf stainless steel blade and a powerful motor for effective lint removal. The stainless steel mesh cover features three different hole diameters to capture various sizes of lint and pills, ensuring thorough cleaning.

- **Three Adjustable Speeds:** Select from three speed settings to match different fabric types and pilling levels, ensuring optimal and safe performance across various materials.
- **Safety Lock and Fabric Protection:** The shaver automatically deactivates if the net cover is loosened or removed, enhancing user safety. The 3D contoured and thickened honeycomb protective net is designed to protect fabrics from damage while effectively removing pills.
- **Ergonomic Design and Accessories:** Lightweight and portable with an ergonomic handle for comfortable use. Includes an extra spare blade and a cleaning brush for extended product life and convenience.



Image 2.1: The coldSky Fabric Shaver's digital display, showing battery percentage and speed settings.

6-Leaf Stainless Steel Blades Paired with Powerful Motor



Extra Replacement Blade

Image 2.2: Detailed view of the shaver's 6-leaf stainless steel blades, designed for efficient lint removal.

3. What's in the Box

Your coldSky Fabric Shaver package includes:

- coldSky Rechargeable Fabric Shaver (Model CY-608)
- USB-C Charging Cable
- Extra Replacement Blade
- Cleaning Brush
- User Manual

Efficient and Smart Lint Shaver



Image 3.1: All components included in the coldSky Fabric Shaver package.

4. Setup

1. **Unpack:** Carefully remove all items from the packaging.
2. **Initial Charge:** Before first use, fully charge the fabric shaver. Connect the USB-C charging cable to the shaver's charging port and plug the other end into a compatible USB power adapter (not included). The LED display will show the charging status. A full charge typically takes about 1 hour.
3. **Check Blades:** Ensure the 6-leaf blade is securely installed. The shaver comes with the blade pre-installed. Refer to the 'Maintenance' section for blade replacement instructions.

5. Operating Instructions

1. **Power On/Off:** Press and hold the power button (located on the handle) for 2-3 seconds to turn the shaver on or off. The LED display will illuminate upon activation.
2. **Adjust Speed Settings:** Briefly press the power button to cycle through the three available speed settings (low, medium, high). The selected speed will be indicated on the LED display. Choose a lower speed for delicate fabrics and a higher speed for tougher materials or heavier pilling.
3. **Prepare Fabric:** Lay the garment or fabric flat on a hard, smooth surface. Stretch the fabric taut to ensure a smooth surface for shaving.
4. **Begin Shaving:** Gently glide the shaver head over the pillied area. Apply light, even pressure. Avoid pressing too hard, especially on delicate fabrics, to prevent damage. Move the shaver in small, circular motions or straight strokes.
5. **Monitor Lint Bin:** Periodically check the transparent lint collection bin. Empty it when it becomes full to maintain optimal performance.
6. **Safety Feature:** The shaver is equipped with a safety lock that automatically stops the blades if the mesh cover is loose or removed. Ensure the cover is securely fastened before operation.



Image 5.1: The digital display indicating the three adjustable speed settings.



Image 5.2: The coldSky Fabric Shaver is suitable for a wide range of fabrics and textures.

6. Maintenance

1. **Emptying the Lint Bin:** Twist the transparent lint collection bin counter-clockwise to detach it from the shaver body. Discard the collected lint.
2. **Cleaning the Blades:** Use the provided cleaning brush to gently remove any lint or debris from the

blades and the inner mesh. Be careful as the blades are sharp.

3. **Replacing Blades:** If the blades become dull or damaged, replace them with the extra blade provided. Carefully remove the old blade by twisting it off, then align and twist the new blade into place. Ensure it is securely fastened.
4. **Cleaning the Mesh Cover:** Wipe the stainless steel mesh cover with a soft, dry cloth. Do not use water or harsh chemicals.
5. **Storage:** Store the shaver in a cool, dry place away from direct sunlight and out of reach of children.

Transparent Large Lint Collection Bin



Image 6.1: The transparent lint collection bin, showing collected lint.

7. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery; Safety lock engaged.	Charge the device fully; Ensure the mesh cover is securely twisted into place.
Poor lint removal.	Full lint bin; Dull blades; Incorrect speed setting.	Empty and clean the lint bin; Replace the blades; Select a higher speed setting for tougher pilling.
Unusual noise during operation.	Lint/debris caught in blades; Loose blade.	Turn off and clean blades with brush; Ensure blade is securely installed.
Fabric damage.	Excessive pressure; Inappropriate speed for fabric type.	Use gentle pressure; Select a lower speed for delicate fabrics.

8. Specifications

Brand: coldSky

Model Number: CY-608

Material: Acrylonitrile Butadiene Styrene (Body), Alloy Steel (Handle)

Color: Black

Product Dimensions: 2.95"D x 3.15"W x 5.51"H

Item Weight: 0.33 Pounds

Operation Mode: Manual (referring to user-guided operation, not hand-powered)

UPC: 726047370165

9. Official Product Videos

Rechargeable Fabric Shaver Remove Fuzz Easily

Your browser does not support the video tag.

Video 9.1: A demonstration by a seller showing how the coldSky Fabric Shaver effectively removes fuzz from various fabrics.

Clothing Lint Shaver

Your browser does not support the video tag.

Video 9.2: A seller's review highlighting the performance of the coldSky Fabric Shaver on clothing.

Watch how well this works!

Your browser does not support the video tag.

Video 9.3: A seller demonstrating the effective lint removal capabilities of the coldSky Fabric Shaver.

Demonstration of fabric shaver on wool blanket

Your browser does not support the video tag.

Video 9.4: A seller showcasing the coldSky Fabric Shaver's performance on a wool blanket, effectively removing pills.

10. Warranty and Support

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official coldSky website. Keep your proof of purchase for any warranty claims.

© 2026 coldSky. All rights reserved.