

[Manuals.plus](#) /

› [T'nB](#) /

› T'nB KBWPRO Wireless Bluetooth Keyboard User Manual

T'nB KBWPRO



T'nB KBWPRO Wireless Bluetooth Keyboard User Manual

Model: KBWPRO

1. INTRODUCTION

Thank you for choosing the T'nB KBWPRO Wireless Bluetooth Keyboard. This ultra-thin, ergonomic keyboard is designed for comfortable and efficient typing across multiple devices. It features a long-lasting rechargeable battery, intuitive multimedia controls, and universal compatibility with Windows and macOS operating systems. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your keyboard.



Clavier sans fil

Connexion Bluetooth 5.0

Image 1.1: The T'nB KBWPRO Wireless Bluetooth Keyboard, showcasing its sleek design and Bluetooth 5.0 connectivity.

2. PRODUCT OVERVIEW

2.1 What's in the Box

- 1 x T'nB KBWPRO Wireless Bluetooth Keyboard
- 1 x USB-C Charging Cable

2.2 Key Features

- **Ultra-thin and Ergonomic Design:** Minimizes hand movement for comfortable typing.
- **Rechargeable Battery:** Integrated 400 mAh battery provides weeks of use on a single charge.
- **Universal Compatibility:** Works with Windows and macOS, as well as gaming consoles, laptops, PCs, and smartphones.
- **Multi-Device Connection:** Connects to up to three devices via Bluetooth.
- **Intuitive Multimedia Controls:** 13 integrated shortcuts for brightness, volume, and other functions.
- **Exceptional Typing Comfort:** Ultra-thin scissor keys offer precise and pleasant tactile feedback.

Format compact

et ergonomique pour un confort optimal




Image 2.1: Compact dimensions of the T'nB KBWPRO keyboard, measuring 37 cm in length and 12.5 cm in width.

3. SETUP GUIDE

3.1 Charging the Keyboard

1. Locate the USB-C charging port on the side of the keyboard.
2. Connect the provided USB-C cable to the keyboard and the other end to a USB power source (e.g., computer, wall adapter).
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.
4. A full charge provides several weeks of battery life.

Batterie rechargeable intégrée

pour une autonomie prolongée



Image 3.1: The keyboard's USB-C charging port and ON/OFF switch, highlighting its rechargeable battery.

3.2 Powering On/Off

Locate the ON/OFF switch on the side of the keyboard, next to the charging port. Slide the switch to 'ON' to power on the keyboard and to 'OFF' to power it down.

3.3 Bluetooth Pairing

The KBWPRO keyboard can connect to up to three devices. Follow these steps to pair your keyboard:

1. Ensure the keyboard is powered on.
2. On the keyboard, press and hold one of the Bluetooth channel keys **BT1**, **BT2**, or **BT3** for approximately 3 seconds until the corresponding indicator light starts blinking rapidly. This indicates the keyboard is in pairing mode.
3. On your device (computer, tablet, smartphone), go to the Bluetooth settings.
4. Search for available Bluetooth devices. You should see "T'nB KBWPRO" or a similar name appear in the list.
5. Select the keyboard from the list to initiate the connection. Your device may prompt you to enter a code displayed on the screen using the keyboard, then press Enter.
6. Once connected, the indicator light on the keyboard will stop blinking and remain solid for a few seconds before

turning off, indicating a successful pairing.

Note: Some older instructions may incorrectly state to use the 'Fn' key during pairing. For this model, simply press and hold the desired Bluetooth channel key (BT1, BT2, or BT3) directly.



Connectez jusqu'à 3 appareils

Compatible Windows et MacOS

Image 3.2: The keyboard's multi-device connectivity, allowing pairing with up to three different devices.

4. OPERATING INSTRUCTIONS

4.1 Basic Typing

The T'nB KBWPRO keyboard features a standard French AZERTY layout. Simply begin typing after successful pairing. The ultra-thin scissor keys are designed for a precise and comfortable typing experience.

Touches ciseaux ultra fines

pour une frappe précise et silencieuse



Image 4.1: Close-up view of the ultra-thin scissor keys, designed for quiet and precise typing.

4.2 Using Multimedia Keys

The keyboard includes 13 dedicated multimedia shortcuts located on the function key row (F1-F12, and Del). These keys allow for quick control of various device functions without needing to navigate through software menus.

- **F1-F12:** Typically control functions like media playback (play/pause, next/previous track), volume (mute, up, down), screen brightness, and other system functions.
- To activate these functions, press the desired multimedia key directly. On some operating systems, you may need to press the **Fn** key simultaneously with the function key.

Contrôle multimédia intuitif

pour une expérience utilisateur optimisée




Image 4.2: The function key row with integrated multimedia shortcuts for quick access to controls.

4.3 Switching Between Devices

If you have paired the keyboard with multiple devices (up to three), you can switch between them by simply pressing the corresponding Bluetooth channel key (**BT1**, **BT2**, or **BT3**) once. The keyboard will automatically connect to the last paired device on that channel.

4.4 Battery Status and Sleep Mode

- **Low Battery Indicator:** A red LED will blink to alert you when the battery is low and requires charging.
- **Automatic Sleep Mode:** To conserve battery, the keyboard will enter sleep mode after a period of inactivity.
- **Waking Up the Keyboard:** Press any key to wake the keyboard from sleep mode. Note that there may be a slight delay (approximately 1 second) before the keyboard fully reconnects and responds.

5. MAINTENANCE

5.1 Cleaning

To clean your keyboard, gently wipe the surface with a soft, damp, lint-free cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the keyboard.

5.2 Storage

When not in use for extended periods, store the keyboard in a cool, dry place. Ensure the keyboard is powered off to preserve battery life.

6. TROUBLESHOOTING

If you encounter issues with your T'nB KBWPRO keyboard, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Keyboard does not pair or connect via Bluetooth.	• Ensure the keyboard is powered on and fully charged. • Make sure the keyboard is in pairing mode (indicator light blinking rapidly) by pressing and holding the desired BT1/BT2/BT3 key for 3 seconds. • Check your device's Bluetooth settings and ensure Bluetooth is enabled. • Remove any previous pairings of the keyboard from your device's Bluetooth list and try pairing again. • Restart both the keyboard and your device.
Keys are unresponsive or typing is inconsistent (e.g., spacebar issues).	• Ensure the keyboard is fully charged. Low battery can affect performance. • Check for any physical obstructions under the keys. • Ensure the keyboard is within the effective range of your Bluetooth device (typically up to 10 meters). • Interference from other wireless devices can affect connection stability. Try moving closer to your device or away from other wireless sources.
Incorrect characters appear when typing, or certain keys do not function as expected (e.g., 'Delete' key).	• Verify that your device's operating system is set to the correct keyboard layout (French AZERTY). • Ensure the keyboard is correctly paired to the appropriate operating system mode (Windows or macOS, if applicable, though this keyboard is universally compatible).
Keyboard experiences latency or slow response after waking from sleep mode.	• This is normal behavior as the keyboard re-establishes its Bluetooth connection. Allow a moment for it to reconnect after pressing a key to wake it up. • If latency persists, try re-pairing the keyboard.

Problem	Possible Cause / Solution
Keyboard does not work when connected via USB cable.	The USB-C cable is for charging purposes only. The T'nB KBWPRO is a wireless Bluetooth keyboard and does not function as a wired keyboard.

7. SPECIFICATIONS

Feature	Detail
Model Name	KBWPRO
Connectivity Technology	Bluetooth 5.0
Keyboard Layout	French AZERTY
Battery Capacity	400 mAh (Rechargeable)
Dimensions (L x W x H)	37 x 12.5 x 2 cm (14.57 x 4.92 x 0.79 inches)
Product Weight	426 Grams (0.94 lbs)
Compatible Devices	Windows PCs, macOS computers, Laptops, Smartphones, Gaming Consoles
Special Features	Portable, Multimedia Shortcuts, Rechargeable
Color	Grey Blue
Power Source	Battery Powered

8. WARRANTY AND SUPPORT

8.1 Manufacturer's Warranty

The T'nB KBWPRO Wireless Bluetooth Keyboard comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact T'nB customer service. Our support team is based in France and is dedicated to providing solutions for your product needs.

Please visit the official T'nB website for contact information or to submit a support request.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CJ5L6312>

More documents and user manuals: <https://manuals.plus/>