

[Manuals.plus](#) /

› [WINICE](#) /

› WINICE Dino-001 Star Projector Night Light User Manual

WINICE dino-001

WINICE Dino-001 Star Projector Night Light User Manual

Model: Dino-001 | Brand: WINICE

1. INTRODUCTION

Thank you for choosing the WINICE Dino-001 Star Projector Night Light. This device is designed to create a captivating and soothing environment with its vibrant projections, adjustable lighting, and built-in lullabies. Please read this manual carefully to ensure proper use and to maximize your enjoyment of the product.



Image 1.1: The WINICE Dino-001 Star Projector Night Light in operation, projecting colorful dinosaur shapes onto a room's ceiling and walls, with a baby observing the display.

2. SAFETY INFORMATION

- Keep the device away from water and moisture.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Use only the provided USB charging cable.
- Small parts, such as projection films, can be a choking hazard. Keep them out of reach of small children.
- Avoid direct eye exposure to the light source for extended periods.
- Ensure the device is placed on a stable, flat surface to prevent falling.

3. PACKAGE CONTENTS

Please check the package for the following items:

- WINICE Dino-001 Star Projector Night Light (Blue Dinosaur)
- USB Charging Cable
- 6 Interchangeable Projection Films (e.g., Starry Sky, Ocean, Christmas, Birthday, Planet, Dinosaur)
- User Manual

4. PRODUCT OVERVIEW

The WINICE Dino-001 features a charming dinosaur design and multiple functions including a projector, night light, and table lamp. Familiarize yourself with the device's components:



Image 4.1: Multi-functional diagram illustrating the projector's various modes and features.



Image 4.2: Front view of the projector, highlighting its design.



Image 4.3: Side view of the projector, indicating the location of control buttons and the USB charging port.

Control Buttons:

- **Power Button:** Turns the device On/Off.
- **Light Color Button:** Cycles through white, blue, and warm yellow light colors.
- **Rotation Button:** Activates or deactivates the 360° projection rotation.
- **Music Button:** Plays or pauses the built-in lullabies.
- **Brightness Adjustment:** Dims or brightens the projection (often integrated with light color button or a separate touch control).

The device also features a USB charging port and a transparent lampshade for projection.

5. SETUP INSTRUCTIONS

5.1 Charging the Device

Before first use, fully charge the projector. Connect the provided USB charging cable to the projector's USB port and plug the other end into a compatible USB power adapter (not included) or a computer's USB port. The charging indicator light will show the

charging status. The device is powered by a 1200mAh rechargeable battery.

5.2 Installing Projection Films

The projector comes with 6 interchangeable projection films to vary the visual themes.

1. Gently remove the transparent lampshade from the top of the projector.
2. Locate the inner projection cylinder.
3. Carefully insert your desired projection film into the cylinder, ensuring it is properly seated.
4. Replace the transparent lampshade if you wish to use it as a night light, or leave it off for clearer projection.



6 Slides Available

Dinosaur

Christmas

Birthday

Seabed

Planet

Starry sky



Image 5.1: The six interchangeable projection films.



Image 5.2: Illustration demonstrating the effect of removing the lampshade for a clear projection.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **Power Button** once to turn the projector on. Press it again to turn the projector off.

6.2 Adjusting Light Colors

Press the **Light Color Button** to cycle through the available light colors: white, blue, and warm yellow. You can also combine colors for unique effects.




Image 6.1: The three adjustable lighting colors: white, yellow, and blue.

6.3 Activating Rotation

Press the **Rotation Button** to start the 360° rotation of the projected images. Press it again to stop the rotation.

6.4 Playing Lullabies

Press the **Music Button** to play the built-in lullabies. Press it again to pause. The projector includes 8 soothing melodies.

6.5 Adjusting Brightness

The projector features dimmable brightness. This function is typically controlled by holding down the Light Color Button or through a dedicated touch control area. Refer to the specific button labels on your device for precise operation.

7. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Projector does not turn on.	Battery is low or depleted.	Charge the device using the USB cable.
Projection is blurry.	Lampshade is on.	Remove the transparent lampshade for a clearer projection.
Projection is not rotating.	Rotation function is off.	Press the Rotation Button to activate.
No sound from lullabies.	Music function is off or volume is too low.	Press the Music Button to play. Ensure no external audio is interfering.

9. SPECIFICATIONS

Feature	Detail
Model Name	Dinosaur lamp (dino-001)
Brand	WINICE
Color	Blue Dinosaur
Material	Plastic
Product Dimensions	5"D x 5"W x 5"H
Item Weight	12.5 ounces
Light Source Type	LED
Number of Light Sources	3
Power Source	Battery Powered (1 Lithium Ion battery included)
Control Method	Touch
Special Feature	Auto off, 360° Rotation, Dimmable Brightness, 8 Lullabies, 6 Projection Films
Indoor/Outdoor Usage	Indoor

10. WARRANTY AND SUPPORT

10.1 Warranty Information

This product comes with a 1-year manufacturer's warranty. Please retain your proof of purchase for warranty claims.

10.2 Customer Support

For any questions, concerns, or technical support regarding your WINICE Dino-001 Star Projector Night Light, please contact WINICE Direct. We are committed to providing the highest standard of service and will assist you promptly to ensure your satisfaction.

You can visit the official WINICE store on Amazon for more information: [WINICE Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question