

INOI T1072DJARSG

INOI Tablet 10.1" User Manual

MODEL: T1072DJARSG

1. Product Overview

The INOI Tablet 10.1" (Model: T1072DJARSG) is a versatile and portable device designed for entertainment, productivity, and communication. Featuring a 10.1-inch HD+ display, 4GB RAM, 128GB internal storage, and a robust 6000 mAh battery, it offers a seamless user experience powered by Android 13 OS. This manual provides essential information to help you get the most out of your tablet.



Front and back view of the INOI Tablet 10.1 inch, showcasing its sleek design and camera module.



Size is Making the Difference

Enjoy expansive 10.1-inch display of the inoiPad. Whether you're watching videos, editing photos, or working, the display ensures an engaging and immersive viewing experience.

Measured diagonally. Actual viewable area is less due to the rounded corners.

The INOI Tablet 10.1 inch with its physical dimensions indicated in millimeters (243mm length, 160mm width, 9.3mm thickness).

2. Getting Started: Setup

2.1. Initial Charging

Before first use, fully charge your INOI Tablet. Connect the provided USB cable to the tablet's charging port and the other end to a compatible power adapter. A charging indicator will appear on the screen.

2.2. Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the INOI logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears. Select "Power off" and confirm.
- **To Restart:** From the power options menu, select "Restart".

2.3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup process. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, pattern, password).

2.4. SIM Card Insertion (for 4G LTE models)

If your tablet supports 4G LTE, you can insert a SIM card for mobile data connectivity.

1. Locate the SIM card tray on the side of the tablet.
2. Use the SIM ejector tool (if provided) to open the tray.
3. Place the Nano-SIM card into the tray with the gold contacts facing down.
4. Gently push the tray back into the tablet until it clicks into place.

3. Operating Your Tablet

3.1. Basic Navigation

The INOI Tablet uses touch gestures for navigation:

- **Tap:** To select an item or open an app.
- **Tap and Hold:** To access contextual menus or move icons.
- **Swipe:** To scroll through screens or lists.
- **Pinch:** To zoom in or out on content.

3.2. Display and Visuals

Enjoy an expansive 10.1-inch HD+ display with a resolution of 1280 x 800 pixels, ensuring an engaging and immersive viewing experience for videos, photos, and work.

Size is Making the Difference

Enjoy expansive 10.1-inch display of the inoiPad. Whether you're watching videos, editing photos, or working, the display ensures an engaging and immersive viewing experience.



The 10.1-inch display of the INOI Tablet, ideal for multimedia consumption and productivity.

3.3. Connectivity (Wi-Fi and 4G LTE)

The tablet supports both Wi-Fi (802.11a/b/g/n) and 4G LTE for flexible internet access.

- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi* to connect to available networks.
- **Mobile Data (4G LTE):** Ensure your SIM card is inserted correctly. Go to *Settings > Network & internet > Mobile network* to manage data settings.



**Stay Connected
Anywhere, Anytime**

Experience uninterrupted connectivity with LTE support and Dual SIM capability. Enjoy fast and reliable connection on the go with lightning-fast internet access and manage personal and work routine effortlessly.

Enjoy the flexibility of choosing the best network for your needs, ensuring you never miss a beat.

The INOI Tablet offers robust connectivity options, including 4G LTE, allowing you to stay connected anywhere.

3.4. Camera Usage

The tablet is equipped with an 8 MP front-facing camera for video calls and a 13 MP rear camera with autofocus and an LED flash for capturing photos and videos.

- Open the Camera app from your home screen or app drawer.
- Tap the camera icon to switch between front and rear cameras.
- Tap the shutter button to take a photo or start/stop video recording.

Cherish the Moment

Keep in touch with your loved ones with 8 MP front-facing camera which is perfect for video calls. Share the videos made on 13 MP rear camera with autofocus and an LED flash.



Detail of the INOI Tablet's rear camera module, featuring a 13 MP sensor and LED flash.

3.5. Battery Management

The tablet features a long-lasting 6000 mAh battery, providing extended usage time.

- To check battery status, go to *Settings > Battery*.
- Enable Battery Saver mode to extend battery life when needed.
- Avoid extreme temperatures to preserve battery health.

Endless Entertainment

Immerse yourself in a world of entertainment with the inoiPad's long-lasting 6,000 mAh battery, providing hours of uninterrupted usage. Whether you're browsing the web, gaming, or streaming your favorite movies and shows, you can dive deep in endless entertainment without worrying about running out of power.




*Typical value tested under third-party laboratory condition.

Visual representation of the INOI Tablet's powerful 6000 mAh battery, designed for extended use.

3.6. Android 13 Operating System

The INOI Tablet runs on Android 13, offering an enhanced user interface, improved security, and access to a vast array of applications and modern features for a flawless digital experience.



The INOI Tablet running on the Android 13 operating system, showcasing its modern interface.

4. Maintenance

4.1. Cleaning the Device

Use a soft, lint-free cloth to clean the tablet's screen and body. Avoid using harsh chemicals or abrasive materials that could damage the surface.

4.2. Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to *Settings > System > System update*

4.3. Storage Management

To free up storage space, consider uninstalling unused apps, deleting old files, or moving large files to cloud storage or an external memory card (if supported). Go to *Settings > Storage*.

5. Troubleshooting

5.1. Common Issues and Solutions

- **Device not turning on:** Ensure the battery is charged. Press and hold the Power button for at least 10-15 seconds.
- **Wi-Fi connection issues:** Restart your tablet and Wi-Fi router. Forget the network in settings and reconnect.
- **Apps crashing or freezing:** Close the app and reopen it. Clear the app's cache (*Settings > Apps > [App Name] > Storage & cache > Clear cache*).
- **Slow performance:** Close background apps, clear cache, and ensure sufficient storage space.

5.2. Factory Reset

If issues persist, you may consider a factory reset. **Warning: This will erase all data on your tablet. Back up important data before proceeding.**

1. Go to *Settings > System > Reset options*
2. Select "Erase all data (factory reset)".
3. Confirm your decision and follow the on-screen prompts.

6. Specifications

Feature	Specification
Brand	INOI
Model Name	T1072DJARSG
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 pixels (HD Ready)
Processor Brand	Unisoc
Processor Speed	2 GHz
RAM Size	4 GB
Memory Storage Capacity	128 GB
Connectivity Type	Cellular, Wi-Fi (802.11n, 802.11b, 802.11a, 802.11g)
Front Webcam Resolution	2 MP
Rear Camera Resolution	13 MP (with autofocus and LED flash)
Battery Capacity	6000 mAh (22.8 Watt Hours)
Operating System	Android 13
Color	Space Gray
Item Weight	96.3 g

Feature	Specification
Package Dimensions	27.6 x 19.3 x 4.4 cm

7. Warranty and Support

7.1. Manufacturer Warranty

The INOI Tablet comes with a manufacturer warranty for 1 year from the date of purchase. Please retain your proof of purchase for warranty claims.

7.2. Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact INOI customer support through their official website or the contact information provided with your product packaging.