

VOCOLinc VT2202

VOCOLinc Wallet Tracker Card Instruction Manual

MODEL: VT2202

Introduction

The VOCOLinc Wallet Tracker Card is an ultra-thin, IP67 waterproof Bluetooth tracker designed to help you locate your valuable belongings. Compatible exclusively with iOS devices, it leverages the Apple Find My network for both nearby and far-away tracking. Featuring a loud built-in speaker, left-behind alerts, and an NFC function for easy recovery, this tracker ensures peace of mind for items like wallets, luggage, bags, and more. Its long-lasting, non-replaceable battery provides up to 3 years of use.

Key features include:

- **Ultra-thin Design:** Measures only 0.16cm (0.06in) thickness, fitting seamlessly into wallets.
- **Find My Network Compatibility:** Utilizes millions of iOS devices worldwide for extensive tracking.
- **Loud Built-in Speaker:** Emits an 80-100 dB beep for easy nearby location.
- **Left-behind Alerts:** Notifies you instantly if your item disconnects from your iOS device.
- **Built-in NFC Function:** Allows finders to contact you easily if your item is lost.
- **IP67 Water-Resistant:** Designed to withstand splashes and dust.
- **Long-lasting Battery:** Provides up to 3 years of power with a non-replaceable battery.



The VOCOLinc Wallet Tracker Card, designed for seamless integration into your wallet.


Setup

Pairing with Apple Find My App

The VOCOLinc Wallet Tracker Card is designed for easy pairing with your iOS device. Follow these steps to connect your tracker:

1. Ensure your iOS device's Bluetooth is activated.
2. Quickly press the tracker card's power button to turn it on. Place it near your iOS device.
3. Open the **Find My** app on your iOS device.
4. Tap on the **"Items"** tab.
5. Tap **"Add Item"**, then select **"Other Supported Item"**.
6. Follow the on-screen instructions within the app to complete the pairing process.

Note: This wallet tracker is only compatible with iOS devices, not Android.



80-100 dB
Loud Sound



Up to 200ft/60m
Bluetooth range



IP67
Waterproof



Up to 3 years of
non-replaceable batteries

Visual guide for the pairing process with the Find My app.

[Official Pairing Tutorial Video](#)

Watch this video for a step-by-step guide on how to pair your VOCOLinc Wallet Tracker Card with your iOS device.

Operating Instructions

Locating Your Item

The VOCOLinc Wallet Tracker offers multiple ways to locate your belongings:

Find Nearby

When your item is within Bluetooth range (up to 200ft/60m), you can use the Find My app to make the tracker emit a loud beep sound (80-100 dB). This audible alert will guide you directly to your misplaced item.

Lost **your item** nearby?

Find it with a tap of a button on your cellphone



Easily find your lost item nearby by tapping a button on your cellphone to activate the tracker's sound.

Find Far Away

If your tracker card is lost outside the 200ft/60m Bluetooth range, the Apple Find My network comes into play. This vast network connects with millions of iOS devices globally, providing an extensive tracking feature. You can view your item's last known location on a map within the Find My app, helping you navigate to its vicinity. Your privacy and safety are protected through the anonymous and encrypted nature of the Find My network.

Find Far Away


When outside of Bluetooth range, use the Find My app to view it on the map and direct you to the vicinity of VOCOLinc



When outside Bluetooth range, use the Find My app to view your item on the map and direct you to its location.

Left-behind Alerts

Never worry about leaving your valuable items behind again. The Find My app will instantly notify you if your VOCOLinc Wallet Tracker disconnects from your iOS device's Bluetooth. This proactive alert ensures you are always aware if you accidentally leave your belongings behind.



Receive instant notifications if your tracker is left behind, ensuring you never lose track of your items.

Built-in NFC Function

The tracker includes a built-in NFC function to facilitate the recovery of lost items. By adding your contact information, anyone who finds your lost item with the Wallet Tracker can simply use NFC to access your details and get in touch with you, making the recovery process smoother.

Get Lost Person's Contact by NFC




The NFC function allows anyone who finds your lost item to easily contact you.

Maintenance

Care and Battery Life

The VOCOLinc Wallet Tracker Card is designed for durability and long-term use:

- **IP67 Water-Resistant:** The tracker is rated IP67, meaning it is protected from dust and can withstand immersion in water up to 1 meter for up to 30 minutes. This ensures it can handle everyday splashes and accidental exposure to water.
- **Long-lasting Battery:** The built-in Lithium Metal battery provides power for up to 3 years. The battery is non-replaceable, ensuring a compact and sealed design.



The IP67 water-resistant design protects your tracker from splashes and dust.

General Care

To ensure the longevity of your tracker, avoid exposing it to extreme temperatures, harsh chemicals, or physical impact beyond its intended use. Clean with a soft, dry cloth if necessary.

Troubleshooting

If you encounter issues with your VOCOLinc Wallet Tracker Card, please refer to the following common troubleshooting tips:

- **Tracker not connecting to Find My app:**

- Ensure Bluetooth is enabled on your iOS device.
- Make sure the tracker is powered on and within range of your device.
- Restart your iOS device and try pairing again.
- Check if the tracker's battery life is depleted (though it lasts up to 3 years, extreme conditions might affect it).

- **No sound from the tracker:**

- Verify that the volume on your iOS device is not muted or too low.
- Ensure the tracker is within audible range.
- Check Find My app settings to confirm sound alerts are enabled for the tracker.

- **Inaccurate location or frequent disconnections:**

- Ensure your iOS device has a stable internet connection (Wi-Fi or cellular data) for accurate location updates via the Find My network.
- Avoid placing the tracker in areas with significant metal or electronic interference.
- Update your iOS device to the latest software version.

If these steps do not resolve the issue, please contact customer support for further assistance.

Product Specifications

Feature	Detail
---------	--------

Product Dimensions	3.35 x 2.13 x 0.06 inches (8.5cm x 5.4cm x 0.16cm)
Item Weight	0.634 ounces
Model Number	VT2202
Battery Type	1 Lithium Metal battery (included, non-replaceable)
Battery Life	Up to 3 years
Water Resistance	IP67
Connectivity	Bluetooth
Compatible Devices	iOS devices (Tablet, Smartphone)
Tracking Range	Up to 200ft/60m (Bluetooth)



The ultra-thin design allows for versatile use in various items.

Warranty and Support

For warranty information and customer support, please refer to the product packaging or visit the official VOCOLinc website. You can also contact the seller directly through your purchase platform for assistance with your VOCOLinc Wallet Tracker Card.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question