

Dioche Diochet6qrm8o1sd-11

Dioche Hair Clipper Replacement Head for 787 Instruction Manual

1. INTRODUCTION AND OVERVIEW

This manual provides instructions for the Dioche Hair Clipper Replacement Head, designed specifically for **model 787 clippers**. This waterproof T-shaped blade is engineered for precise cutting and is suitable for both home and professional grooming applications. Please read these instructions carefully before installation and use to ensure optimal performance and longevity of your replacement head.



Figure 1: Overall view of the Dioche Hair Clipper Replacement Head.

2. PRODUCT FEATURES

- **High-Quality Material:** Constructed from durable stainless steel, ensuring long-lasting sharpness and resistance to wear.
- **Easy Installation:** Designed for quick and secure attachment to compatible clippers via a simple docking and buckle mechanism.
- **Excellent Performance:** Features an innovative cutting edge with 12 precise cuts, providing a smooth and accurate grooming experience.
- **Multipurpose Use:** Versatile for various grooming tasks, including cutting hair, shaving beards, and trimming eyebrows.
- **Waterproof Design:** Allows for easy cleaning under running water, promoting hygiene and preventing rust.



Sharp head

Ensure that every cut is accurate and the result is more professional.

Suitable for home and professional hairdressers

Figure 2: The sharp head design ensures accurate and precise cutting for various grooming needs.

3. SETUP AND INSTALLATION

The Dioche Hair Clipper Replacement Head is designed for straightforward installation. Follow these steps to replace your clipper head:

1. Ensure your clipper is turned off and disconnected from any power source.
2. Carefully remove the existing clipper head according to your clipper's specific instructions.
3. Align the new Dioche replacement head with the docking port on your clipper.
4. Gently push the head into place until it clicks and the buckle secures it firmly.
5. Verify that the head is securely attached before turning on the clipper.



Figure 3: The replacement head's attachment mechanism for easy installation.

4. OPERATING INSTRUCTIONS

Once the replacement head is securely installed, your clipper is ready for use. The T-shaped blade is optimized for precise trimming and cutting of hair, beards, and other body hair. Always ensure the clipper is clean and properly maintained for optimal performance.

- Turn on your clipper and begin grooming as desired.
- Move the clipper smoothly against the direction of hair growth for effective cutting.
- For best results, ensure hair is clean and dry before trimming, unless using a wet-shave technique with appropriate products.

Applicable Model: For 787




Figure 4: The clipper head in action, suitable for shaving and trimming.

Your browser does not support the video tag.

Video 1: A short demonstration showcasing the Dioche Hair Clipper Replacement Head from various angles, highlighting its design and features.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Dioche Hair Clipper Replacement Head.

- **Regular Cleaning:** After each use, turn off and disconnect the clipper. Remove the head and rinse it thoroughly with clean water to remove all hair and debris.
- **Drying:** Allow the clipper head to air dry completely before reattaching it to the clipper or storing it.
- **Rust Prevention:** The blades are designed to be anti-rust. However, proper drying after rinsing is crucial to maintain this property.
- **Replacement Schedule:** For consistent performance and hygiene, it is recommended to replace the clipper head every **12 months**, or sooner if you notice a decrease in cutting efficiency.

6. TROUBLESHOOTING

If you encounter issues with your clipper head, consider the following:

- **Poor Cutting Performance:** Ensure the clipper head is clean and free of hair buildup. Verify it is securely installed on the clipper. If issues persist, the blade may be dull and require replacement.
- **Head Not Attaching Securely:** Check for any obstructions in the docking port or on the head itself. Ensure the buckle mechanism is functioning correctly.
- **Unusual Noise:** This may indicate improper installation or damage. Reinstall the head and inspect for any visible damage.

7. SPECIFICATIONS

Item Type	Hair Trimmer Head
Material	Stainless steel
Applicable Model	For 787
Package Dimensions	4.72 x 3.94 x 0.79 inches
Weight	1.45 ounces
Model Number	Diochet6qrm8o1sd-11
Manufacturer	Dioche

8. WARRANTY AND SUPPORT

For product support, inquiries, or specific warranty information, please refer to your purchase documentation or contact Dioche customer service directly. Warranty terms may vary based on your region and point of purchase.