

SoBuy KLS03-HG

SoBuy KLS03-II-HG Telescopic Garment Rack Instruction Manual

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your SoBuy KLS03-II-HG Telescopic Garment Rack. Please read all instructions carefully before beginning assembly or use to ensure proper installation and safe operation. Keep this manual for future reference.

2. PRODUCT FEATURES AND OVERVIEW

The SoBuy KLS03-II-HG Telescopic Garment Rack is designed for versatile and flexible clothing storage. Its robust construction and adjustable design make it suitable for various room layouts without requiring permanent installation.

- **Durable Construction:** Manufactured from sturdy metal tubes and strong plastic connectors, ensuring stability and longevity.
- **Adjustable Dimensions:** Features telescopic rods allowing for adjustable width (124–226 cm) and height (200–295 cm) to fit diverse spaces.
- **High Load Capacity:** The metal frame is designed to support a total load of up to 65 kg, accommodating a significant amount of clothing.
- **Modular Design:** Composed of 3 adjustable bars and 4 hanging rails, providing a customizable open wardrobe system.
- **Integrated Accessories:** Includes a multi-purpose side hook for organizing hats, coats, ties, scarves, and bags, with additional hooks provided.
- **Tool-Free Assembly:** Designed for quick and easy assembly without the need for specialized tools, preventing damage to walls or ceilings.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are

missing or damaged, please contact customer support.

- Telescopic vertical poles (adjustable height)
- Horizontal hanging bars (adjustable width)
- Plastic connectors and clamps
- Side hook for accessories
- Additional hanging hooks
- Assembly instructions (illustrated)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the SoBuy KLS03-II-HG garment rack is designed to be straightforward and tool-free. Follow these steps for proper installation.

1. **Prepare the Area:** Choose a suitable location for your garment rack. Ensure the floor and ceiling surfaces are clean and stable.
2. **Assemble Vertical Poles:** Connect the sections of the vertical telescopic poles. Adjust the height of each pole to be slightly shorter than your ceiling height.
3. **Position Vertical Poles:** Place the assembled vertical poles in their desired positions. Extend each pole by twisting or using the locking mechanism until it firmly presses against the ceiling and floor. Ensure they are plumb and stable.
4. **Attach Horizontal Bars:** Secure the plastic connectors to the vertical poles at your desired heights. Insert the horizontal hanging bars into these connectors. Adjust the width of the horizontal bars as needed and secure them.
5. **Install Side Hook:** Attach the side hook to one of the vertical poles at a convenient height for hanging accessories.
6. **Final Adjustments:** Double-check all connections and ensure all poles and bars are securely locked in place. The rack should feel stable and not wobble.



Figure 1: This diagram illustrates the adjustable ranges for the height, width, and depth of the garment rack, along with the dimensions of the side hook.



Figure 2: This image shows the mechanism used to adjust the height and width of the telescopic rods, ensuring a secure fit between floor and ceiling.

5. OPERATING INSTRUCTIONS

The SoBuy KLS03-II-HG garment rack offers flexible storage solutions. Utilize its features to organize your clothing and accessories efficiently.

- **Adjusting Height and Width:** To modify the height of the vertical poles or the width of the horizontal bars, loosen the locking mechanisms, adjust to the desired dimension, and then firmly re-secure the locks. Ensure the rack remains stable after any adjustments.
- **Using Hanging Rails:** Hang clothes directly on the horizontal bars using standard hangers. Distribute weight evenly across the bars to maintain stability.
- **Utilizing Side Hooks:** The integrated side hook and additional hooks are ideal for hanging items like hats, scarves, ties, belts, or handbags.
- **Configuration Options:** The modular design allows for various configurations, including straight wall setups or corner arrangements, to best suit your space.



Figure 3: An example of the garment rack installed in a corner, demonstrating its capacity for hanging clothes and utilizing the side hook for bags.



Figure 4: Detail of the integrated side hook, designed for hanging accessories such as scarves, ties, hats, or bags.



Figure 5: An example of the garment rack installed along a straight wall, showcasing its modular design and capacity for organizing different types of clothing.

6. MAINTENANCE

Regular maintenance will help prolong the life and functionality of your garment rack.

- **Cleaning:** Wipe down metal and plastic surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Check Connections:** Periodically inspect all telescopic locks and connectors to ensure they remain tight and secure. Re-tighten if necessary to maintain stability.
- **Weight Distribution:** Always distribute the weight of your clothes and accessories evenly across the hanging bars to prevent strain on individual components. Do not exceed the maximum load capacity of 65 kg.

7. TROUBLESHOOTING

If you encounter any issues with your garment rack, refer to the following common troubleshooting tips:

- **Rack is Unstable/Wobbles:**
 - Ensure all telescopic poles are fully extended and securely locked between the floor and

ceiling.

- Verify that all horizontal bar connectors are tightly fastened to the vertical poles.
- Check if the weight of the clothes is evenly distributed.

- **Difficulty Adjusting Height/Width:**

- Ensure the locking mechanisms are fully disengaged before attempting to adjust.
- Clean any dust or debris from the telescopic sections that might be impeding movement.

- **Parts are Missing or Damaged:**

- Refer to the package contents list. Contact SoBuy customer support for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Model Number	KLS03-HG
Dimensions (L x W x H)	Adjustable: L 124-226 cm x H 200-295 cm
Product Dimensions (Overall)	27 x 226 x 295 cm (Depth x Width x Height)
Weight	5.4 Kilograms
Material	Stainless Steel, Plastic
Color	Grey
Maximum Load Capacity	65 Kilograms
Number of Shelves/Bars	3 bars (horizontal)
Special Feature	Space Saver
Assembly Required	Yes (Tool-free assembly)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact SoBuy customer service directly. Keep your proof of purchase for any warranty claims.