

DHG Portable Bluetooth Speaker User Manual

PRODUCT OVERVIEW

This manual provides comprehensive instructions for the DHG Portable Bluetooth Speaker.

Model: DHG1

ASIN: B0CJC2YLF7

The DHG Portable Bluetooth Speaker is designed for wireless music streaming from various devices. It features a compact and portable design with a convenient handle, making it easy to transport. Key functionalities include Bluetooth connectivity, a USB/SD card reader, FM radio, and a karaoke function. It is equipped with a built-in 1200 mAh rechargeable battery and delivers 20W of power.



Image: DHG Portable Bluetooth Speaker, showcasing its portable design with a top handle and front speaker grille.

WHAT'S IN THE BOX

- DHG Portable Bluetooth Speaker
- Remote control
- Charging cable

KEY FEATURES

- Wireless Bluetooth Connectivity
- Integrated USB and SD Card Reader
- Built-in FM Radio Function
- Karaoke Function with Microphone Input
- Rechargeable Battery (1200 mAh)
- Portable Design with Carry Handle

- 20W Output Power

SETUP GUIDE

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the included charging cable to the **DC-5V** port on the speaker and to a suitable USB power adapter (not included). The charging indicator will illuminate. A full charge ensures optimal battery performance.

2. Powering On/Off

Locate the power switch on the control panel. Slide it to the '**ON**' position to power on the speaker. Slide to '**OFF**' to power off.

3. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED (if applicable).
2. On your smartphone, tablet, or other Bluetooth-enabled device, enable Bluetooth.
3. Search for available devices and select '**DHG1**' or a similar name to connect.
4. A confirmation sound will indicate successful pairing.

4. Connecting a Microphone (for Karaoke)

Insert a 6.35mm jack microphone (not included) into the '**MIC.**' input port on the speaker's control panel.



Image: Close-up view of the speaker's control panel, showing the microphone input, USB and TF card slots, AUX input, mode button, volume knob, and DC-5V charging port.

OPERATING INSTRUCTIONS

1. General Controls

- Volume Knob:** Rotate clockwise to increase volume, counter-clockwise to decrease.
- MODE Button:** Press to cycle through available modes: Bluetooth, FM Radio, USB, SD, and AUX.
- Play/Pause Button (▶/-):** Press to play or pause audio playback. In FM mode, press and hold to auto-scan for radio stations.
- Previous Track/Volume Down (◀/-):** Press briefly to go to the previous track. Press and hold to decrease volume.
- Next Track/Volume Up (▶/+):** Press briefly to go to the next track. Press and hold to increase volume.

2. Bluetooth Mode

Once paired, ensure your device's volume is up. Play audio from your connected device, and it will stream wirelessly through the speaker.

3. USB/SD Card Playback

Insert a USB flash drive or an SD card (containing MP3 audio files) into the corresponding slot. The

speaker will automatically switch to USB or SD mode and begin playing the first track. Use the Previous/Next track buttons to navigate through your music.

4. FM Radio Operation

1. Press the **MODE** button to select FM Radio mode.
2. Press and hold the **Play/Pause** button to initiate an automatic scan for available radio stations. The speaker will save all found stations.
3. Use the **Previous/Next Track** buttons to switch between the saved radio stations.

5. AUX Input

Connect an external audio device (e.g., MP3 player, laptop) to the '**AUX**' port using a 3.5mm audio cable (not included). Press the **MODE** button to select AUX mode. Audio from your external device will now play through the speaker.

6. Karaoke Function

With a microphone connected to the '**MIC**' input, ensure the speaker is in any audio playback mode (Bluetooth, USB, SD, or AUX). Your voice from the microphone will be mixed with the ongoing audio playback, allowing for karaoke.

MAINTENANCE

Cleaning:

Wipe the speaker's exterior with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or solvents, as these can damage the finish or internal components.

Battery Care:

To maximize battery lifespan, fully charge the speaker before its first use. Recharge the battery regularly, even if the speaker is not used for extended periods. Avoid exposing the speaker to extreme temperatures (hot or cold), as this can degrade battery performance.

Storage:

When not in use, store the speaker in a cool, dry place, away from direct sunlight, excessive humidity, and dust.

TROUBLESHOOTING

- **No Power:** Ensure the speaker is fully charged. Verify that the power switch is in the 'ON' position.
- **No Sound:** Check the volume level on both the speaker and your connected device. Confirm that the correct input mode (Bluetooth, USB, FM, AUX) is selected.
- **Bluetooth Not Connecting:** Ensure Bluetooth is enabled on your device and the speaker is in pairing mode. Move your device closer to the speaker to reduce interference. Try unpairing the speaker from your device's Bluetooth list and then re-pairing.
- **FM Radio Static:** Adjust the speaker's position to improve signal reception. Ensure you are in an area with good FM signal. Try performing an auto-scan for stations again.

- Microphone Not Working:** Ensure the microphone is securely plugged into the 'MIC.' input port. If the microphone requires power, ensure it is powered on or has fresh batteries.

SPECIFICATIONS

Feature	Specification
Model Name	DHG1
Dimensions (L x W x H)	18.5 x 25 x 38 cm
Weight	1.5 kg
Brand	DHG
Max Speaker Output Power	20W
Frequency Response	100 Hz
Connectivity Technology	Bluetooth
Audio Output Mode	Mono
Mounting Type	Floor
Speaker Type	Bookshelf
Special Features	Bluetooth, Portable
Recommended Uses	For smartphones or tablets
Battery Capacity	1200 mAh

SAFETY INFORMATION

- Do not expose the speaker to water, rain, or excessive moisture.
- Do not disassemble or attempt to repair the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from heat sources, direct sunlight, and open flames.
- Ensure proper ventilation around the speaker during use.
- Dispose of the battery responsibly according to local regulations. Do not dispose of batteries in fire.


WARRANTY AND SUPPORT

This DHG product comes with a standard manufacturer's warranty. For specific warranty terms, claims, or technical support, please contact DHG customer service directly.

You can also visit the official DHG brand store for more information and support resources:

[Visit the DHG Brand Store](#)

Related Documents - DHG1

	<p>Defy DHG 116 & DHG 117 Gas Hob: Owner's Manual and Installation Guide</p> <p>Comprehensive owner's manual and installation guide for the Defy DHG 116 (Black enamel) and DHG 117 (Stainless steel) gas hobs. Covers installation, operation, safety, maintenance, troubleshooting, and warranty information.</p>
	<p>ENDRESS ESE 608 DHG ES DIN Silent Stromerzeuger – Technische Daten und Ausstattung</p> <p>Detaillierte Informationen zum ENDRESS ESE 608 DHG ES DIN Silent Stromerzeuger, inklusive technischer Daten, Ausstattung und Motorisierung von HATZ.</p>
	<p>LEJRELET Oval Positioning Cushion - User Manual</p> <p>User manual for the DHG LEJRELET Oval, a flexible positioning cushion designed for patient comfort and pressure ulcer prevention, facilitating the 'Walking Cushion' repositioning concept. Includes technical specifications, care instructions, and safety guidelines.</p>
	<p>Märklin Henschel DHG 700 Model Locomotive 29468 User Manual</p> <p>Comprehensive user manual for the Märklin Henschel DHG 700 model locomotive (29468), covering safety, operation, digital functions (mfx, DCC, MM), maintenance, and spare parts. Learn how to operate and care for your H0 scale model train.</p>
	<p>Techbear DHG-D25D1 Multi-purpose Electric Hotpot: User Guide and Specifications</p> <p>User guide and specifications for the Techbear DHG-D25D1 Multi-purpose Electric Hotpot. This document details the product's working principle, usage instructions for various cooking methods (boiling water, noodles, hotpot, steaming, frying), and key technical parameters.</p>
	<p>Endress ESE 606 DHG-GT/A DUPLEX Generator Technical Specifications</p> <p>Detailed technical specifications for the Endress ESE 606 DHG-GT/A DUPLEX Power Generator, including output power, engine details, fuel consumption, noise levels, and dimensions.</p>

Documents - DHG – DHG1

[\[pdf\]](#) Catalog


p yuktih cdef hijiklf mnopq s mqtnq uvwq xnn DCNE 6 mar 2022 — d1ghZ ijkL n o d1gpZ qjirl d1gtZ ijul iv d1gtw d1gtx qjkl d1g0Z ojrl d1g0w Catalog JBIndustries 00114 51 CAT dcne UserFiles Resources |||

* , -/0--01,234056789;: 4== , ; ;0, 3 A2--23B, CDEFFHIJJIKLF UMNVOWPQQXSNNONQ

M MNQOTPQONSQUVWQXNN ... o dhg0 ojirl o YdZp gt Z _ i j u l b n c i d j k l e o f d p g t w i j u l n i j u l s d p g o w o j i r l n i j u l s d h g y d h g **d h g 1 d h g 1 h** q j k l o i j s l o o j k l s q j u l s d p g y Z d p g y w d p g y x d d p p g g y z x d p g z d p g d q j k l n i j k l q j k l n i j k l ...

lang:af score:17 filesize: 1.01 M page_count: 1 document date: 2021-09-16

JPS
HARMONIE SYNTHESIZER



[pdf]


nmffiiilmffi Jiggery Pokery JPS HS G RE shop 20220407094725533500000002 s3 amazonaws product documents
ffe084d62efb |||

..PS HAE MTII T =VII HE= zEE IPS.H.IEUIIIIt EVTJIHEEI EE o;.6I2 I dG nmffiiIImffI TffffiftrMHE q

...
rhoetoosecrDeaLtinyhnoFnebtouaeemtpcsrinocyucnnoatFntnlhveitlsierctaoestiuilorzre,necssder
, The **DHG1** and DHG2 harmonic oscillator, but individual „Cy„ inputs do include a global voltage
inputs

lang:en score:13 filesize: 7.72 M page_count: 36 document_date: 2017-10-22

JPS
HARMONIC SYNTHESIZER



[pdf]

Jiggy Pokery JPS HS G REshop 20220407094725533500000002 s3 amazonaws product documents 178f2cb82616
RF III

.,PS HAE MTil T =VII HE= zEE IPS.H,IEUlllIt EVTJIHEEI EE o:,6l2 I dG nmffiiilmffi TffffitrMHE g
 ...
 rhoetoosecrDeaLtinyhnoFnebtouaeemtpcsrinocyucnnoatFntnlhveitlsierctaoestiuilorzIre,necssder
 , The **DHG1** and DHG2 harmonic oscillator, but individual „Cy„ inputs do include a global voltage
 inputs

lang:en score:13 filesize: 7.72 M page_count: 36 document_date: 2017-10-22

[\[pdf\]](#) Documentation Guide Configuration Guide Release Notes

Management Center Configuration Guide Symantec A Broadcom Company Use Content Policy Language CPL to Create Authenticate Users Against Active Directory LDAP Test Network Connectivity MC 24 CMG techdocs broadcom content dam symantec security software web and network management center 2 4 generated s III

lang:en score:11 filesize: 12.11 M page_count: 833 document_date: 2020-04-08

Symantec Management Center Configuration & Management Guide

Management Center v2.4.1.1
Guide Revision: 4/8/2020



