

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Zeppelin](#) /
- › [Zeppelin LZ14 Marine Series Watch User Manual](#)

## Zeppelin 8886-2

# Zeppelin LZ14 Marine Series Watch User Manual

Model: 8886-2

## INTRODUCTION

This manual provides comprehensive instructions for the Zeppelin LZ14 Marine Series Watch, Model 8886-2. Please read this manual carefully before using your watch to ensure proper operation and maintenance. Keep this manual for future reference.





Figure 1: Front view of the Zeppelin LZ14 Marine Series Watch, showcasing its silver case, ice blue dial, and crocodile-look leather strap.

## PRODUCT OVERVIEW

The Zeppelin LZ14 Marine Series Watch is a sophisticated timepiece featuring a polished silver stainless steel case and a crocodile-look leather strap. It is equipped with a Swiss quartz movement and offers various functions including time display, chronograph, and date.

### Key Features:

- Polished silver stainless steel case with screwed back.
- Case diameter: approximately 42 mm.
- K1 Flat Mineral Glass for durability.
- Swiss quartz movement Ronda 5030.D, 6 stones.
- Waterproof up to 5 ATM (50 meters), suitable for everyday use and light water activities.
- Crocodile-look leather strap with silver-coloured stainless steel pin buckle.
- Luminous material on hands and index fingers for visibility in low light.



Figure 2: Side view of the Zeppelin LZ14 Marine Series Watch, highlighting the polished stainless steel case and crown.




Figure 3: Back view of the Zeppelin LZ14 Marine Series Watch, showing the screwed back case.

## SETUP AND INITIAL USE

### Setting the Time:

1. Pull the crown out to position 2 (the outermost position). The second hand will stop.

2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Push the crown back to position 0 (normal operating position). The second hand will resume movement.

### Setting the Date:

1. Pull the crown out to position 1 (the first click).
2. Turn the crown clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.
3. Once the date is set, push the crown back to position 0.

### Using the Chronograph:

The watch features a chronograph function for measuring elapsed time.

1. **Start/Stop:** Press the upper pusher (button A) to start the chronograph. Press it again to stop.
2. **Reset:** While the chronograph is stopped, press the lower pusher (button B) to reset all chronograph hands to zero.

## OPERATING THE WATCH

Your Zeppelin LZ14 Marine Series Watch is powered by a precise Swiss quartz movement. It requires one Lithium Metal battery (included) for operation.

### Water Resistance:

The watch is water-resistant up to 5 ATM (50 meters), which means it is suitable for everyday use, accidental splashes, rain, and short periods of recreational swimming. **It is not suitable for diving or prolonged submersion.** Ensure the crown is fully pushed in before any contact with water.



Figure 4: The Zeppelin LZ14 Marine Series Watch displaying its luminous hands and markers in low light conditions, ensuring

readability.

## MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch case and strap with a soft, dry cloth regularly to remove dust and dirt. For the stainless steel case, a slightly damp cloth can be used, followed by a dry cloth.
- **Avoid Chemicals:** Do not expose the watch to solvents, detergents, perfumes, or other chemical substances, as they may damage the case, strap, or internal components.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (above 60°C / 140°F or below 0°C / 32°F) or sudden temperature changes.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, which can affect the accuracy of the quartz movement.
- **Battery Replacement:** When the battery is depleted, the watch may stop or the second hand may jump in 2-second intervals (End-of-Life indicator). Replace the battery promptly by a qualified watchmaker to prevent leakage and damage to the movement.
- **Strap Care:** The crocodile-look leather strap should be kept dry. Avoid prolonged exposure to water, sweat, and direct sunlight to preserve its quality and appearance.



Figure 5: A close-up view of the Zeppelin LZ14 Marine Series Watch dial, showing the intricate details of the sub-dials, date window, and index markers.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch stops or runs intermittently.	Depleted battery.	Replace the battery.
Time is inaccurate.	Exposure to strong magnetic fields; low battery.	Demagnetize the watch (by a professional); replace battery.
Date does not change at midnight.	Time is set to AM/PM incorrectly; date set during restricted hours.	Advance the time by 12 hours; reset the date outside of 9 PM - 3 AM.
Condensation inside the crystal.	Temperature change; water ingress.	Seek professional service immediately to prevent damage.

## SPECIFICATIONS

Feature	Detail
Model Number	8886-2
Movement	Swiss quartz movement Ronda 5030.D, 6 stones
Case Material	Polished silver stainless steel
Case Diameter (without crown)	Approx. 42 mm
Case Height	Approx. 13 mm
Crystal	K1 Flat Mineral Glass
Water Resistance	5 ATM (50 meters)
Strap Material	Crocodile-look leather
Lug Width	22 mm
Weight	Approx. 74g
Battery Type	1 Lithium Metal battery (included)
Product Dimensions	15 x 4.5 x 1.14 cm

## WARRANTY AND SUPPORT

Zeppelin watches are manufactured with high standards of quality and precision. This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage.

For technical support, service, or warranty claims, please contact your authorized Zeppelin dealer or the official Zeppelin service center. Contact information can typically be found on the warranty card or the official Zeppelin website.

**Manufacturer:** Zeppelin

**ASIN:** B0CJC3WDJB



Figure 6: The official Zeppelin logo, representing the brand's heritage and quality.



Internationale Garantie  
International Guarantee

**2 Jahre Garantie · 2 years guarantee**  
Stempel der Verkaufsstelle und im Servicefall mit einsenden! 

Mod. No. \_\_\_\_\_  
Name \_\_\_\_\_  
Date \_\_\_\_\_  
Point of Sale \_\_\_\_\_



ZEPPELIN

POINT tec Elektronik GmbH  
Herstellung und Vertrieb:  
Steinheilstraße 6 · D-85737 Ismaning/München · service@pointtec.de · www.pointtec.de

Nicht übertragbar; gültig nur mit eigenhändiger Unterschrift des Fahrgastes auf dem Kontroll-Abschnitt.  
Not transferable. Requires for its validity the personal signature (on the voucher) of the passenger.

**LUFTSCHIFFBAU ZEPPELIN**

**FAHRKARTE NR. 1746**  
TICKET NO. Kabine / Cabin 107/26

für die Luftreise von **Friedrichshafen** über \_\_\_\_\_  
for the air-voyage from \_\_\_\_\_ via \_\_\_\_\_

nach **Köln**  
to \_\_\_\_\_

mit dem Luftschiff **Graf Zeppelin** am **5. Juli 1930**  
by the airship \_\_\_\_\_ on \_\_\_\_\_

gültig für Herrn/Frau/Fräulein **Dr. Sackaler**  
valid for Mr./Mrs./Miss \_\_\_\_\_

Einschiffung am Luftschiffhafen in **Friedrichshafen**  
Embarkation at the airport of \_\_\_\_\_

Abfahr des Autos von **Königstoss** am **5. Juli 1930** um **9.15** Uhr  
Departure of motor-car from \_\_\_\_\_ on \_\_\_\_\_ at \_\_\_\_\_

Der Betrag von **20 Reichsmark**  
The amount of \_\_\_\_\_  
**mit Luftschiffbau**  
has been duly paid.

ist ordnungsgemäß entrichtet.  
The ticket has been delivered against

Die Fahrkarte ist ausgeliefert gegen \_\_\_\_\_  
Signature \_\_\_\_\_

Empfangschein Nr. \_\_\_\_\_ vom \_\_\_\_\_  
deposit receipt No. \_\_\_\_\_ dated \_\_\_\_\_

Ort/Datum **Friedrichshafen 5. Juli 1930**  
Place/Date \_\_\_\_\_

**HAMBURG-AMERIKA LINIE**  
ALS GENERALAGENTUR  
**DR. L. MOERPEL-ROBBERG**  
G. m. b. H.  
Reisebüro  
Travel bureau  
Agent der Hamburg-Amerika Linie

Figure 7: An example of a Zeppelin international guarantee card, indicating warranty information and contact details.