

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HONEST](#) /

› [HONEST Butane Refillable Torch Lighter Model BCZ User Manual](#)

## HONEST BCZ

# HONEST Butane Refillable Torch Lighter Model BCZ User Manual

## INTRODUCTION

This manual provides essential instructions for the safe and effective use, maintenance, and troubleshooting of your HONEST Butane Refillable Torch Lighter, Model BCZ. Please read this manual thoroughly before operating the device and retain it for future reference.

The HONEST Butane Refillable Torch Lighter is designed for various applications, including culinary tasks, lighting, and craft projects. It features Piezo Ignition technology and an adjustable flame, capable of reaching temperatures up to 1300 °C (2372 °F).

## SAFETY INFORMATION

**WARNING: Keep out of reach of children. This product contains flammable gas when filled. Improper use can result in injury or fire.**

- Always operate the lighter away from face and clothing.
- Do not expose to temperatures exceeding 50°C (122°F) or prolonged sunlight.
- Never puncture or incinerate the lighter.
- Ensure the flame is extinguished after each use.
- Use only high-quality butane fuel for refilling.
- Do not attempt to disassemble or modify the lighter.
- The lighter is shipped without gas. Fill before first use.

## SETUP

### Butane Refilling Instructions

1. Ensure the lighter is completely cool and the flame adjustment is set to the minimum.
2. Hold the lighter upside down.
3. Insert the nozzle of a standard butane gas canister vertically into the refill valve located at the bottom of the lighter.

4. Press firmly for 5-10 seconds. Repeat 2-3 times to ensure a full refill.
5. Wait a few minutes after refilling before ignition to allow the gas to stabilize.



Figure 1: Illustration of the butane refilling process and flame adjustment dial on the HONEST torch lighter.

## Initial Ignition

After refilling, ensure the flame adjustment is set to a moderate level before attempting to ignite.

## OPERATING INSTRUCTIONS

### Ignition Process

The HONEST torch lighter features Piezo Ignition technology for easy operation.

1. Hold the lighter with the nozzle pointed away from you and any flammable materials.
2. Slide the ignition switch upwards to activate the flame.
3. Release the ignition switch to extinguish the flame.

# 360 Angle Flame

*Handle at any Angle ; Slide Up Type*

**Slide up**



**Figure 2:** Operating the slide-up ignition for the HONEST torch lighter.

## Flame Adjustment

The flame size can be adjusted using the regulator located on the side of the lighter.

- Turn the adjustment dial towards the '+' symbol to enlarge the flame.
- Turn the adjustment dial towards the '-' symbol to reduce the flame.
- Always adjust the flame to the desired intensity before ignition.

## Typical Applications

This versatile torch lighter is suitable for:

- **Culinary Uses:** Caramelizing sugar on crème brûlée, glazing ham, searing meats, roasting vegetables, melting cheese.
- **Lighting:** Fireplaces, candles, cigars.
- **Hobbies & Crafts:** Jewelry making, welding, various arts and crafts projects.

- **Outdoor Activities:** Camping ignition, BBQ.



**Figure 3:** The HONEST torch lighter in action, demonstrating its versatility for cooking and outdoor use.



## 1. Pilot Gas Stove



## 2. Light a Cigar



## 3. Gourmet Cooking



## 4. Outdoor ignition

Figure 4: Examples of the HONEST torch lighter's practical applications.

## MAINTENANCE

### Cleaning

- Ensure the lighter is cool and empty of fuel before cleaning.
- Wipe the exterior with a soft, dry cloth.
- Do not use abrasive cleaners or solvents, as these can damage the finish.

### Storage

- Store the lighter in a cool, dry place, away from direct sunlight and heat sources.
- Ensure the lighter is empty of fuel if storing for extended periods.
- Keep out of reach of children and pets.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lighter does not ignite.	No butane fuel; low fuel; clogged nozzle; faulty ignition.	Refill with butane; ensure proper flame adjustment; clean nozzle; if problem persists, contact support.
Flame is weak or inconsistent.	Low butane fuel; improper flame adjustment; air in fuel tank.	Refill with butane; adjust flame regulator; purge air from tank by pressing refill valve with a small tool before refilling.
Gas leaks during refilling.	Butane canister nozzle not properly aligned; refill valve issue.	Ensure canister nozzle is straight and firmly pressed into the valve; use a butane canister with a suitable adapter if necessary.
Flame angles upward or is yellow.	Improper fuel mixture; air in fuel tank; low quality butane.	Purge air from tank and refill with high-quality butane.

## SPECIFICATIONS

- **Brand:** HONEST
- **Model:** BCZ
- **Color:** Black
- **Material:** Plastic (ABS body), Aluminum Head, Ceramic
- **Product Dimensions:** 3.15"L x 1.18"W x 5.5"H (80mm L x 30mm W x 141mm H)
- **Item Weight:** 3.53 ounces (100 Grams)
- **Maximum Temperature:** Up to 1300 °C (2372 °F)
- **Ignition Type:** Piezo Ignition
- **Fuel Type:** Butane (not included)

# Portable Size

*Easy To Use*



Figure 5: Physical dimensions of the HONEST Butane Refillable Torch Lighter.

## WARRANTY AND SUPPORT

### Warranty Information

The HONEST Butane Refillable Torch Lighter is covered by a 90-day return policy and a 2-year service commitment from the manufacturer. Please retain your proof of purchase for warranty claims.

### Customer Support

For any questions, concerns, or assistance with your product, please contact HONEST customer support through the retailer where the product was purchased or visit the official HONEST store online.

[Visit the HONEST Store](#)

## IMPORTANT NOTE ON VIDEOS

No official product videos from the seller were available in the provided product data for embedding in this manual.