

[Manuals.plus](#) /

› [ocioc](#) /

› ocioc 52-inch Black Ceiling Fan with Light and Remote Control (Model 9001) Instruction Manual

ocioc 9001

ocioc 52-inch Black Ceiling Fan with Light and Remote Control (Model 9001) Instruction Manual

Your guide to safe installation, operation, and maintenance.

1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the ocioc 52-inch Black Ceiling Fan. This manual provides essential instructions for the safe and efficient use of your new ceiling fan. Please read all instructions carefully before installation and operation, and retain this manual for future reference.

Important Safety Instructions:

- **Electrical Safety:** Always disconnect power at the circuit breaker before installing, cleaning, or servicing the fan. Ensure all electrical connections comply with local codes and ordinances. If you are unsure about wiring, consult a qualified electrician.
- **Mounting:** The fan must be mounted to a ceiling joist or a securely anchored outlet box capable of supporting the fan's weight (approximately 10.36 pounds). Ensure the mounting structure can support at least 35 pounds.
- **Blade Clearance:** Maintain a minimum clearance of 7 feet from the floor to the bottom of the fan blades. Ensure blades are clear of any obstructions.
- **Dimmer Switches:** Do not use this fan with a dimmer switch. Using a dimmer switch may cause excessive noise and can damage the fan motor. It is recommended to use a regular on/off wall switch.
- **Remote Control:** The remote control requires two AAA batteries (not included). Insert batteries with correct polarity.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer service.

- 1 Ceiling Bracket
- 1 Integrated LED Light Kit
- 1 Remote Control and Holder (Batteries not included)
- 5 Blades (ABS material)

- 1 Downrod (6 inches)
- Mounting Hardware (screws, washers, wire nuts)

Image: Key components of the ocioc 52-inch ceiling fan, including the downrod, blades, LED light, and DC motor.

3. SPECIFICATIONS

Brand	ocioc
Model Name	9001
Color	Black
Size	52-inch
Product Dimensions	52"D x 52"W x 13"H
Number of Blades	5
Motor Type	Quiet Reversible DC Motor
Air Flow Capacity	Up to 6000 CFM
Noise Level	Under 30 dB
Light Type	Integrated LED Light Kit
Color Temperatures (CCT)	3000K (Warm White), 4000K (Neutral White), 5000K (Cool White)
Luminous Flux	1500 Lumen
Wattage	50 watts (Fan), 15 watts (Light)
Voltage	120 Volts (AC)
Control Method	Remote Control
Installation Type	Semi Flush Mount (Downrod)
Indoor/Outdoor Usage	Indoor

4. INSTALLATION

This section outlines the general steps for installing your ocioc ceiling fan. Refer to the detailed installation instructions included in your product packaging for specific diagrams and safety warnings. Professional installation is recommended if you are not familiar with electrical wiring.

Installation Steps Overview:

1. **Power Disconnection:** Turn off power at the main circuit breaker to prevent electrical shock.
2. **Mounting Bracket Installation:** Secure the ceiling bracket to a junction box rated for fan support or directly to a structural ceiling joist.
3. **Downrod Assembly:** Attach the downrod to the motor housing.
4. **Wiring:** Connect the fan's electrical wires to the household wiring according to the provided wiring diagram. Ensure all connections are secure.
5. **Canopy Installation:** Slide the canopy up to the ceiling bracket and secure it.
6. **Blade Attachment:** Securely attach the five ABS blades to the motor housing.
7. **Light Kit Installation:** Connect and install the integrated LED light kit.
8. **Power Restoration:** Restore power at the circuit breaker and test the fan's functions.

Mounting Options:

The ocioc ceiling fan can be installed on flat ceilings or slightly angled ceilings up to 12 degrees. The included 6-inch downrod is suitable for most standard installations.



Image: Illustration of the fan's 52-inch diameter and compatibility with both flat and angled ceilings (up to 12 degrees).

5. OPERATION

Your ocioc ceiling fan is controlled by the included remote control, offering various settings for optimal comfort.

Remote Control Functions:

- **Fan On/Off:** Turns the fan on or off.
- **Fan Speed Control:** Select from six wind speeds (Level 1-2: Low, Level 3-4: Medium, Level 5-6: High).
- **Light On/Off:** Turns the LED light on or off.
- **Color Temperature (CCT) Adjustment:** Cycle through 3000K (Warm White), 4000K (Neutral White), and 5000K (Cool White).

- **Timer Settings:** Schedule the fan to turn off automatically after a set period.
- **Fan Direction (Reversible Motor):** Switch between downdraft mode (summer) and updraft mode (winter).
- **Buzzer On/Off:** Mute or unmute the remote control's beep sound.

Light Memory Function:

The integrated LED light features a memory function. If you turn off the light and wait for more than seven seconds before turning it back on, it will retain the previously selected color temperature setting. If you turn it on within seven seconds, the color temperature will cycle to the next setting.



Image: Explanation of the LED light's memory function for color temperature settings.

Reversible DC Motor:

The fan's quiet DC motor allows for reversible blade rotation, optimizing air circulation for different seasons:

- **Summer Mode (Downdraft):** Blades rotate counter-clockwise, pushing cool air downwards to create a refreshing breeze.
- **Winter Mode (Updraft):** Blades rotate clockwise, drawing cool air up towards the ceiling and distributing warm air evenly throughout the room.



Image: Visual representation of the reversible DC motor's function for summer cooling and winter air circulation.

Adjustable Wind Speeds and Quiet Operation:

The fan offers six adjustable wind speeds, from a gentle breeze to strong cooling airflow. The high-efficiency DC motor operates at under 30 dB, ensuring a quiet environment suitable for bedrooms, living rooms, and other quiet spaces.



Image: Visual guide to the fan's 6-speed settings and their corresponding airflow intensity.



Image: Noise level comparison demonstrating the fan's ultra-quiet operation, ideal for sleep.



Image: Visual representation of the three adjustable color temperatures (Cool, Neutral, Warm White).

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ocioc ceiling fan.

- **Cleaning:** To clean the fan, wipe the blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish. The ABS blades are designed for low maintenance and are easy to clean.
- **Blade Fasteners:** Periodically check all blade fasteners to ensure they are tight. Over time, they may loosen due to vibration.

- **Light Kit:** The integrated LED light kit is designed for long-term use and does not require bulb replacement.
- **Power Disconnection:** Always disconnect power at the circuit breaker before performing any cleaning or maintenance.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your ocioc ceiling fan. If you experience problems not listed here, or if the solutions do not resolve the issue, please contact customer service.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control batteries are dead or incorrectly inserted.	Check circuit breaker; Ensure all wire connections are secure; Replace remote control batteries (2x AAA, not included) and check polarity.
Fan makes excessive noise	Loose fan blades or mounting hardware; Fan is connected to a dimmer switch.	Ensure all blade screws and mounting hardware are tightened; Do not use with a dimmer switch. Replace with a standard on/off wall switch.
Light does not work	No power to the light; Loose wire connections; Integrated LED failure.	Check circuit breaker; Ensure light kit wires are securely connected; If integrated LED fails, contact customer service for assistance.
Light color temperature changes unexpectedly	Light was turned on within 7 seconds of being turned off.	This is part of the light's memory function. To retain the previous setting, ensure the light is off for at least 7 seconds before turning it back on.
Remote control not responding	Dead or incorrectly inserted batteries; Remote not paired (if applicable); Obstruction between remote and receiver.	Replace batteries (2x AAA) and check polarity; Refer to remote pairing instructions in the full manual; Ensure clear line of sight to the fan's receiver.

8. WARRANTY AND SUPPORT

The ocioc 52-inch Black Ceiling Fan (Model 9001) comes with a**5-year warranty** from the date of purchase, covering manufacturing defects and material flaws under normal use.

For technical assistance, troubleshooting, or warranty claims, please contact ocioc customer service. Our team is available to provide round-the-clock support to ensure your satisfaction.

You can find more information and contact details by visiting the official ocioc store: [ocioc Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CJFQ39QQ>

More documents and user manuals: **<https://manuals.plus/>**