

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vente-unique](#) /

› [Vente-unique Komoni Extendable Dining Table User Manual](#)

Vente-unique 776527

Vente-unique Komoni Extendable Dining Table User Manual

Model: 776527

1. PRODUCT OVERVIEW

The Vente-unique Komoni dining table is a versatile and elegant piece of furniture designed for indoor use. It features an MDF tabletop and sturdy steel legs, offering a contemporary style. This table is extendable, accommodating 4, 6, or up to 8 people, making it suitable for various dining occasions.

The table's design allows for two extension leaves to be centrally placed, transforming its shape and seating capacity. It is delivered in two packages and requires self-assembly.

2. SAFETY INSTRUCTIONS

Please read and follow these safety instructions carefully before assembly and use to prevent injury or damage to the product.

- Keep all assembly hardware out of reach of children.
- Assemble the table on a soft, clean surface (e.g., carpet) to prevent scratches.
- Ensure all screws and fasteners are securely tightened before using the table. Periodically check and re-tighten as needed.
- Do not overload the table. The maximum recommended weight capacity is 100 kg.
- Avoid standing or sitting on the table.
- Use caution when extending or retracting the table to avoid pinching fingers or damaging the mechanism.
- Do not use abrasive cleaners or harsh chemicals on the table surface.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

Item	Description	Dimensions (L x W x H)	Weight
Package 1	Tabletop sections and main frame components	131 cm x 131 cm x 17 cm	40 kg
Package 2	Legs and hardware	83 cm x 51 cm x 13 cm	12 kg

Note: Small parts and hardware are typically included within one of the packages. Refer to the detailed assembly diagram for a complete list of parts.

4. SETUP AND ASSEMBLY

This table requires self-assembly. It is recommended to have two people for assembly due to the size and weight of the components. Please ensure you have adequate space and the necessary tools (e.g., screwdriver, Allen key, if not provided).

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the included assembly diagram to identify all tabletop sections, legs, extension mechanisms, and hardware.
3. **Attach Legs to Tabletop:** Secure the steel legs to the designated mounting points on the underside of the main tabletop sections using the provided screws and tools. Ensure they are firmly attached.
4. **Install Extension Mechanism:** If the extension mechanism is separate, attach it according to the diagram, ensuring smooth operation.
5. **Connect Tabletop Sections:** Join the main tabletop sections, ensuring they align correctly. Do not fully tighten all fasteners until all sections are loosely connected.
6. **Insert Extension Leaves (Optional during initial setup):** If you wish to assemble the table in its extended form, insert the extension leaves into the central mechanism.
7. **Final Tightening:** Once all components are in place and aligned, carefully tighten all screws and fasteners. Do not overtighten.
8. **Position the Table:** With assistance, carefully flip the table upright and place it in its desired location.



Image: The Komoni dining table in its compact, round configuration, ideal for smaller gatherings.



Image: A detailed view of the Komoni table's round top and the sturdy steel leg design.

5. OPERATING INSTRUCTIONS: EXTENDING AND RETRACTING THE TABLE

The Komoni dining table is designed for easy extension to accommodate more guests. It features two central extension leaves.

To Extend the Table:

1. **Unlock Mechanism:** Locate any locking mechanisms under the tabletop that secure the two main halves of the table. Unlock them.
2. **Separate Table Halves:** Gently pull the two main halves of the tabletop apart. The table will slide open, revealing the central space for the extension leaves.
3. **Insert Extension Leaves:** Take one or both extension leaves and carefully place them into the central opening. Ensure they fit snugly and align with the main tabletop surface.
4. **Close Table Halves:** Push the two main halves of the tabletop back together until they meet the inserted extension leaves. Ensure there are no gaps.
5. **Lock Mechanism:** Re-engage any locking mechanisms under the tabletop to secure the extended table.

To Retract the Table:

1. **Unlock Mechanism:** Unlock any locking mechanisms under the tabletop.
2. **Separate Table Halves:** Gently pull the two main halves of the tabletop apart, creating a gap.
3. **Remove Extension Leaves:** Carefully lift and remove the extension leaves from the central opening. Store them safely to prevent damage.
4. **Close Table Halves:** Push the two main halves of the tabletop back together until they meet, forming the compact

configuration.

5. **Lock Mechanism:** Re-engage any locking mechanisms to secure the table in its retracted position.



Image: The Komoni dining table in its extended, oval configuration, ready to accommodate more guests.



Image: Overhead view illustrating the central placement of the extension leaves when the table is extended.

6. MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Komoni dining table.

- **Cleaning:** Wipe the table surface with a soft, damp cloth. For stubborn marks, use a mild soap solution and immediately dry with a clean cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, solvents, or chemical-based sprays, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining, especially on the MDF tabletop.
- **Heat and Moisture:** Use placemats and coasters to protect the surface from hot dishes and moisture rings.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Stability Check:** Periodically check all screws and fasteners and re-tighten them if necessary to maintain stability.

7. TROUBLESHOOTING

If you encounter any issues with your Komoni dining table, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Table is wobbly	Loose fasteners; uneven floor.	Check and tighten all screws and bolts. Ensure the table is on a level surface; use furniture glides if needed.
Extension leaves do not fit or slide smoothly	Misalignment; debris in tracks; locking mechanism engaged.	Ensure the main table halves are fully separated and aligned. Check tracks for obstructions. Verify locking mechanisms are disengaged.
Gaps between tabletop sections when extended/retracted	Table halves not fully pushed together; extension leaves not properly seated.	Push the table halves firmly together. Ensure extension leaves are correctly inserted and flush with the main tabletop.
Scratches or marks on surface	Impact from objects; abrasive cleaning.	Minor scratches may be touched up with furniture repair kits. Prevent future damage by using placemats and avoiding abrasive materials.

8. SPECIFICATIONS

Brand	Vente-unique
Model Number	776527
Color	Black
Material	Engineered Wood (MDF), Steel
Dimensions (Compact)	120 cm (Length) x 120 cm (Depth) x 76 cm (Height)
Dimensions (Extended)	220 cm (Length) x 120 cm (Depth) x 76 cm (Height)
Extension Leaf Length	50 cm (each)
Product Weight	52.7 kg
Maximum Weight Capacity	100 kg
Seating Capacity	4 to 8 persons
Usage	Indoor
Country of Origin	France

9. WARRANTY AND SUPPORT

This product is subject to the standard return policy of 30 days from the date of purchase. For specific warranty details, product support, or to inquire about replacement parts, please contact Vente-unique customer service directly.

You can find more information and contact details by visiting the official Vente-unique store on Amazon:

[Visit Vente-unique Store](#)

Note: Availability of spare parts is currently unavailable information.