Statik PUP-0710-BLK

Statik Aktive Bone Conduction Headphones User Manual

Model: PUP-0710-BLK
Brand: Statik

Introduction

Welcome to the user manual for your Statik Aktive Bone Conduction Headphones. These open-ear headphones utilize bone conduction technology to transmit sound directly to your inner ear, allowing you to enjoy audio while remaining fully aware of your surroundings. This design is particularly beneficial for outdoor activities, workouts, and remote work where situational awareness is crucial.



Figure 1: Statik Aktive Bone Conduction Headphones.

What's in the Box

Your Statik Aktive Bone Conduction Headphones package includes the following items:

- Statik Aktive Bone Conduction Headphones
- Magnetic Charging Cable
- Protective Carrying Case
- User Manual



Figure 2: Retail packaging of Statik Aktive Headphones.



Figure 3: Statik Aktive Headphones stored in their protective carrying case.

Setup

Charging the Headphones

Before first use, fully charge your Statik Aktive headphones. Connect the magnetic charging cable to the charging port on the headphones and plug the USB-A end into a compatible power source (e.g., USB wall adapter, computer USB port). A full charge takes approximately 1.5 hours. For a quick boost, 10 minutes of charging provides up to 1.5 hours of playtime.

Pairing with a Device

Your Statik Aktive headphones use Bluetooth 5.3 for a stable wireless connection.

1. Ensure the headphones are powered off.
2. Press and hold the Power/Multi-function button (center button on the control panel) for 3 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "Statik Aktive" from the list of found devices.
5. Once connected, the LED indicator will turn solid blue, and a voice prompt will confirm "Connected."

Your browser does not support the video tag.

Video 1: This video demonstrates the unboxing, setup, and basic features of the Statik Aktive Bone Conduction Headphones, including how to wear them and their sound quality.

Operating Instructions

Button Functions

Button	Action	Function
Power/Multi-function (Center)	Press and Hold (3s)	Power On/Off
Power/Multi-function (Center)	Single Press	Play/Pause Music, Answer/End Call
Power/Multi-function (Center)	Press and Hold	Reject Call
Volume + (Front)	Single Press	Increase Volume
Volume + (Front)	Double Press	Next Song
Volume + (Front)	Press and Hold (3s)	Activate Voice Assistant
Volume - (Rear)	Single Press	Decrease Volume
Volume - (Rear)	Double Press	Previous Song

Wearing the Headphones

Place the neckband behind your head, resting the bone conduction transducers just in front of your ears, on your cheekbones. The ear hooks should rest comfortably over your ears to secure the headphones in place. Ensure a snug but comfortable fit for optimal sound transmission.



Figure 4: Proper placement of Statik Aktive Open-Ear Headphones.

Maintenance

Cleaning and Care

To maintain the performance and longevity of your headphones:

- Wipe the headphones with a soft, damp cloth after each use, especially after workouts, to remove sweat and dirt.
- Do not use abrasive cleaners or harsh chemicals.
- Store the headphones in their protective carrying case when not in use to prevent damage.

Water Resistance

The Statik Aktive headphones are IPX8 rated, meaning they are water and sweat-resistant. This makes them suitable for intense workouts and use in various weather conditions. However, they are not designed for swimming or prolonged submersion in water.



Figure 5: Water and sweat resistance features of Statik Aktive Headphones.

Troubleshooting

No Power

- Ensure the headphones are fully charged. Connect them to the charging cable and a power source.
- Press and hold the Power/Multi-function button for 3 seconds to power on.

Cannot Pair

- Make sure the headphones are in pairing mode (LED flashing blue and red).
- Ensure Bluetooth is enabled on your device and it is within 2 feet of the headphones.
- Forget/delete "Statik Aktive" from your device's Bluetooth list and try pairing again.
- Restart both your headphones and your device.

Poor Sound Quality

- Ensure the headphones are positioned correctly on your cheekbones, just in front of your ears.
- Adjust the volume on both the headphones and your connected device.
- Move closer to your connected device to ensure a strong Bluetooth signal.

Specifications

Feature	Detail
Model Name	PUP-0710-BLK
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Ear Placement	Open Ear
Audio Driver Type	Bone Conduction Driver
Battery Life	Up to 10 Hours
Charging Time	1.5 Hours
Water Resistance Level	IPX8 (Water Resistant)
Material	Silicone, Plastic
Item Weight	27.7 Grams (0.977 ounces)
Frequency Range	20 Hz - 20,000 Hz
Impedance	18 Ohm
UPC	810024054602

Warranty and Support

Warranty Information

Statik Aktive Bone Conduction Headphones come with a 2-Year Protection Plan. Please refer to the warranty card included in your package for detailed terms and conditions.

Customer Support

For further assistance, troubleshooting, or warranty claims, please visit the official Statik website or contact their customer support team. Specific contact details can be found on the product packaging or the Statik website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question