TOZO T10

TOZO T10 Wireless Earbuds User Manual

Model: T10 | Brand: TOZO

Introduction

Welcome to the user manual for your TOZO T10 Wireless Earbuds. These earbuds are designed to provide a comfortable fit, exceptional sound quality, and robust features for daily use. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your device to ensure an optimal user experience.
The TOZO T10 features Bluetooth 5.3 for stable connectivity, IPX8 waterproofing for durability, and a long-lasting battery with up to 55 hours of total playtime. You can also customize your audio experience using the TOZO App.

What's in the Box

Upon unboxing your TOZO T10 Wireless Earbuds, you should find the following components:

- TOZO T10 New Upgraded Wireless Earbuds
- Wireless Charging Case
- 6 pairs of Eartips (XS/S/M/L/XL/XXL)
- USB-C (A to C) cable (20cm)
- Quick Guide & User Manual

Setup

1. Initial Charge

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB-C cable to the charging case and a power source, or place the case on a wireless charging pad.
3. The indicator lights on the case will show charging status. A full charge takes approximately 1.5 hours for the earbuds and 2 hours for the case.



Image: TOZO T10 earbuds in their charging case, demonstrating both wireless charging and USB-C cable charging options.

2. Pairing with Your Device

The TOZO T10 earbuds utilize Bluetooth 5.3 for a fast and stable connection.

1. Open the charging case, and the earbuds will automatically enter pairing mode (indicator lights will flash).
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
3. Select "TOZO T10" from the list of available devices.
4. Once connected, the earbud indicator lights will turn off.



Image: A TOZO T10 earbud being held next to a smartphone, illustrating the seamless Bluetooth pairing process.

3. Achieving the Best Fit

Proper fit is crucial for optimal sound quality and comfort.

1. Choose the ear tips that provide a snug and comfortable seal in your ear canal. Six different sizes (XS/S/M/L/XL/XXL) are included.
2. Gently insert the earbuds into your ears and rotate them slightly until they feel secure and the sound is clear and full.



Image: Two TOZO T10 earbuds with feather motifs, emphasizing their lightweight design, alongside a diagram showing proper earbud placement for unmatched comfort.

Operating Your Earbuds

Touch Controls

The TOZO T10 earbuds feature intuitive touch controls for managing playback, calls, and voice assistants. Refer to the quick guide for specific tap functions.

TOZO App Customization

Enhance your listening experience by downloading the TOZO App.

- **Customize EQ:** Choose from 32 preset EQ modes or create your own personalized sound profiles.
- **Firmware Updates:** Keep your earbuds updated with the latest features and improvements.
- **Touch Settings:** Adjust the touch control functions to your preference.



Image: Multiple smartphone screens showcasing the TOZO App, highlighting the 32 preset EQ modes, over 100 white noise tracks, and more than 2000 user-shared EQ settings for customizable audio.

Battery Life

The TOZO T10 provides extended listening time:

- Up to 15 hours of playtime on a single charge.
- Total playtime of up to 55 hours with the charging case.



Image: A user enjoying music with TOZO T10 earbuds, illustrating the extended battery life of 55 hours total playtime and 15 hours single playtime.

Maintenance

Water Resistance

The TOZO T10 earbuds feature an IPX8 waterproof rating, protecting them from sweat and splashes. They are suitable for various sports and outdoor activities.



Image: TOZO T10 earbuds submerged in water, highlighting their IPX8 waterproof capability to withstand moisture challenges.

Cleaning

To maintain optimal performance and hygiene:

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Ensure charging contacts on both earbuds and case are clean and dry.

Troubleshooting

Issue	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then reopen to re-enter pairing mode. Forget "TOZO T10" on your device's Bluetooth list and try pairing again.

Issue	Possible Solution
Only one earbud playing sound	Ensure both earbuds are charged. Place both back in the case, close, then reopen. If issue persists, try resetting the earbuds (refer to the quick guide for specific reset instructions).
Low volume or poor sound quality	Check ear tip size for a secure seal. Clean ear tips and earbud mesh. Adjust EQ settings via the TOZO App.
Charging case not charging	Ensure the USB-C cable is properly connected or the case is correctly placed on the wireless charging pad. Try a different cable or power source.

Specifications

Feature	Detail
Model Name	TOZO T10
Bluetooth Version	5.3
Bluetooth Range	Up to 15 Meters
Battery Life (Single Charge)	15 Hours
Total Playtime (with Case)	55 Hours
Water Resistance Level	IPX8 Waterproof
Audio Driver Size	8 Millimeters
Frequency Response	20Hz - 20kHz
Charging Time (Earbuds)	1.5 Hours
Charging Time (Case)	2 Hours
Control Type	Touch Control / APP
Carrying Case Battery Capacity	600 Milliamp Hours

Warranty and Support

For detailed warranty information and customer support, please refer to the official TOZO website or the warranty card included with your product.
You can also download the full User Guide in PDF format for more comprehensive instructions. Download Full User Guide (PDF)

© 2025 TOZO. All rights reserved.