

[Manuals.plus](#) /

› [PayLessHere](#) /

› PayLessHere 35-Inch Z-Shaped Gaming/Computer Desk User Manual

PayLessHere 35 Inch Modern Z-Shaped Computer Desk

PayLessHere 35-Inch Z-Shaped Gaming/Computer Desk

USER MANUAL

Model: 35 Inch Modern Z-Shaped Computer Desk

Brand: PayLessHere

1. INTRODUCTION

Thank you for choosing the PayLessHere 35-Inch Z-Shaped Gaming/Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Designed for both gaming and home office use, this desk features a sturdy Z-shaped structure, a spacious carbon fiber desktop, and a convenient headphone hook.

Please read this manual thoroughly before assembly and retain it for future reference.



Image: The PayLessHere 35-Inch Z-Shaped Gaming Desk, showcasing its design and typical setup with a monitor, keyboard, and headphones.

2. SAFETY INFORMATION

To ensure safe use and prolong the life of your desk, please adhere to the following safety guidelines:

- This desk is intended for working use.
- Ensure the maximum monitor/equipment height does not exceed 28 inches to maintain stability.

- Proper assembly and secure use of the headphone hook are required. Do not overload the hook.
- Do not stand or sit on the desk.
- Keep liquids away from electronic equipment placed on the desk.
- Regularly check all screws and connections to ensure they remain tight.
- Avoid placing excessively heavy items on the desk, especially near the edges.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Panel (1)
- Z-Shaped Leg Frames (2)
- Headphone Hook (1)
- Hardware Kit (screws, bolts, adjustable foot pads, assembly tools if included)
- Assembly Instructions Manual (1)

4. SETUP AND ASSEMBLY

The PayLessHere Z-Shaped Gaming Desk is designed for easy assembly. It is recommended that one person assembles the desk. Please follow the step-by-step instructions provided in the included assembly guide.

Key Assembly Features:

- **Z-Shaped Structure:** The unique Z-shaped design provides exceptional stability and a modern aesthetic.
- **Adjustable Foot Pads:** Ensure stability on uneven surfaces by adjusting the foot pads at the base of the legs.
- **Headphone Hook:** Easily attach the headphone hook to keep your workspace organized.



**ADJUSTABLE
FOOT PAD**



STURDY Z-SHPED LEG DESIGN

Providing strong support

Image: Detail showing the sturdy Z-shaped leg design and the adjustable foot pad for leveling the desk.



Image: The integrated headphone hook, designed for convenient storage of gaming headsets or headphones.

5. OPERATING INSTRUCTIONS

Your PayLessHere Z-Shaped Gaming Desk is ready for use once assembled. It provides a versatile surface for various activities:

- **Gaming Setup:** The spacious desktop can accommodate multiple monitors, keyboards, mice, and other gaming peripherals. The ergonomic curved design provides comfortable access.
- **Home Office Workstation:** Ideal for laptops, desktop computers, and office supplies, offering ample space for productivity.
- **Study Desk:** Provides a stable and comfortable area for reading, writing, and studying.



Image: The gaming desk integrated into a modern room setup, demonstrating its use as a gaming workstation.



Image: A detailed view of the ergonomic curved design along the front edge of the desktop, enhancing user comfort.

6. MAINTENANCE

To keep your desk in optimal condition, follow these simple maintenance tips:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. The carbon fiber desktop is waterproof and scratch-proof, making it easy to clean.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.
- **Placement:** Avoid prolonged exposure to direct sunlight or extreme temperatures, which can affect the material integrity.



Image: A close-up view of the carbon fiber desktop, highlighting its texture and durable surface properties.

7. TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

- **Desk is Wobbly:**

Solution: Ensure all assembly screws are securely tightened. Adjust the individual foot pads at the bottom of the Z-shaped legs to level the desk on uneven floors.

- **Headphone Hook is Loose:**

Solution: Check the attachment point of the headphone hook and ensure its screws are tightened.

- **Surface Scratches/Damage:**

Solution: The carbon fiber desktop is designed to be scratch-proof. For minor marks, try cleaning with a soft cloth and mild cleaner. For significant damage, contact customer support.

8. SPECIFICATIONS

Detailed specifications for the PayLessHere 35-Inch Z-Shaped Gaming/Computer Desk:

Feature	Detail
Model Number	35 Inch Modern Z-Shaped Computer Desk
Product Dimensions (D x W x H)	21"D x 35"W x 28"H
Color	Red
Style	Modern
Base Material	Alloy Steel
Top Material Type	Wood (Carbon Fiber Texture)
Finish Type	Steel
Item Weight	19 Pounds
Special Feature	Adjustable (Foot Pads), Headphone Hook
Required Assembly	Yes
Recommended People for Assembly	1
Shape	Z-Shape
Tabletop Thickness	1 Inches

DIMENSIONS:




Image: A visual representation of the desk's dimensions, including length, width, and height.

9. WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation included with your purchase or contact the retailer directly. PayLessHere is committed to providing quality products and customer satisfaction.

If you have any questions, require assistance with assembly, or need troubleshooting support, please contact PayLessHere customer service through the platform where you purchased the product.

© 2025 PayLessHere. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CJJC58W4>

More documents and user manuals: <https://manuals.plus/>